



MOTOROLA

Service Manual

Level 3

Release 1



DIGITAL WIRELESS TELEPHONE



Model V.60c

CDMA 1900 MHz / CDMA 800 MHz / Analog 800 MHz

COMPUTER SOFTWARE COPYRIGHTS

The Motorola products described in this instruction manual may include copyrighted Motorola computer programs stored in semi-conductor memories or other media. Laws in the United States and other countries preserve for Motorola certain exclusive rights for copyrighted computer programs, including the exclusive right to copy or reproduce in any form the copyrighted computer program. Accordingly, any copyrighted Motorola computer programs contained in the Motorola products described in this instruction manual may not be copied or reproduced in any manner without the express written permission of Motorola. Furthermore, the purchase of Motorola products shall not be deemed to grant either directly or by implication, estoppel, or otherwise, any license under the copyrights, patents or patent applications of Motorola, except for the normal non-exclusive, royalty free license



| | | | |
|--|-----------|--|-----------|
| Product Description | 5 | Reciever Circuitary | 20 |
| CDMA Dual Band Trimode Phone. | 5 | Recieve Audio..... | 20 |
| General | 5 | Transmitter | 20 |
| V.60c Logic Circuit. | 6 | TransmitterAudio..... | 20 |
| Key Feautres of the Wally IC..... | 6 | Transmitter Circuitary | 21 |
| Key Feautres of the CCAP IC | 6 | CDMA PCS (1900 Mhz) Mode of Ops | 21 |
| V.60c RF Circuit | 7 | Reciever | 21 |
| CDMA-PCS 1900 Mhz Band Performance | | Reciever Circuitary | 21 |
| Specs. | 8 | Reciever Audio | 21 |
| Overall System CDMA 800Mhz. | 11 | Transmitter | 21 |
| Enviromental | 12 | Transmitter Audio | 21 |
| Foreward | 13 | Transmitter Circuitary | 22 |
| Scope of Manual | 13 | Frequency Synthesizer Circuitary..... | 22 |
| Replacement Parts Ordering | 13 | Transmit Power Control Circuitary | 22 |
| Service..... | 13 | Audio Logic Block Diagram..... | 23 |
| General Safety Information | 14 | RF Side Block Diagram..... | 24 |
| Portable Operation | 14 | | |
| Mobile Operation | 14 | | |
| | | | |
| Cellular Overview | 15 | Disassembly Procedure | 25 |
| Overall Concept. | 15 | Introduction | 25 |
| Hypothetical Cell System..... | 16 | Recommended Tools | 25 |
| Operation..... | 16 | Disassembly Procedure | 25 |
| Service Area | 16 | Assembly Procedure..... | 25 |
| PCS System | 16 | | |
| | | | |
| Circuit Description & Theory of Operation | 17 | Product Support Tools..... | 33 |
| V.60c Logic Circuit | 17 | Flashing and Flexing /NAM Programming | 33 |
| Key Feautres of the Wally IC..... | 17 | About Junior Board Operation | 33 |
| Key feautres of the CCAP IC..... | 18 | Test and Phasing | 35 |
| V.60c RF Circuit | 18 | Testing | 37 |
| Theory Of Operation | 19 | | |
| Amps | 19 | Troubleshooting | 43 |
| Receiver Circuitary | 19 | Introduction | 43 |
| Receive Audio | 19 | Troubleshooting & Repair..... | 43 |
| Transmitter | 19 | Testing and Repair | 43 |
| Transmit Audio | 19 | Troubleshooting | 44 |
| Transmitter Circuitary | 20 | No Turn On Debug Procedure | 44 |
| CDMA Cellular Mode Of Operation 800Mhz | 20 | General Charging Failures | 45 |

| | |
|---|------------|
| Test Procedure | 48 |
| Hardware Introduction | 48 |
| Automatic Call Processing Tests | 48 |
| Digital Test Measurements | 48 |
| Connections for performing tests | 49 |
| RF Cable test | 50 |
| Setup for analog call | 51 |
| Rx Sensitivity Test | 52 |
| Tx Power out test | 53 |
| Tx Frequency Error test | 54 |
| Tx Modulating Deviation Limiting Test | 55 |
| Tx Sat Deviation Test | 56 |
| Tx FM Hum and noise test | 57 |
| Tx hum and noise pass specification | 58 |
| Making a CDMA call | 59 |
| Setup for CDMA RF Parametric | 60 |
| Making a reciever sensitivity Measurement | 61 |
| Reciever Test Termination | 62 |
| CDMA Transmitter Tests | 63 |
| CDMA Transmitter Power Range Test | 64 |
| FER with AWGN Tests | 65 |
| Nam Programming | 67 |
| | |
| Replacement Parts | 71 |
| Mechanical Exploded Diagram | 72 |
| Mechanical Parts List | 72 |
| Electrical Parts List | 73 |
| | |
| Reciever 1900 CDMA | 85 |
| Troubleshooting Steps | 87 |
| | |
| Reciever 800 CDMA | 102 |
| Troubleshooting Steps | 103 |
| | |
| Reciever 800 AMPS | 118 |
| Troubleshooting Steps | 119 |
| | |
| RF Circuit (I) Reciever | 133 |
| Antenna | 134 |
| FEIC Circuit | 136 |
| ZIF SYN :A03 | 142 |
| ZIF:A03 | 145 |
| ZIF:A03 Reference Oscillator | 149 |

| | |
|--|------------|
| RF Circuit (II) Transmitter | 150 |
| ZIF:A03 | 151 |
| Mixer Exiter | 157 |
| PA &TX Power Control | 161 |
| PA Gate Supply | 162 |
| Power Detect | 165 |
| | |
| Audio Logic Circuit | 166 |
| PA | 168 |
| CCAP:A12 | 170 |
| Wally Internal Block Diagram | 176 |
| Memory | 179 |
| Wally Power | 181 |
| Connectors | 183 |
| | |
| 800 & PCS RX TX Signal Flow | 190 |
| PCS RX TX Flow | 191 |
| 800 RX TX Flow | 192 |



MOTOROLA

Cellular Subscriber Sector

Product Description

V.60c

CDMA Dual Band Tri Mode Phone

General:

This product (V.60c) is based on CDMA Platform-2000 reference Architecture. This is a Dual Band Tri Mode phone – 1900 Mhz CDMA / 800 Mhz CDMA/ 800 Mhz AMPS.

The clam form factor provides the smallest form factor (73 cc with 500 mAh battery), while maintaining the best usability, i.e maximizing the keypad and display sizes.

The 96 x 64 pixel array display will be larger than the current V-Series with improved readability, 3 lines using Synergy, Animation capability.

V.60c have a one line external display to allow viewing of caller ID and other phone status messages while the flip is closed. EL back lighting on both internal and external Caller ID displays with Hologram.

Painted metal housings will add a unique look and feel to V.60c. Improved usability with the new Synergy User Interface.

LED back lighting for keypad. 19 keys on keypad for synergy support. Volume keys and Smart key on side. Micro browser capable. Integrated headset jack located on the top.

Accessory Connector: 17 pin CE Bus connector, Access to USB, RS232, power and ground, analog and digital audio. Internal charging: V.60c supports dead battery operation with a CLA and Travel charger.

Batteries: Lithium Polymer and Lithium Ion (500mAh, 600mAh, 800mAh, 1100mAh), MT and MO SMS.



V.60c LOGIC CIRCUIT

The main chip sets of Platform 2000 reference architecture products consists of WALLY and CCAP IC. The memory chips are the FLASH and the RAM.

The WALLY includes the functionality of CPU + DSP + CSP + CIA. The WALLY is M-Core product (Motorola Proprietary) 32 bits. The CCAP IC works in Buck mode and provides the power management function of the phone. It also does the audio amplification and routing. It controls the 32Khz crystal, it interfaces with WALLY on 8 bit Parallel Bus. The communication to the accessories through the CSS bus connector is done through the CCAP IC. The audio through the external connector is digital. All audio interface is through CCAP IC- Alert, Phone Speaker, headset speaker & Microphone, External Speaker & Microphone, and Phone Microphone

The Wally IC integrates the functionality of Casper IC (which contains the MCU,

RIB, the CSP and the DSP) and CIA

Key features of the WALLY IC:

- M-Core integer processor, 32 bit RISC architecture
- 56600 NDE-UL DSP Core running at up to 70 Mhz @ 1.8V
- MCU-DSP interface
- CDMA signal processor (CSP3) ASIC
- 16 bit external memory interface for the MCU
- 8 bit parallel interface for CCAP
- 32-Input Interrupt Controller for the MCU
- Internal MCU ROM and RAM
- Special modules for CDMA mode (all are MCU peripherals):
- Dual 9.8304 M samples/sec 4-bit ADCs (RX I/Q with Receive AGC)
- Dual 4.9152 M samples/sec 9-bit DACs
- 13-bit linear CODEC
- 1-8bit, 2-10bit, 1-12bit measurement DAC
- 8-bit measurement ADC with 6 multiplexed inputs

- 10-bit AOC-loop control ADC and DAC (DSP peripheral)
- A UART with auto baud detection
- Universal serial bus (USB) interface module
- Serial Audio Port interface

Key features of the CCAP IC:

CCAP IC uses Buck converter mode with no 5V supply

- 8 bit parallel interface from Wally
- Buck and Boost converters
- 8-Linear voltage regulators
- 2-Hi end linear regulators w/ common reference (PA Drain regulators)
- External B+ clamp regulator
- 3 Microphone Amplifiers
- Differential audio interfaces to and from Wally
- Audio Amps, Multiplexers and Speaker & Alert Drivers
- Headset and Send/End key detection
- Battery charger
- 6 input 8 bit ADC
- Real time clock (RTC) with coin cell backup supply and coin cell charger
- Timer circuits
- CE bus interface
- Vibrator and Backlight regulator inside the CCAP IC

The external memory consists of 32 Mega bit 1.8V FLASH and 4 Mega bit 1.8V SRAM

The butt plug is a 17 pin CE bus connector , which supports the USB and RS232 Serial communications. CE bus runs at 1.8V.

V.60c will not support the 3WB mode of communications.

Keypad connector is a 14 pin data no mating connector-keypad, compression type

32 Khz crystal controlled by CCAP IC for RTC and slotted mode operation.

The charging circuit consists of Fast charger which is similar to StarTac , V.60c phones will also support Mid Rate charger

The flex connector interfaces the main board with the Display, Speaker and the RTC Battery in the flip.

The accessory antenna port is present on the back side of the phone near the antenna.

All the logic parts and IC's are placed on one side and all RF parts and IC's are placed on another side of the PCB

V.60c RF CIRCUIT

The RF circuit is somewhat similar to Dual band Caliber/Shark product, the V.60c phone contains FE IC (the front end IC)

The receiver contains two complete receiver paths : 800 Mhz path that is used by 800 Mhz analog and 800 Mhz CDMA signals, and a PCS band(1900 Mhz) path for PCS signal. The two paths have different RF, LO and IF frequencies.

The switching of the antenna and accessory antenna port is mechanical, normally close circuit with antenna connector, but when accessory RF cable is inserted in the accessory port the switch opens the circuit with antenna and closes the circuit with the accessory port.

For Frequencies and channel numbers look at the table in this manual

The FE IC contains the LNA's , interstage filtering and Mixers, the switching and gain of the LNA's is controlled by the control signals

ZIF/SYN IC extracts the broadband signal from the IF , demodulate the analog signal and sends it to the audio logic side for further processing.

ZIF/SYN IC controls the Main VCO ,the second LO and the TX offset VCO (in analog mode).

V.60c uses the dual band VCO module for main

LO (one for the 800 mhz band and another for PCS band) The output is split into RX_LO and TX_LO

for both the bands.

V.60c uses the ME3 IC - the mixer exciter IC

The ME3 IC allows to control the RF output power. The ME3 IC requires two LO's, one for PCS, and the other for the 800 Mhz band.

The IF pins (input to the ME3 IC) are the same for any band. The control signal (TX Att) at the AGC pins control the gain of the ME3 IC.

There is an external interstage RF filter between the mixer and exciter.

From the mixer the outputs take two different paths one for TX PCS band and another for TX 800 Mhz band.

ME3 IC has 50 dBm attenuator control (input IF level= -23dBm , max output TX level= 25dBm)

At the output of ME3 IC band filter are used , in the PCS path two split band filters are used.

Two stage PA in 800 Mhz band and three stage PA in PCS band .

PA operates in depletion mode, therefore requires negative gate voltage.

In V.60c PA adjustable bias both Gate and Drain therefore the output power can be controlled by PA_B+ DAC and PA_Bias DAC besides ME3 IC (through Tx_Attn)

CDMA –PCS 1900 Mhz BAND

Performance specification:

General Frequency and channel information:

| <i>Channel No.</i> | <i>Tx Frequency (Mhz)</i> | <i>Rx Frequency (Mhz)</i> |
|--------------------|-----------------------------------|-----------------------------------|
| 25 | 1851.25 | 1931.25 |
| 200 | 1860.00 | 1940.00 |
| 400 | 1870.00 | 1950.00 |
| 600 | 1880.00 | 1960.00 |
| 800 | 1890.00 | 1970.00 |
| 1000 | 1900.00 | 1980.00 |
| 1175 | 1908.50 | 1988.50 |

The 1900 MHz band is split into 6 blocks(ABCDEF) of channels. usually only one block is used in a given geographic area. There are no “standard” primary and secondary channels.

The actual primary and secondary channel depends on which block is used.

The lower valid channel number is 25.

The higher valid number is 1175.

Total Number of valid channel numbers is 46.

1

Table 1: CDMA 1900MHz Performance Specifications General

| <i>Function</i> | <i>Specification</i> |
|-------------------------------------|--|
| Frequency Range | 1850 to 1910 MHz(tx), 1930 to 1990(RX) |
| RF Channel Bandwidth | 1.25 MHz |
| Channels | 46 (Channel number spaced at an increment of-25, beginning channel, #25 lowest frequency and ending channel number 1175 highest frequency) |
| Duplex Spacing | 80 MHz |
| Frequency Stability | Center Frequency* $\pm 8.5 \times 10^{-8}$ ± 150 Hz of incoming RX CDMA signal. |
| Operation Voltage | +3.6 V nominal (3.0 -4.4 V DC) |
| RF Power output | 0.20 Watts - 23 dBm into 50 ohms (CDMA, nominal) |
| input/output impedance | 50 ohms(nominal) |
| Spurious /Harmonic emissions | Complies with title 47, Part 22 of the code of federal regulations. |
| Vocoders | 8kbps, 13kbps, EVRC |
| Transmit Time Error | ± 1 US |
| Modulation Type | 1M25D1W(1.25MHz bandwidth), OQPSK, G7W(CDMA) |
| Transmit Duty Cycle | Variable- full, 1/2, 1/4, 1/8 rate(CDMA Mode) |
| CDMA Transmit Waveform Quality(rho) | 0.94 |
| Receive Sensitivity | -104dBm(CDMA, 0.5% Static FER, 8kbps Vocoder) |
| Display | 96 X 64 Pixel array (V.60c) have a one line external display to allow viewing of caller ID and other phone status messages while the flip is closed. |

Specifications CDMA - 800 MHz

General:

The 800 MHz CDMA channel numbering evolved from the Amps analog system which shares the same spectrum.

The Amps channel spacing is 30 KHz, because the CDMA signal BW=1.25 MHz, the actual CDMA signal must be spaced every 41 channels

$$(41 \times 30 \text{ KHz} = 1.23 \text{ MHz})$$

In a dual-mode system, CDMA signals would never occupy analog control channels 313 to 354.

A -System preferred channels : primary =283, Secondary = 691

B- System preferred channels : Primary =384, Secondary = 771

The lowest valid CDMA channel is 1013.

The highest valid CDMA channel is 777.

Table 2: Overall System CDMA 800MHz

| <i>Function</i> | <i>Specification</i> |
|--------------------------------------|---|
| Frequency Range | 824.04 - 848.97 MHz Tx, Channels 1 to 799, $f_{Tx} = 0.03 * N + 825$ MHz Channels 990 to 1023, $f_{Tx} = 0.03(N - 1023) + 825$ MHz 869.04 - 893.97 MHz Rx Channels 1 to 799 is $f_{Rx} = 0.03 * N + 870$ MHz Channels 990 to 1023, $f_{Rx} = 0.03(N - 1023) + 870$ MHz |
| Channel Spacing | 30 KHz |
| Channels | 832 |
| Duplex spacing | 45 MHz(amps) |
| Frequency Stability | +/- 2.5 ppm (Amps) |
| Operating Voltage | +3.6 v nominal (3.0v to 4.4 v DC) |
| Display | 96 X 64 Pixel array V.60c have a one line external display to allow viewing of caller ID and other phone status messages while the flip is closed. |
| RF Power Output | 0.6 watts - 28.0 dBm into 50 ohms (AMPS, nominal) 0.25 watts - 24.0 dBm into 50 ohms (CDMA, nominal) |
| Input/Output Impedance | 50 ohms (nominal) |
| Spurious / Harmonic Emissions | Complies with Title 47, Part 22 of the code of Federal Regulations. |
| Audio Distortion | Less than 5% at |
| Hum and Noise(C-MSG) | 32 dBm below +/- 8kHz deviation(transmit and receive) |
| Modulation | F3: + 12 kHz for 100% at 1 kHz, AMPS (wide) 1M25D1W (1.25 MHz bandwidth) CDMA |
| Transmit Audio Response | 6 dBm/octave pre-emphasis |
| Transmit Audio sensitivity | (AMPS) + 2.9 kHz deviation (nom.) @ 97 dBm SPL input @ 1 kHz |
| Transmit Duty Cycle | full, 1/2, 1/4, 1/8 rate (CDMA Mode) |
| CDMA Transmit Waveform Quality(Rho) | 0.94 |
| Receiver Sensitivity | -116 dBm (AMPS, SINAD, C-MSG weighted) Sinad 12dB or greater -104 dBm (CDMA, 0.5% Static FER) 0.5 % or less |
| Alternate Channel Desense Protection | -60 db@ +/- 60kHz (Amps) |

Table 3: Environmental

| <i>Function</i> | <i>Specification</i> |
|------------------------|---|
| Temperature Range | Operational -30 °C to +60 °C (-22 °F to +140 °F) Storage -55 °C to +85 °C (-67 °F to +185 °F) Thermal Shock -40 °C to +85 °C (-40 °F to +185 °F) meets Mil. Std. 810C |
| Shock | Exceeds EIA Standards RS152B (Section 15) and IS-19 |
| Drop | Exceeds EIA Standards RS316B and IS-19 |
| Humidity | 95% Relative Humidity; meets EIA Standard IS-19 |
| Vibration | Exceeds EIA Standards RS316B and IS-19 |
| Salt Fog | Salt Solution fog at 35 °C (95 °F), tested for 48 hours |
| Dust | 140 mesh blown silica flour test, tested for 5 hours |
| Notes: | <ul style="list-style-type: none"> • EIA (Electronic Industries Association) Standard RS152B states the minimum standards for Land Mobile Communications, FM or PM transmitters 25-470 MHz. • EIA IS-19 states the recommended standards for 800 MHz cellular subscriber units. • EIA Standard RS316B states the standards for portable land mobile communications. • U.S. Military Standard 810D establishes uniform environmental test methods for determining the resistance of equipment to the effects of natural and induced environments peculiar to military operations. • TIA/EIA/IS-98 Recommended Minimum Performance Standards for Dual-Mode Wide band Spread spectrum Cellular Mobile Stations. |

Specifications subject to change without notice.

Foreword

Scope of Manual

This manual is intended for use by experienced technicians familiar with similar types of equipment. It is intended primarily to support basic servicing, which consists primarily of mechanical repairs and circuit board replacement.

Authorized distributors may opt to receive additional training to become authorized to perform limited component repairs. Contact your regional Customer Support Manager for details.

Replacement Parts Ordering

Motorola maintains a parts office staffed to process parts orders, identify part numbers, and otherwise assist in the maintenance and repair of Motorola Cellular products. Orders for all parts should be sent to the Motorola International Logistics Department at the following address:

Accessories and After market Division Motorola Personal Communications Sector

Schaumburg, IL 60196

International Motorolans that need to purchase parts should contact AAD via one of the following numbers:

Phone: 1-847-538-8023, Fax: 1-847-576-3023

However, domestic Motorolans should contact AAD via one of the following numbers:

Phone: 1-800-422-4210, Fax: 1-800-622-6210

<http://accesssecure.mot.com/Accesspoint/cgi-bin2/SoftCart.exe/Accesspoint/quick.html?L+test+rkod3498+930004870>

When ordering replacement parts or equipment information, the complete identification number should be included. This applies to all components, kits, and chassis. If the component part number is not known, the order should include the number of the chassis or kit of which it is a part, and sufficient description of the desired component to identify it.

Model and Kit Identification

Motorola products are specifically identified by an overall model number on the product label. In most cases, assemblies and kits which make up the equipment also have kit numbers stamped on them.

Service

Motorola's regional Cellular Subscriber Service Centers offer some of the finest repair capabilities available to Motorola Subscriber equipment users. The Cellular Subscriber Service Centers are able to perform computerized adjustments and repair most defective transceivers and boards. Contact your regional Customer Service Manager for more information about Motorola's repair capabilities and policy for in-warranty and out-of-warranty repairs in your region.

General Safety Information

CAUTION

Do not jump start vehicle or use an automotive battery charger while the vehicle adapter option and the portable radiotelephone are connected to the vehicle electrical system, as this may cause serious damage to the radio. Disconnect the radio by removing the cable kit fuses.

Portable Operation

DO NOT hold the radio so that the antenna is very close to, or touching, exposed parts of the body, especially the face or eyes, while transmitting. The radio will perform best if it is held in the same manner as you would hold a telephone handset, with the antenna angled up and over your shoulder. Speak directly into the mouthpiece.

DO NOT operate the telephone in an airplane.

DO NOT allow children to play with any radio equipment containing a transmitter.

Mobile Operation (Vehicle Adaptor)

As with other mobile radio transmitting equipment, users are advised that for satisfactory operation of the equipment and for the safety of personnel, it is recommended that no part of the human body shall be allowed to come within 20 centimeters of the antenna during operation of the equipment.

DO NOT operate this equipment near electrical blasting caps or in an explosive atmosphere. Mobile telephones are under certain conditions capable of interfering with blasting operations. When in the vicinity of construction work, look for and observe signs cautioning against mobile radio transmission. If transmission is prohibited, the cellular telephone **must be turned off** to prevent any transmission. *In standby mode, the mobile telephone will automatically transmit to acknowledge a call if it is not turned off.*

All equipment must be properly grounded according to installation instructions for safe operation.



Cellular Overview

Table 4:

| Note |
|---|
| The following description is intended only as a preliminary general introduction to cellular systems. This description is greatly simplified and does not illustrate the full operating capabilities, techniques, or technology involved in cellular systems. |


Overall Concept

Cellular systems are used to provide radio-telephone service in the frequency range of 824-894 MHz.

A cellular system provides higher call handling capacity and system availability than would be possible with conventional radiotelephone systems that require total system area coverage on every operating channel. The cellular system divides the system coverage area into several adjoining sub-areas, or cells.

Each cell contains a base station (cell site) which provides transmitting and receiving facilities. CDMA is a "spread spectrum" technology, which means that it spreads the information contained in a particular signal of interest over a greater bandwidth than the original signal. With CDMA, unique digital codes, rather than separate RF frequencies or channels are used to differentiate subscribers.

The codes are shared by both the mobile station and base station and are called "pseudo-random code sequences". Since CDMA is a spread spec-



trum technology, all users share a range of the radio spectrum. CDMA cell coverage is dependent upon the way the network is designed. For each system 3 characteristics must be considered: coverage, quality, and capacity. These 3 must be balanced for desired level of performance.

Some of the CDMA benefits are:

- Improved call quality with better and more consistent sound.
- Enhanced privacy.
- Variable rate vocoder.
- Soft hand off.

Hypothetical Cell System

Operation

In Figure 1: “Hypothetical Cell System”, the area bounded by bold lines represents the total coverage area of a cellular system. This area is divided into several cells, each containing a cell site base station which interfaces radiotelephone subscribers to the switching system. Since there are no reserved channels for each cell in CDMA, a user has a better chance of completing a call. Also, now there is no hard handoff between cell sites since all sites operate on the same frequency. This is called soft handoffs. In this system, subscribers in cell A & D simultaneously operate in the same frequency. As a user moves from cell site to cell site, the base station monitors the signal strength of the user. Based on this signal strength, the base station decides which cell shall carry the call.

When a radiotelephone is in use well within a cell, the signal strength received at the cell site base station will be high. As the phone is moved towards the edge of the cell, its received signal strength decreases. Signal strength information therefore provides an indication of the subscriber's distance from a cell's base station. This change is handled automatically, and is completely transparent to the user. For example, assume that a cellular tele-phone initiates a call in cell A and then moves across the system area through cells B and C to cell D. As the phone moves into cell B, it is instructed to change to a different frequency that operates through the B cell on that frequency. A similar change is performed when the phone moves from cell B to cell C and again when the phone moves from cell C to cell D.

In this example, the radiotelephone has operated in four cell sites, through four cell sites, and on the same spread spectrum without interruptions in voice communications. As the radiotelephone leaves a cell, the frequency on which the phone and base station were operating is made available to another subscriber in that cell. Since this radiotelephone is dual mode, the radiotelephone can operate in either a CDMA system or Analog system.

Service Area

The area within which calls can be placed and received is defined by the system operator. (Because this is a radio system, there is no exact boundary that can be drawn on a map.) If the portable is outside the radio service area, a No Svc (no service) message will appear on the phone's display, and calls cannot be placed or received. If this happens during a conversation, the call is lost. Places where the ability to place or receive calls would be lost are in totally enclosed areas, such as underground parking garages, in buildings without windows, and in elevators. This situation would be indicated either by the No Svc message illuminating, or by the sound of either a fast busy signal or a high-low siren signal when call placement is attempted.

General usage in buildings having reasonable glass area is usually quite good. However, it may be necessary to move closer to a window to ensure reliable operation.

PCS System

(Personal communication System) is identical to this cellular system except that the radio telephone service in the frequency range of 1850 MHZ to 1990 MHZ and the duplex spacing is 80 MHZ.

**MOTOROLA***Cellular Subscriber Sector*

Circuit Description & Theory Of Operation

V.60c

V.60c Logic Circuit

The main chip sets of Platform 2000 reference architecture products consists of WALLY and CCAP IC. The memory chips are the FLASH and the RAM.

The WALLY includes the functionality of CPU + DSP + CSP + CIA.

The WALLY is M-Core product (Motorola Proprietary) 32 bits.

The CCAP IC works in Buck mode and provides the power management function of the phone. It also does the audio amplification and routing. It controls the 32Khz crystal, it interfaces with WALLY on 8 bit Parallel Bus. The communication to the accessories through the CE bus connector is done through the CCAP IC. The audio through the external connector is digital.

All audio interface is through CCAP IC- Alert, Phone Speaker, headset speaker & Microphone, External Speaker & Microphone, and Phone Microphone.

The Wally IC integrates the functionality of Casper IC (which contains the MCU, RIB, the CSP and the DSP) and CIA.

Key features of the WALLY IC:

- M-Core integer processor, 32 bit RISC architecture
- 56600 NDE-UL DSP Core running at up to 70 Mhz @ 1.8V
- MCU-DSP interface
- CDMA signal processor (CSP3) ASIC

- 16 bit external memory interface for the MCU
- 8 bit parallel interface for CCAP
- 32-Input Interrupt Controller for the MCU
- Internal MCU ROM and RAM
- Special modules for CDMA mode (all are MCU peripherals):
- Dual 9.8304 M samples/sec 4-bit ADCs (RX I/Q with Receive AGC)
- Dual 4.9152 M samples/sec 9-bit DACs
- 13-bit linear CODEC
- 1-8bit, 2-10bit, 1-12bit measurement DAC
- 8-bit measurement ADC with 6 multiplexed inputs
- 10-bit AOC-loop control ADC and DAC (DSP peripheral)
- A UART with auto baud detection
- Universal serial bus (USB) interface module
- Serial Audio Port interface

Key features of the CCAP IC:

CCAP IC uses Buck converter mode with no 5V supply

-
- 8 bit parallel interface from Wally
- Buck and Boost converters
- 8-Linear voltage regulators
- 2-Hi end linear regulators w/ common reference (PA Drain regulators)
- External B+ clamp regulator
- 3 Microphone Amplifiers
- Differential audio interfaces to and from Wally
- Audio Amps, Multiplexers and Speaker & Alert Drivers
- Headset and Send/End key detection
- Battery charger
- 6 input 8 bit ADC
- Real time clock(RTC) with coin cell backup supply and coin cell charger
- Timer circuits
- CE bus interface
- Vibrator and Backlight regulator inside the CCAP IC

The external memory consists of 32 Mega bit 1.8V FLASH and 4 Mega bit 1.8V SRAM.

The butt plug is a 17 pin CE bus connector , which supports the USB and RS23 Serial communications. CE bus runs at 1.8V.

V.60cV.60c will not support the 3WB or PST mode of communications.

Keypad connector is a 14 pin data no mating

connector-keypad, compression type 32 Khz crystal controlled by CCAP IC for RTC and slotted mode operation.

The charging circuit consists of Fast charger which is similar to StarTac , V.60cV.60c phones will also support Mid Rate charger.

The flex connector interfaces the main board with the Display, Speaker and the RTC Battery in the flip.

The accessory antenna port is present on the back side of the phone near the antenna.

All the logic parts and IC's are placed on one side and all RF parts and IC's are placed on another side of the PCB

V.60c RF CIRCUIT

The RF circuit is somewhat similar to Dual band Caliber/Shark product, the V.60cV.60c phone contains FE IC (the front end IC).

The receiver contains two complete receiver paths : 800 Mhz path that is used by 800 Mhz analog and 800 Mhz CDMA signals, and a PCS band(1900 Mhz) path for PCS signal. The two paths have different RF, LO and IF frequencies.

The switching of the antenna and accessory antenna port is mechanical, normally close circuit with antenna, but when accessory RF cable is inserted in the accessory port the switch opens the circuit with antenna and closes the circuit with the accessory port.

For Frequencies and channel numbers look at the table in this manual. The FE IC contains the LNA's , interstage filtering and Mixers, the switching and gain of the LNA's is controlled by the control signals. ZIF/SYN IC extracts the broadband signal from the IF , demodulate the analog signal and sends it to the audio logic side for further processing.

ZIF/SYN IC controls the Main VCO ,the second LO and the TX offset VCO (in analog mode).

V.60c uses the dual band VCO module for main

LO (one for the 800 mhz band and another for PCS band) The output is split into RX_LO and TX_LO for both the bands. V.60c uses the ME3 IC - the mixer exciter IC. The ME3 IC allows to control the RF output power. The ME3 IC requires two LO's, one for PCS, and the other for the 800 Mhz band.

The IF pins (input to the ME3 IC) are the same for any band. The control signal (TX Att) at the AGC pins control the gain of the ME3 IC. There is an external interstage RF filter between the mixer and exciter. From the mixer the outputs take two different paths one for TX PCS band and another for TX 800 Mhz band. ME3 IC has 50 dBm attenuator control (input IF level= -23dBm , max output TX level= 25dBm). At the output of ME3 IC band filter are used , in the PCS path two split band filters are used.

Two stage PA in 800 Mhz band and three stage PA in PCS band. PA operates in enhance mode, therefore requires positive gate voltage. In V.60c PA adjustable bias both Gate and Drain therefore the output power can be controlled by PA_B+ DAC and PA_Bias DAC besides ME3 IC (through Tx_Attn)

Theory of Operation

I. AMPS

RECEIVER

RECEIVER CIRCUITRY

The phone receives the RF signal from the Antenna or the RF test port, the received RF signal is routed through the Diplexer - FL53 to mono block duplex SAW filter – FL51. The RF signal is then routed to the Front End IC (FE IC) – U100 , which contains LNA which provides a 10-12 dB gain to the received RF signal, and U100 provides inter stage filtering and it contains Mixer which down converts the frequency

of the signal to IF which is 109.65Mhz.

The local oscillator signal which is input to the filter FL101 is 978 – 1004 Mhz. The VCO module U626 is controlled by the ZIF/SYN IC – U700.

The mixer output IF signal 109.65Mhz is routed through IF filter- FL160 into the ZIF/SYN IC U700 for mixing with the second LO ,filtering and demodulation.

RECEIVE AUDIO

DISC - signal an AMPS discriminator audio which is the output of FM demodulator in U700 is produced by mixing the IF signal with the second LO (which is controlled by U700) and then filtered. The audio on DISC line goes to WALLY IC-U1100 to be digitized. All receive audio filtering and gain control is performed in the digital domain within the WALLY which contains DSP, the processed RX audio is converted back to analog and routed to CCAP IC – U1200 on signals AUDIO_P and AUDIO_M. The CCAP - U1200 amplifies and route the audio signal (receive audio) to the speaker (phone speaker, boom speaker or external speaker). The alert tone originates in WALLY IC and follows the same path as receive audio except from CCAP it is routed to the alert.

TRANSMITTER

TRANSMITTER AUDIO

Audio from the Microphone (internal, boom or external) is routed through and amplified by CCAP – U1200 and then travel to the WALLY IC – U1100 on MIC1 and MICREF lines which is digitized by the CODEC inside the WALLY and the DSP present in WALLY performs the compression, pre-emphasis, limiting and band pass filtering function in the digital domain. All Amps signaling (SAT, ST, DTMF) is also generated in the digital domain by the DSP inside the WALLY. The digitized amps TX audio signal is

converted back to analog inside the WALLY and sent on FM line to the 154.8Mhz Tx offset VCO to modulate the transmitter frequency.

through IF filter- FL150 into the ZIF/SYN IC U700 for mixing with the second LO ,filtering and demodulation.

TRANSMITTER CIRCUITRY

The FM signal from WALLY modulates the Tx offset VCO signal which is external but controlled by ZIF/SYN – U700. The Tx IF modulated signal 154.8Mhz is input to the ME3 IC – U400 where it get mixed with the 979 – 1004 Mhz local oscillator signal. The Tx signal then passes through the band pass filter FL404 into the Power Amplifier (PA) – U900 where it is amplified and the output passes through the isolator U550 and then through TX band pass mono block duplex SAW filter FL51 and through diplexer FL53 to the antenna or RF test port.

II. CDMA CELLULAR (800Mhz) MODE OF OPERATION

RECEIVER

RECEIVER CIRCUITRY

The phone receives the RF signal from the Antenna or the RF test port, the received RF signal is routed through the Diplexer - FL53 to mono block duplex SAW filter – FL51. The RF signal is then routed to the Front End IC(FE IC) – U100 , which contains LNA which provides three stage gain to the received RF signal based on its strength, and U100 provides inter stage filtering and it contains Mixer which down converts the frequency of the signal to IF which is 109.8Mhz.

The FE IC is controlled by WALLY through the following signals: FEIC_G1, FEIC_G2, and MODE.

The local oscillator signal which is input to the filter FL101 is 978 – 1004 Mhz. The VCO module U626 is controlled by the ZIF/SYN IC – U700.

The mixer output IF signal 109.8Mhz is routed

RECEIVE AUDIO

Four outputs from U700 – RXIP, RXIM, RXQP, RXQM carries the base band signal of the receive digital call to the WALLY, the received QPSK data is gain controlled and converted to digital, the 1.2288 Mb/sec Rx data stream is then decoded by the CSP inside the WALLY to produce a signal containing only the desired data. The digital speech data is further decoded by the CELP vocoder a part of DSP within WALLY and then converted back into analog receive audio and routed to CCAP IC – U1200 on signals AUDIO_P and AUDIO_M.

The CCAP - U1200 amplifies and route the audio signal (receive audio) to the speaker (phone speaker, boom speaker or external speaker). The alert tone originates in WALLY IC and follows the same path as receive audio except from CCAP it is routed to the alert.

TRANSMITTER

TRANSMITTER AUDIO

Audio from the Microphone (internal, boom or external) is routed through and amplified by CCAP – U1200 and then travel to the WALLY IC – U1100 on MIC1 and MICREF lines which is digitized by the CODEC inside the WALLY and the DSP present in WALLY processes by CELP variable rate vocoder and then processed by the modem (CSP) within the WALLY which produces the 1.2288Mb/sec CDMA data stream. This stream is then converted to analog signals and send to ZIFSYN IC on four lines TXIP, TXIM, TXQP, TXQM. This modulates on the TX IF (QPSK modulation) 154.8Mhz TX offset VCO.

TRANSMITTER CIRCUITRY

The four signals TXIP, TXIM, TXQP, TXQM from WALLY modulates the Tx offset VCO signal which is external but controlled by ZIF/SYN – U700. The Tx IF modulated signal 154.8Mhz is input to the ME3 IC – U400 where it get mixed with the 979 – 1004 Mhz local oscillator signal. The Tx signal then passes through the band pass filter FL404 into the Power Amplifier (PA) – U900 where it is amplified and the output passes through the isolator U550 and then through TX band pass mono block duplex SAW filter FL51 and through diplexer FL53 to the antenna or RF test port.

III. CDMA PCS (1900Mhz) MODE OF OPERATION

RECEIVER

RECEIVER CIRCUITRY

The phone receives the RF signal from the Antenna or the RF test port, the received RF signal is routed through the Diplexer - FL53 to mono block duplex ceramic filter – FL50. The RF signal is then routed to the Front End IC(FE IC) – U100 , which contains LNA which provides three stage gain to the received RF signal based on its strength, and U100 provides inter stage filtering and it contains Mixer which down converts the frequency of the signal to IF which is 109.8Mhz.

The FE IC is controlled by WALLY through the following signals: FEIC_G1, FEIC_G2, and MODE.

The local oscillator signal RX_LO_PCS is 2039-2100 Mhz. The VCO module U636 is controlled by the ZIF/SYN IC – U700.

The mixer output IF signal 109.8Mhz is routed through IF filter- FL150 into the ZIF/SYN IC U700 for mixing with the second LO ,filtering and demodulation.

RECEIVE AUDIO

Four outputs from U700 – RXIP, RXIM, RXQP, RXQM carries the base band signal of the receive digital call to the WALLY, the received QPSK data is gain controlled and converted to digital, the 1.2288 Mb/sec Rx data stream is then decoded by the CSP inside the WALLY to produce a signal containing only the desired data. The digital speech data is further decoded by the CELP vocoder a part of DSP within WALLY and then converted back into analog receive audio and routed to CCAP IC – U1200 on signals AUDIO_P and AUDIO_M.

The CCAP - U1200 amplifies and route the audio signal (receive audio) to the speaker (phone speaker, boom speaker or external speaker). The alert tone originates in WALLY IC and follows the same path as receive audio except from CCAP it is routed to the alert.

TRANSMITTER

TRANSMITTER AUDIO

Audio from the Microphone (internal, boom or external) is routed through and amplified by CCAP – U1200 and then travel to the WALLY IC – U1100 on MIC1 and MICREF lines which is digitized by the CODEC inside the WALLY and the DSP present in WALLY processes by CELP variable rate vocoder and then processed by the modem (CSP) within the WALLY which produces the 1.2288Mb/sec CDMA data stream. This stream is then converted to analog signals and send to ZIFSYN IC on four lines TXIP, TXIM, TXQP, TXQM. This modulates on the TX IF (QPSK modulation) 189.8Mhz TX offset VCO.

TRANSMITTER CIRCUITRY

The four signals TXIP, TXIM, TXQP, TXQM from WALLY modulates the Tx offset VCO signal which is external but controlled by ZIF/SYN – U700. The Tx IF modulated signal 189.8Mhz is input to the ME3 IC – U400 where it get mixed with the 2039-2100 Mhz local oscillator signal. The Tx signal then passes through the SPLIT BAND SAW filter FL401 into the Power Amplifier (PA) – U520 where it is amplified and the output passes through the isolator U551 and then through TX band pass mono block duplex ceramic filter FL50 and through diplexer FL53 to the antenna or RF test port.

FREQUENCY SYNTHESIZER CIRCUITRY

The phone contains three PLL frequency synthesizers controlled by U700.

1. The main VCO : there are two main VCO modules- a) one synthesizer controls the tunable 979 – 1004Mhz main local oscillator – U626, which is ON during Cellular or 800Mhz mode. b) another synthesizer controls the tunable 2039-2100Mhz main local oscillator – U636, which is ON during PCS or 1900Mhz mode.
2. The Tx offset VCO: there are two modes and two frequency at which this oscillator which is internal to U700 works, but the tank circuit is external. There are two tank circuits one for Cellular mode (800 Mhz) which will set 309.6Mhz frequency for the oscillator to oscillate on. Another tank circuit for PCS mode (1900Mhz) which will set 379.6Mhz frequency for the oscillator to oscillate on. The Tx offset frequency is divided by 2 before being fed into the mixer for modulation.

3. The second LO: the second local oscillator also operates in two modes with two different frequencies: For AMPS mode the frequency is 219.3Mhz and for CDMA mode at cellular or 800Mhz band and PCS or 1900Mhz band the frequency is 219.8Mhz. The tank circuit is external to the U700. The frequency is divided by 2 before being fed into the mixer.

All the synthesizers obtain their reference frequency from the 16.8Mhz reference oscillator.


TRANSMIT POWER CONTROL CIRCUITRY

The transmit signal power (the output RF power) is controlled by the three control signals ZIF_VCA and ME_VCA from WALLY IC and PA_BIAS from CCAP IC. The output power is controlled at three places, ZIFSYN – U700 which has a gain control of max 40dB and ME3 IC- U400 which has a total gain of max 36dB and PA has a gain of max 27-32dB.

In Amps mode the power range is +8dBm to +28dBm. In CDMA mode the RF power range is from –50dBm to +23dBm.

In CDMA mode the power control operates in two mode: Open loop and Close loop. In open loop mode (at the beginning of registering – access probe) the power level is proportional to the received signal level, in close loop mode the power level is controlled by the CDMA cell based on the received signal strength at the cell site.

RF SIDE BLOCK DIAGRAM





Disassembly

Introduction

Care must be taken during the disassembly and reassembly of the unit in order to avoid damaging or stressing the housing and internal components. Ensure that a properly grounded high impedance conductive wrist strap is used while performing these procedures on electronic units.

Recommended Tools

The following tools are recommended for use during the disassembly and reassembly of the phone.

- Anti-Static Mat 6680387A95
- Ground Cord 6680334B36
- Wrist Band 4280385A59
- Plastic Prying Tool SLN7223A
- Rear Housing Removal Tool
- Dental Pick
- Tweezers
- T6 Torque Screw Driver
- Antenna Removal Tool **6680334F28**

CAUTION

Many of the integrated circuit devices used in this equipment are vulnerable to damage from static charges. An anti-static wrist band, connected to an anti-static (conductive) work surface, must be worn during all phases of disassembly, repair, and reassembly.

Disassembly Procedure

Refer to the disassembly instructions and photo sequence on the following pages.

Assembly Procedure

Once the unit is disassembled and the repair is carried out it then becomes obvious that to

assemble the unit, the procedure is the reverse of that previously completed for disassembly.

Antenna Removal:

Turn off the power.

Place the Antenna Removal tool over the antenna nut as shown in the picture below. Remove antenna by turning counterclockwise.



Battery Cover Removal:

Press and hold the battery cover release button next to the antenna. Remove the battery cover.



Battery Removal:

Remove the battery.

Label:

Remove the Label by applying heat with a heat gun gently. Care should be taken not to destroy (burn) the label or the housing. Save and re-use the Label.




Rear Housing Removal:

Unscrew the two top and two bottom screws on the rear housing. A collar held by the screws is released as soon as the 4 screws come off. There is a tab on either side of the front housing which holds the rear and board down. Pry it with the bezel stick and release both the tabs as shown in the picture.




Volume / Smart and VA Button Removal:

Remove the Volume / Smart and VA buttons as shown.




Z-Axis connector Removal:

The board is connected to the display assembly by a Z-Axis connector. Use the bezel stick to pry up the connector as shown in the picture.



Spacer Gasket Removal:

Remove the spacer gasket as shown.




Keypad Board Removal:

Remove the keypad as shown.



Domes or Popples Removal:

Remove the domes or popples. It is placed over the front housing.




Flip Disassembly


1. Disconnect the display flex from the transceiver board as shown below.
2. When removing the transceiver front housing from the knuckles be careful not to damage the flex or the flex connector.
3. Remove the screws from the flip assembly.

Note: To remove the screws after the lens has been placed onto the housing, at this time, you must break the lens. After the screws have been removed and the flip outer housing has been removed you should be able to remove the rest of the broken CLI lens to reuse the flip outer housing.

4. Remove the flip from the assembly fixture.



5. Using the flat end of a Bezel (black stick) place it into the parting line between the flip inner housing and the flip outer housing where they snap into the hinge barrel.




6. With the flat part of the black stick in the parting line twist the black stick in a clockwise or counter clockwise rotation.

Note: This will unlatch the flip inner housing from the hinge barrel. DO NOT PULL TO HARD ON THE FLIP INNER HOUSING. The hinge barrel will now be able to be removed from the flip outer housing.




7. After the hinge barrel is released from the flip outer housing slide the flip outer housing forward and the two housings should then come apart.



8. Remove the display from the flip inner housing. Be sure to remove the speaker from the gasket before removing the entire display assembly from the flip inner housing.

Note: The speaker gasket will get damaged when the display is removed.




9. Next place the display assembly into the winding fixture with the main display face down as though you were going to assemble a display.

Note: Make sure to clamp down the hinge barrel.

10. Next position the winding fixture handle all the way to the rear as though a display had just been assembled.



11. Next slide the display into the knuckle bit to unwind the fixture. The adapter bit will need to be somewhat manually aligned due to the fact that the winding fixture at present goes past the 900 degrees of rotation.



12. The display and the fixture should now be ready to unwind. With a slight amount of tension pull the display toward you. At the same time slowly pull the winding fixture handle toward you.

Note: The flex should start to unwind at this time. When the handle stops the flex will be completely unwound.



13. With the assembly still in the fixture hold the left knuckle with one hand and with the other hand insert a tweezers or other object that is able to disengage the shaft from the left knuckle.

14. Next slide the display flex out of the right knuckle shaft.

15. Remove the hinge barrel and knuckle assembly from the fixture.






MOTOROLA

Cellular Subscriber Sector

Product Support Tools

V.60c



V.60c/Timeport 270c/TARPON PRODUCT SUPPORT TOOLS

FLASHING/FLEXING/NAM PROGRAMMING

All P2K products that include V.60c, Timeport 270c and Tarpon are Wally based and are using the 17 pin CE Bus Connector which uses the USB and RS232 communication protocols. The following are the hardware and software requirements:

1. Personal computer with PST 2.3 software
2. Motorola test interface adapter box (junior board) - SYN8400A
3. Interface adapter power supply – SPN4029A or Wall charger SPN4278D
4. CE Bus cable SKN6304B
5. RF Port Connect Fixture Part # 6680334F29


About Junior board operation:

To use USB mode plug the USB plug into the type B port provided on the back of the box. In this mode RS232 is turned off and only USB is allowed. Dip switches inside the box determines the mode of selection:


SWITCH NUMBER

| MODE Selection | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 |
|--------------------------|------|------|------|----|------|------|----|------|
| Legacy TDMA flash | Down | Up | Up | Up | Up | Up | Up | Up |
| Legacy CDMA Serial Comm. | Up | Up | Down | Up | Up | Up | Up | Up |
| Legacy CDMA flash | Up | Up | Down | Up | Up | Up | Up | Up |
| Legacy CDMA datalog | Up | Down | Up | Up | Up | Up | Up | Up |
| P2K USB/RS232 | Up | Up | Up | Up | Up | Up | Up | Down |
| P2K Flash | Up | Down | Up | Up | Down | Up | Up | Up |
| P2K serial Comm. | Up | Down | Up | Up | Up | Down | Up | Up |
| USB | Up | Up | Up | Up | Up | Up | Up | Up |


Phoenix Phone Testing / Troubleshooting Fixture



SYN8400A – JUNIOR BOARD





FLASHING STATION



TEST AND PHASING

Gate 24 supports the testing and phasing of all P2K products, obtain the phasing and test software that includes V.60c, Timeport 270c and Tarpon. For more details on Test and Phasing contact International Service Engineering ISE-CDMA





TESTING: General Procedure for Analog Testing

- Connect RF and CE BUS connectors to radio and set power supply to level specified in the 12M issue X8.
- Before selecting suspend or other suspended commands for the radio, Data Mode must be selected first. Select Data Mode. If Data Mode step was successful, a message displaying “Returned From Radio: data stream xxx ” will appear in the status window. Only then, can you proceed with entering the Suspend command.
- Select the Suspend command. If the Suspend command was successful, the status window will turn green and display data sent and returned from the radio. The window will also display a message “P2K HEAD COMMAND = SUSPEND == >

SUCCESSFUL”. If the SUSPEND command was unsuccessful, the status window will turn red and display “Failed. Response = 0000,0”. If any subsequent suspended commands sent to the radio fail, the status window will turn red and display a failed message.

- After the successful entry of Data Mode and Suspend, select and or set the fields highlighted in yellow as shown in the CDMAComm screen shot.

Connect the Audio Out (Boom Speaker) of the boom/audio plug thru a 32 ohm resistor to boom ground. Inject an audio tone of 1004Hz at 2.2mVrms into the Audio In (Boom Mic). within the specifications listed.

| Parameter | V.60c Lower Limit | V.60c Upper Limit |
|---------------------------|-------------------|-------------------|
| Mic Bias | 2.0 VDC | 2.6 VDC |
| Loopback | 28.2 mVAC | 56.4 mVAC |
| Jack Sense | 1 | 1 |
| Headset Jack Ground Sense | 1 | 1 |

Set test set to 50Hz High Pass, 15KHz Low Pass filtering with De-Emphasis turned OFF. Measure the RMS audio signal at the Audio Out (Boom Speaker). The result should be within the specifications listed.

Loopback (Boom Mic Speaker)

Test Procedure

Select the SUSPEND button to put the phone into Suspend Mode.

Select CDMA 800 button under CP_MODE to put the radio in 800 CDMA Mode.

Under AUD_PATH command, set Input to 4 and Output to 6 to route Audio to/from Headset Jack. Under the AUD_LPB heading, select Vocoder 13K (CDMA) button to put the phone into full rate loopback mode.

Set AUD_LVL to level 3.

See View 1.

TROUBLE SHOOTING OR ANALYZING PHONE

P2K products V.60c, Timeport 270c and Tarpon DO NOT support the previous CDMA Handset test mode commands. P2K platform products supports two different types of TEST MODE COMMAND :

1. COMPUTER TEST MODE COMMANDS (software)
2. SPECIAL HANDSET TEST MODE COMMANDS

IMPORTANT:

1. DO NOT TURN THE TRANSMITTER ON IN CDMA MODE UNLESS YOU HAVE ATTACHED THE ANTENNA OR RF TEST PORT TO THE COMMUNICATION ANALYZER (HP8924, CMD80 Etc.)

Please read the Section “**Testing**” in this manual for more detail. Please read the Section “**Testing**” in this manual for more detail.

SPECIAL HANDSET TEST MODE COMMANDS:


P2K products also supports the handset test mode commands. This will help if you do not have a PC.

Five Keys and the display are used. The keys used are:

1. Menu key
2. Left soft key (to the left of Menu key denoted by -)
3. Right soft key (to the right of Menu key denoted also by -)
4. UP arrow key and Down arrow key

The soft keys to the Left and Right of the menu key are used to make the selection corresponding to their sides immediately above them in the display.

Manual Testing Thru Handset Test Mode Commands



Procedure to use the Hand set test mode commands:

1. Attach the RF cable and the power supply to the UUT and to the Communication analyzer and power supply or can use phone battery.
2. Press the following keys in the right sequence:
3. Menu+0+7+3+8+8+7+* (do it fast)
4. Enter default security code 000000 then select OK with the Right soft key

(If the default security code is changed then obtain the new security code by using the support studio).

5. Scroll using Up or down key and select TEST MODE and then Right soft key to select
6. Scroll up or down key to select ENABLED and then Right soft key to select
7. Now the phone is in the FTS Mode
8. FTS mode has several screens of menu's(which if you get familiar could be helpful)
9. By selecting the NEXT from the display screen by pressing the Right soft key seven times brings the screen that shows the menu's that read CP Mode, Load synth etc. If this screen doesn't appear then you need to change the auto cycle byte.
- 10.(Read below the process to change the auto cycle byte to enable handset test mode commands.).
- 11.Now use the UP/Down key to chose the commands, once you press any of up/dwn keys on this screen the phone is now suspended in test mode.
- 12.Make the selection as required to test the phone
- 13.After you select or change any item you must press the right soft key to chose commit
- 14.For the items listed in this menu the explanation from the previous products test mode commands
- 15.holds good. (eg. CP Mode means AMPS or CDMA 800 or PCS1900, Load synth means channel number etc.)
- 16.Phone will come out of test mode if the Menu and right soft key is pressed but the test mode remain enabled.

- 17.When you done with the trouble shooting make sure you go back in the same menu as listed in 5 and select DISABLED.
- 18.Once the commands are entered the keypad and the display can be taken out and the phone stays in the state as you have chosen as long as power is not disconnected.

Changing Auto cycle byte

- 1.Use the program CDMA COMM 2.0.4 version
- 2.Choose DIRECT ACCESS
- 3.Under SUSPEND click on DATA MODE then SUSPEND
- 4.At the bottom right corner you will see PARM - PARM PARAMETER
- 5.Choose from PARM PARAMETER 00 - AUTO-CYCLE BYTE
- 6.Choose to READ then click EXECUTE
- 7.The data window will display the contents.
- 8.Record the byte. (so that after you finish trouble-shooting replace the same data in the auto cycle byte)
- 9.Change the data byte to 06
- 10.Click on WRITE then click EXECUTE.

Entering Handset Test Command Mode

Enter the following on the handset to enter test command mode:

1. Menu + 0 + S + E + T + U + P + *
2. Enter the security code and press "OK" (right soft key)
3. Scroll down to "Test Mode" and press "SELECT"
4. Scroll to "Enabled" and click "SELECT"
5. Scroll using the right or left soft key to the Handset Test Command Menu

Upon scrolling up or down through the Handset Test Command Menu, the phone enters a suspended mode and must be restarted with the “Restart” option.

Menu Items

RESTART:

- After the phone enters handset test command mode, the only way to restart the phone is with the restart option.

DEFAULT:

- Currently not implemented but listed in the menu. This can be used to setup default test cases.

CP MODE: [AMPS, C 800, C 1900]

- Used to select the CP Mode of the phone.

LOAD SYNTH: [100 – 600]

- Used to select the channel used by the phone.

SET ATTN:

AMPS: [0, 1, 2, 3, 4, 5, 6, 7]

- Used to specify the attenuation of the AMPS power out.
- CDMA: [0 – 255]
- Used to specify the attenuation of the CDMA power out.

CARRIER: [ON, OFF]

- Used to enable or disable the carrier.

RX: [MUTE, UNMUTE]

- Used to mute or unmute RX audio.

TX: [MUTE, UNMUTE]

- Used to mute or unmute TX audio.

AUDIO LEVEL: [1 – 15]

- Used to select the audio level of the phone.

CDATA: [OFF, VAR RATE, FULL RATE,

HALF RATE, QURT RATE, EGTH RATE]

- Used to modulate data onto the carrier (AMPS) or begin transmit of CDMA data.

ADC: [THERM0, THERM1, BUSMODE, RSSI, MCI0, MCI1, RF DETECT, EXT B, MAIN TEMP, CCAP THERM, B PLUS, MAIN BATT, RTC BATT]

- Used to perform A/D readings of the various selections.

SPKR: [NOCHNG, MUTE, HNDST, CEBUS, HEADST]

- Used to route the speaker audio.

MIC: [NOCHNG, MUTE, HNDST, CEBUS, HEADST]

- Used to route the microphone.

SIDE TONE: [ON, OFF]

- Used to create an audio loopback on the phone.

SIGNAL TONE: [ON, OFF]

- Used to enable or disable the signal tone.

SAT TONE: [ON, OFF]

- Used to modulate SAT onto the carrier (AMPS only).

COMPd: [ON, OFF]

- Used to specify the current mode of the compander.

DTMF: [OFF, 1, 2, 3, 4, 5, 6, 7, 8, 9]

- Used to generate the various DTMF tones.

SET AFC: [0-255]

- CNG <increment>: Used to change the AFC Warp Value on the screen by the increment displayed.
- COMMIT: Used to commit the AFC Warp Value, and change the increment value to an opposite and smaller number than the previously selected until the value is –1. Pressing COMMIT again will then change the value to the maximum increment step

available.

VIBRATE: [ON, OFF]

- Used to specify the current state of the vibrator.

VERSION: [SOFTWARE MAJOR & MINOR, DSP ROM, DSP RAM]

- Used to display various version numbers.

INVM: [Verify, Changed]

- Used to default the NVM including all call timers.

RST NAM: [Verify, Changed]

- Used to default all NAMs to first-time power-up values.

LNA CTRL [Low /Mid / High]

- Gain settings to LNA

Troubleshooting

Introduction

Known good replacement parts and assemblies should be available to be used for troubleshooting by substitution, and for replacement of defective parts/assemblies. Defective circuit boards should be forwarded to the appropriate Motorola service facility for repair. Refer to the “Replacement Parts” section of this manual for a list of replacement part descriptions and part numbers.

CAUTION

Many of the integrated circuit devices used in this equipment are vulnerable to damage from static charges. An ESD-s workstation should be used whenever a transceiver is opened.

Troubleshooting and Repair

Refer to the disassembly instructions located in the “Disassembly” section of this manual for instructions on removing parts/assemblies.

Testing after Repair

After any repair work has been carried out, the unit should be thoroughly tested to ensure that it operates correctly. This is especially important if the Logic / RF assembly is replaced.

For general repairs which do not include replacing the Logic/RF assembly, simply placing a call and checking signal strength, and transmit and receive audio quality is normally sufficient.

When the Logic/RF assembly is replaced, the unit must have a comprehensive test on a CDMA cellular/PCS compatible communications analyzers. See “Testing” for further details. Placing a call on air is usually carried out at this stage to complete the testing procedure.

(Note: The field test guide will also provide you with additional information and help you in investigating a problem.

TROUBLESHOOTING

The goal in troubleshooting is to quickly narrow-down the possibilities to isolate a failure to a single faulty component. This is especially important before deciding to replace a multi-pin IC, filter, or other component that is difficult or risky to replace. Sometimes the problem will be visually obvious, for example: a cold solder joint, cracked chip, tombstone, etc. Other times, it will be necessary to measure a voltage. The RF/AL board level repair requires the following equipment: Personal Computer (with the troubleshooting software), Interface box(junior board)

I. NO TURN ON - DEBUG PROCEDURE

1. Turn on failed.
2. Visual check.
 - Check for any damaged parts.
3. Check short circuits.
 - Apply 4.4V power supply with 1A current limit to CE flash cable.
 - If the radio draw more than 0.5A, check all the CCAP regulators, make sure they are not shorted to ground.
 - Else go to step 4
4. Switch R1108 to R1107 to tie WDG to high.
5. Check for the power route to CCAP B+.
 - If B+ is present, go to step 6
 - Else check VR1202 pin 1
 - If there isn't a 4.4V on VR1202 pin 1
 - Check J1000 and make sure it is placed correctly
 - Else if there isn't a 4.4V on CR1050 pin 2
 - Replace Q1305 and reflow CCAP if needed.
 - Else check CR1050 and R1306, make sure they are placed correctly.
6. Check CCAP regulator output voltage.
 - If the voltages on the following regulators are correct , go to step 7.

Analog_1.8V: 1.875V
 Digital_1.8V: 1.875V
 Memory_Vcc: 1.875V
 Logic_2.75V: 2.775V
 V4: 2.775V
 Rx_2.75V: 2.775V

Else reflow CCAP or replace CCAP is reflow does not work.

7. Check the RTC clock from CCAP.

If there is a 32.768 KHz clock on R1253, go to step 8.

Else if there is no clock on R1253, reflow CCAP.

Else the phone running at CCAP internal clocks(32.768 KHz +/-

50%), check the RTC crystal Y1170

If there is no 32 KHz sine wave on Y1170, check C1171 and C1172, make

sure they are placed correctly before replace Y1170.

Else go to step 8.

8. Check the 16.8 MHz clock goes into Wally.

If there is a 16.8 MHz clock at C1173, go to step 9.

Else make sure the voltage on Q325 pin 2 and pin 3 are both 2.75V

9. Flash Analysis

If the Flash_CS is toggling, go to step 10.

Else reflow Flash or replace Flash if reflow does not work.

10. SRAM analysis

IF SRAM_CS is toggling, go to step 11.

Else reflow SRAM or replace SRAM if reflow does not work.

11. CCAP analysis

If CCAP_CS is toggling, reflow Wally or replace Wally if reflow does not work.

Else reflow CCAP or replace CCAP is reflow does not work.

12. Switch R1107 back to R1108.

If the phone turns on the first time during the debug process, wait 20~30 second to insure the software fully initialized the Flash SEEM.

II. GENERAL CHARGING FAILURES

- Charging icon not flashing
- Charging icon flashing but no charge current
- Charging icon flashing but charge current always greater than 500 mA
- Charging icon flashing but charge current unstable
- Charging Icon always shows fully charged
- No battery/charging Icon
- Invalid battery message

*Please note charging icon is located in upper right corner of main display. The shape of the icon is of a battery

Charging icon not flashing Debug tips:

- J1000 pins 1, 2, or 3 not connected
- EXTB+ pin of CCAP (pin D2 U1200) not making contact
- Q1305 may be missing or misplaced
- EXTBDREV pin of CCAP (pin E4 U1200) not making contact

Charging icon flashing but no charge current Debug tips:

- R1052, Q1050, CR1051 misplaced, missing, or bad
- CHRGC (pin C3 U1200) not making connection
- ISENSE (pin B2 U1200) shorted or not connected BATT+ (pin 4 J870) intermittent

Charging icon flashing but charge current always greater than 500 mA debug tips:

- R1052 or Q1050 shorted, misplaced or bad

- CHRGC (pin C3 U1200) not making connection or shorted to ground
- ISENSE (pin B2 U1200) shorted or not connected
- CCAP charge current register always > 90 hex (bad U1200)

Charging icon flashing but charge current unstable debug tips:

- Q1306, R1307 or Q1307 misplaced, shorted, or bad
- CHRGC (pin C3 U1200) not making connection or shorted
- ISENSE (pin B2 U1200) shorted or not connected

Charging Icon always shows fully charged debug tips:

- BATT+ pin (J870 pin 4) not connected properly
- MAINBATT pin (pin C3 U1200) not connected properly

No battery/charging Icon debug tips:

- BATT+ or BATT- pins (J870 pins 1 or 4) not connected properly
- MAINBATT pin (pin C3 U1200) not connected properly
- MAINTTEMP pin (pin D4 U1200) not connected properly
- TEMPBIAS pin (pin B1 U1200) not connected properly
- R1217 or R1244 not connected properly

Invalid battery message debug tips:

- BATT_Serial_data (pin 3 J870) not connected properly
- GPI08_0Wire (pin C9 U1100) not connected properly
- R1155 or R1113 not connected properly
- BATT+ or BATT- pins (J870 pins 1 or 4) not connected properly
- MAINBATT pin (pin C3 U1200) not connected properly

| Symptom | Probable Cause | Verification and Remedy |
|---------------------------------------|---|---|
| 1. Phone will not turn on or stay on. | a) Battery either discharged or defective. | <ol style="list-style-type: none"> 1. Measure battery voltage across a 50 ohm (>1 Watt) load. 2. If the battery voltage is <3.4 V DC, recharge the battery using the appropriate battery charger. 3. If the battery will not recharge, replace the battery. |
| | b) Battery connector open or misaligned. | <ol style="list-style-type: none"> 1. Visually inspect the battery connectors on both the battery pack and the transceiver, including the solder connections from the battery connector to the main PC board. 2. Realign the contacts or, if necessary, replace either the battery or battery connector. |
| | c) RF/Audio-Logic Board defective. | <ol style="list-style-type: none"> 1. Replace the keypad membrane with a known good part. 2. Temporarily connect 4.5 V DC to the battery contacts. 3. Depress the PWR button; if unit turns on and stays on, disconnect the power source and reassemble the phone with the new keypad membrane. |
| | d) Keypad board defective. | <ol style="list-style-type: none"> 1. Replace keypad board assembly with a known good assembly. 2. Temporarily connect 4.5 V DC to the battery contacts. Depress the PWR button. 3. If the units turns on and stays on, disconnect the power source and reassemble the phone with the new keypad board assembly. |
| | e) RF/AL Board Debugging Follow the no turn on Debug procedure. | <ol style="list-style-type: none"> 1. Remove the RF/Audio-Logic Board. Substitute a known good board. 2. Temporarily connect 4.5 V DC to the battery contacts. 3. Depress the PWR button; if unit turns on and stays on, disconnect the power source and reassemble the phone with the new RF/Audio-Logic board and re-test phone. |

| Symptom | Probable Cause | Verification and Remedy |
|--|---|--|
| 2. Phone exhibits poor reception and/or erratic operation (such as calls frequently dropping, weak and/or distorted audio, etc.) | a) Defective antenna or damaged antenna connector. b) Defective RF/ Audio-Logic Board. | 1. Make sure the antenna and antenna assembly is properly shaft ferrule is screwed into the antenna socket. 2. Replace the antenna with a known good antenna. 3. Check for loose or damaged cans. |
| 3. Display is erratic, or provides partial or no display. | a) Defective display module. b) RF/Audio-Logic board defective. | 1. Gain access to RF/Audio-Logic board or keypad board as described in the "Disassembly" section of this manual. 2. Check connection. If connection not at fault, proceed to b. Replace the RF/Audio-Logic Board |
| 4. Alert ringer volume is distorted or too low. | a) Alert ringer defective. b) RF/Audio-Logic board defective. | Replace the defective speaker or alert ringer with a known good alert/ ringer. Replace the RF/Audio-Logic Board |
| 5. Transmit audio is weak, distorted, or dead. | a) Microphone defective. b) RF/Audio-Logic board defective. | Replace defective microphone. Replace the RF/Audio-Logic Board |
| 6. Receive audio is weak and/or distorted. | a) Speaker defective. b) RF/Audio-Logic board defective. | Replace defective speaker. Replace the RF/Audio-Logic Board |

Test Procedure

Hardware Introduction

Patagonia allows keypad controlled testing.

This chapter includes the keypad button functions and recommended equipment setup to use when testing.

Automatic Call-Processing Tests

Most communications analyzers can simulate site in order to perform automatic call processing tests. Automatic call processing tests can be performed while the phone is in its power-up state. However, it is useful to do the tests with the phone in Test Mode Status Display.

Refer to the communications analyzer's manual for details about performing call processing tests. The following call processing test sequence is recommended:

1. Inbound call, analog mode
2. Outbound call, analog mode
3. Analog-to-Analog channel handoff
4. Analog-to-Digital channel handoff
5. Inbound call, digital mode
6. Outbound call, digital mode
7. Digital-to-Digital channel handoff
8. Digital-to-Analog channel handoff

Handoffs should be performed between low, middle, and high frequency channels.

Analog Test Measurements

- ? RX Sensitivity (SINAD)
- ? RX Audio Distortion
- ? TX Power Out
- ? TX Frequency Error
- ? TX Audio Distortion
- ? TX Maximum Deviation
- ? TX SAT Deviation
- ? TX ST Deviation

Digital Test Measurements

- ? Digital RX Sensitivity (FER)
- ? Digital Power Out
- ? TX Frequency Error
- ? Waveform Quality (Rho)

The analog and digital parameters are stored in EEPROM on the Transceiver Board. Each transceiver is shipped from the factory with these parameters already calibrated. However, if a board is repaired, these parameters should be measured and, if necessary, adjusted. Checking and adjusting calibration parameters is also useful as a troubleshooting/diagnostic tool to isolate defective assemblies.

Set up for Analog call

CALL CONTROL

Display

Data / Meas

Active

Register

Page

Access

Connect

Phone : 111-111-1111

ESN (dec) : 156-4460397

ESN (hex) : 9C440F6D

SCM : Class II I, Discont, 25MHZ

Active

Register

Page

Handoff

Release

System Type

AMPS

Contrl CHan

384

Amplitude

-50

dBm

Order

Chng PL 0

MS Id

1111111111

Phone Num

1111111111

SID

231

Voice Channel Assignment

CHan : -

212

Pwr Lvl : -

4

SAT :

5970 Hz

To Screen

CALL CTL

CALL CONFG

ANLG MEAS

SPEC ANLG

DIG MEAS

More

Select CALL CNTL button from the Analog Screen Control panel

? Select System type: **AMPS**

? Zero the RF Power meter in the: **Call**

Config Screen

? Set Amplitude to: **-50 dBm**

? Set SID: **Your phone System ID**

? Select: **Active**

? **Voice Channel Assignment Type:**

? Chan: **212**

? Pwr Lvl: **4**

? SAT: **5970Hz**

Registration

- Put the Test Set in Active state by selecting Active from the list on the left side of the screen.
- Select Data from the Data/Meas field. This is the default mode.
- Select Register from the list to register phone.
- If the registration message has been received, the Test Set will display registration data in the upper half of the screen as shown in the sample screen above.

Page

- Select page from the list on the left side of the screen.
- If the mobile responds, you will see the Access annunciator light briefly.
- Answer the call by raising the flip or press SEND on the mobile to start the conversation.
- The Connect annunciator lights. This is the Connect state.

Origination

- Dial the desired phone number on the mobile station and press SEND.
- The Access annunciator will light while the Test Set signals the mobile on the assigned voice channel.
- The connect annunciator will light if the mobile properly signals the Test Set.

TX Power Out Test

| TX | | TEST | |
|--------------|-----|--------------|-----|
| TX Frequency | OFF | FM Deviation | kHz |
| 834.99 | | 11.58 | |
| TX Power | dBm | AF Freq | kHz |
| 26.78 | | 1.0000 | |

| Tune Mode | Input Port | AF Anl In | AF Gen1 Freq | To Screen |
|---------------|------------|--------------|--------------|-----------|
| Auto / Manual | RF In/Ant | Audio In | 1.0000 | RF GEN |
| Tune Freq | If Filter | Filter 1 | kHz | RF ANL |
| 834.9900 | 230 kHz | 50 Hz HPF | AFGen1 To | AF ANL |
| MHz | | Filter 2 | 6.00 | SCOPE |
| Tx Pwr Zero | Ext TX Key | 15kHz LPF | V | SPEC ANL |
| Zero | ON / OFF | DE Emphasis | | ENCODER |
| | | 750 us / off | | DECODER |
| | | Detector | | RADIO INT |
| | | Pk + Max | | |
| | | | | More |

Communications Analyzer

Setup:

? Select **TX TEST** button from the Analog Screen Control panel

? **PWR** is measured in **dBm**

Set **Frequency Measurement** to **auto** or **manual** (display will show TX Freq. Error)

? Set **TX frequency** to **834.990 MHz**

? Set IF filter to 230 kHz

? Set **AF Filter 1** to **50 Hz**

? Set **AF Filter 2** to 15 kHz

? Set **AF gen1** for **1 kHz frequency** at **6V level** (output will go to the **audio** port)

Test Mode Commands:

CP Mode AMPS

Load synthesizer to channel 300

Turn on carrier

Set ATT power level from 1 to 7

The TX Power Out specification for each portable power level is as follows:

Power Step 0 25dBm - 29dBm

Power Step 1 25dBm - 29dBm

Power Step 2 25dBm - 29dBm

Power Step 3 21.5dBm - 25.5dBm

Power Step 4 17.5dBm - 21.5dBm

Power Step 5 13.5dBm - 17.5dBm

Power Step 6 9.5dBm - 13.5dBm

Power Step 7 5.3dBm - 9.5dBm

Refer to the TX troubleshooting section for radios not within the pass specifications.

Note: When taking measurements, remember to compensate for cable loss.

TX Frequency Error Test

| TX | | TEST | |
|--------------|-----|--------------|-----|
| TX Frequency | MHz | FM Deviation | kHz |
| 834.99 | | 11.58 | |
| TX Power | dBm | AF Freq | kHz |
| 26.78 | | 1.0000 | |

| | | | | |
|----------------------------|---------------------------|---|----------------------------|--|
| Tune Mode Auto / Manual | Input Port RF In / Ant | AF Anl In Audio In | AF Gen1 Freq 1.0000 kHz | To Screen |
| Tune Freq 834.9900 MHz | If Filter 230 kHz | Filter 1 50 Hz HPF | AF Gen1 To 6.00 V | RF GEN RF ANL AF ANL SCOPE SPEC ANL ENCODER DECODER RADIO INT |
| Tx Pwr Zero Zero | Ext TX Key ON / OFF | Filter 2 15kHz LPF DE Emphasis 750 μ s / Off Detector Pk + Max | | More |

Communications Analyzer

Setup:

- ? Select **TX TEST** button from the Analog Screen Control panel
- ? **PWR** is measured in **dBm**
- ? Set **Frequency Measurement** to **auto** or **manual** (display will show TX Freq. Error)
- ? Set **TX frequency** to **834.990 MHz**
- ? Set **IF filter** to **230 kHz**
- ? Set **AF Filter 1** to **50 Hz**
- ? Set **AF Filter 2** to **15 kHz**
- ? Set **AF gen1** for **1 kHz frequency** at **6V level** (output will go to the **audio** port)

Test Mode Commands:

- Enter Test Mode
- Initialize Test Mode
- Load synthesizer to channel 300
- Turn on transmit carrier
- Set ATT level to step 2

The frequency error measured on the communications analyzer must be less than ± 1 kHz.

TX Modulation Deviation Limiting Test

TX TEST

TX

TX Frequency: 834.99 MHz

TX Power: 26.78 dBm

TEST

FM Deviation: 11.58 kHz

AF Freq: 1.0000 kHz

Tune Mode: Auto / Manual

Tune Freq: 834.9900 MHz

Tx Pwr Zero: Zero

Input Port: RF In/Ant

If Filter: 230 kHz

Ext TX Key: ON / OFF

AF Anl In: Audio In

Filter 1: 50 Hz HPF

Filter 2: 15kHz LPF

DE Emphasis: 750 us / Off

Detector: Pk +-Max

AF Gen1 Freq: 1.0000 kHz

AFGen1 To: 0.40 V

To Screen: RF GEN, RF ANL, AF ANL, SCOPE, SPEC ANL, ENCODER, DECODER, RADIO INT

More

Communications Analyzer

Setup:

- ? Select **TX TEST** button from the Analog Screen Control panel
- ? **PWR** is measured in **dBm**
- ? Set **Frequency Measurement** to **auto or manual** (display will show TX Freq. Error)
- ? Set **TX frequency** to **834.990 MHz**
- ? Set **IF filter** to **230 kHz**
- ? Set **AF Filter 1** to **50 Hz**
- ? Set **AF Filter 2** to **15 kHz**
- ? Set **AF gen1** for **1 kHz frequency** at **4V level** (output will go to the audio port)

Test Mode Commands:

Enter Test Mode

CP Mode AMPS

Load synthesizer to channel 300

Turn "ON" carrier

Set ATT level to step 2

Unmute TX Audio path

Turn "ON" compandor

Turn "ON" SAT

The AF gen1 is stepped from 300 Hz to 3 kHz while the level is maintained at the 20dB (4V) override. The size of the Freq. Steps is 500 Hz.

View FM Deviation for reading.

TX Modulation Deviation Limiting Pass Specifications: 12 kHz as the upper limit.

TX SAT Deviation Test

TXTEST

TX Frequency

MHz

834.99

TX Power

dBm

26.78

FM Deviation

kHz

1.958

AF Freq

kHz

6.0000

Tune Mode

Auto /Manual

Tune Freq

834.9900

MHz

Tx Pwr Zero

Zero

Input Port

RF In/Ant

If Filter

230 kHz

Ext TX Key

ON / OFF

AF Anl In

FM Demod

Filter 1

50 Hz HPF

Filter 2

15kHz LPF

DE Emphasis

750 us / Off

Detector

Pk +-Max

AF Gen1 Freq

1.0000

kHz

AFGen1 To

6.00

V

To Screen

RF GEN

RF ANL

AF ANL

SCOPE

SPEC ANL

ENCODER

DECODER

RADIO INT

More

Communications Analyzer Setup:

- ? Select **TX TEST** button from the Analog Screen Control panel
- ? **PWR** is measured in **dBm**
- ? Set **Frequency Measurement** to **auto or manual** (display will show TX Freq. Error)
- ? Set **TX frequency** to **834.990 MHz**
- ? Set **IF filter** to **230 kHz**
- ? Set **AF Filter 1** to **50 Hz**
- ? Set **AF Filter 2** to **15 kHz**
- ? Set **AF gen1** for **1 kHz frequency** at **6V level** (output will go to the au-

Test Mode Commands:

- Enter Test Mode
- CP Mode AMPS
- Load synthesizer to channel 300
- Turn "ON" carrier
- Set ATT level to step 2
- Enable Signalling tone "ON"
- View FM Deviation for the reading.

The transponded peak SAT FM deviation should be 8 kHz ±800 Hz.

The demodulated signal on the communications analyzer should have an audio frequency of 10 Hz.

TX FM Hum and Noise Test

| DUPEX | | TEST | |
|---------------|-----|--------------|-----|
| TX Freq Error | kHz | FM Deviation | kHz |
| 4.07 | | 8.01 | |
| TX Power | dBm | AF Freq | kHz |
| 26.78 | | 1.0000 | |

| | | | | |
|------------|---------------|--------------|--------------|---|
| Input Port | RF Channel | AF Gen1 Freq | AF Anl In | To Screen |
| RF In/Ant | 333 | 1.0000 | FM Demod | <input type="radio"/> CDMA <input checked="" type="radio"/> CALL CNTL <input type="radio"/> SMS <input type="radio"/> AUTHEN |
| If Filter | Amplitude | kHz | Filter 1 | |
| 230 kHz | -80.0 | AFGen1 To | 50 Hz HPF | |
| Ext TX Key | dBm | Audio out | Filter 2 | |
| ON / OFF | | 50.0 | 15kHz LPF | |
| | Atten Hold | mV | DE Emphasis | <input checked="" type="radio"/> Analog <input type="radio"/> RX TEST |
| | On / Off | FM Coupling | 750 us / off | Config |
| | Output Port | AD / DC | Detector | |
| | RF Out / Dupl | Audio Out | Pk +-Max | TESTS |
| | | AC / DC | | |

CommunicationsAnalyzer

Setup:

4. Select **DUPLEX TEST** button from the Analog Screen Control panel

• **PWR** is measured in **dBm**

⌘ **SetFrequency Measurement** to **auto or manual** (display will show TX Freq. Error)

çÃ SetTX frequency to 834.990 MHz

Set IF filter to 230 kHz

çÃ SetAF Filter 1 to 50 Hz

Set AF Filter 2 to 15 kHz

çÃ Set AF gen1 for1 kHz frequency

Test Mode Commands:

1. Adjust AF Fcn1 to voltage to get 8 kHz peak deviation. (about 400mV)

4. Remove the audio cable which connects with AUDIO OUT in 8924C. Or change to 0mV at audio out level.

Test Mode Commands:

Enter Test Mode

CP Mode "ON"

Load synthesizer to channel

300

Turn "ON" carrier

Set ATT level to step 2

Unmute TX Audio path

Turn on compandor

Turn "ON" SAT tone

Measure the change in dB at FM Deviation on the screen.

- ## 2. Set AF Filter1 to C-MESSAGE

Set Detector to RMS.

3. Put the cursor on the unit of FM Deviation in the screen.

Press **SHIFT**, **REF SET** and knob.

We can see the change of the unit from kHz to dB. It is setting 0 reference.

TX Hum and Noise Pass Specifications: **-32dBm as the upper limit.**

Pseudo LED's show call Status

The "Transmitting" light means that the HP 8924C is configured and transmitting the required CDMA signals to make a call

Enter the expected RF channel number

Select Echo Mode

Zero the Power Meter

Set CDMA Generator Power to -60 dBm/1.23MHz

Select Protocol

Once the Phone Acquires Service, Register it by Using the Knob

Set up for CDMA call

1. Enter the channel number that the CDMA phone expects to find a CDMA system on. The IS-95A standard defines a primary and secondary channel number for both the A and B service providers. These channels are: 283 and 691 for the A side, and 384 and 777 for the B side. A CDMA phone will only look for a CDMA system on power-up at its programmed primary or secondary channels. The HP 8924C defaults to channel 384. The phone you are using is set to B side service with a primary channel of 384.

2. Select the necessary protocol (IS-95, ID-95A, JSTD-008). For this demo we select IS-95.

3. Select the Traffic Data Mode to Service Option 001 (duplexed voice mode).

4. Set the Data Type to echo. This will allow you to speak into the phone under test and hear the voice quality echoed in the phone via the CDMA link from the HP 8924C.


5. Zero the average power detector. This is a good time to perform this step since no power is being transmitted by the phone.

6. Finally, set the Sector A power to -60 dBm/1.23 MHz. You are now ready to make a CDMA phone call.

7. Make sure that the phone has acquired service (some type of display indicator on the phone).

8. Register the phone. This step is not required for mobile initiated calls. When registration is successful, the Registration Indicator will go out. The MS database should now show an ESN value.

Making a CDMA Phone Call



1. Press the HP 8924C's CALL button.

2. Notice the call status indicators are activated at each step in the call process. First the PAGE indicator activates when the HP 8924C sends out a page message on its paging channel. When the mobile answers with an access probe, the access probe indicator is activated.

3. The phone will now ring, or indicate on its' display there is an incoming call.

4. To complete the call, press the send key on the phone. The connected indicator should now be on. When the HP 8924C receives an acknowledgment from the phone that the traffic channel connection process is activated.

Setup for CDMA RF Parametric Measurements

| CDMA CALL CONTROL | | | | |
|--|-------------|------------------------------|-------------|--|
| <div> <input checked="" type="checkbox"/> Transmitting <input type="checkbox"/> Registering <input type="checkbox"/> Page Sent <input type="checkbox"/> Access Probe <input type="checkbox"/> Connected <input type="checkbox"/> Softer Handoff <input type="checkbox"/> Hard Handoff </div> | | | | |
| Avg. Power | | dBm | | |
| 17.38 | | Ideal Mobile Power: 17.0 dBm | | |
| Rf Channel | Handoff | Traffic Data Mode | MS ID | To Screen |
| 384 | Execute | Svc Opt 2 | Auto | <input type="radio"/> CDMA |
| Register | System Type | Data Rate | MS Database | <input checked="" type="radio"/> CALL CNTL |
| IS-95 | AMPS | Full | ESN | <input type="radio"/> Analog |
| Protocol | Channel | Power Meas | 81234CD4 | <input checked="" type="radio"/> RX TEST |
| IS-95 | 1 | Zero | Sctr A Pwr | Config |
| Rf Chan Std | SAT | | -90.0 | <input checked="" type="radio"/> PRNT CNFG |
| MS_AMPS | 5970Hz | | dBm/BW | |
| | Pwr Level | | | |
| | 4 | | | |

| CDMA CALL CONTROL | | |
|-------------------|-----|----------|
| CALL | ANS | END CALL |

Setup a CDMA Call with the following parameters:

- ? Traffic Data Mode:
Service Option 2
- ? Data Rate:
Full
- ? Set Sector A's power:
-90 dBm/1.23 MHz
- ? Press the front panel "CALL" key
CDMA CALL CONTROL

While service option 001 calls are useful for the verification of CDMA mobile functionality, parametric tests cannot be accurately made in this mode. The TIA IS-98A minimum performance standard recommends that testing be made using service option 002. In service option 002, the mobile under test demodulates the received signal and then re-transmits this data to the HP 8924C. This mode allows accurate receiver performance measurements.

To make a service option 002 call:

1. Press the END CALL front panel key to terminate the service option 001 call.
2. Return to the CDMA Call Control screen.
3. Change the Traffic Data Mode to Service Option 002.
4. Make sure that the Data Rate is set to Full.
5. Set Sector A's power to -90 dBm/1.23 MHz (this value may need some adjustment for varying cable losses - some phones with their associate fixtures may require higher levels due to path losses to make a phone call).

6. Press the HP 8924C's front panel CALL button.

The HP 8924C's call status indicators should now indicate that a call is connected. Depending on the phone being used, either SO2 or Loop-back will be shown on the phone's display. Also available is service option 03 (voice EVRC), along with service option 09 and service option 32768 for 14.4K vocoder type phones.

Making a Receiver Sensitivity Measurement

CDMA CELLULAR MOBILE RECEIVER TEST

Test Status

Connected

Service Opt 2/9

Testing

Passed

Failed

Max Frames

FER

0.00

Errors Counted

0

Frames Counted

467

FER

%

Meas Cntl

Single / Cont

Max Frames

10000

Confidence

95.00

FER Spec

0.50

Display Interim Results

Yes / No

Traffic Data Mode

Svc Opt 2

Data Rate

Full

Eb / Nt

Sctr A Pwr

-80.0

Traffic

-80.0

AWGN

Off

To Screen

CDMA

CALL CNTL

ANALOG

RX TEST

Config

PRNT CNFG

To make an FER Measurement:

- ? Enter the Maximum number of frames to Test: **10,000**
- ? Enter the Confidence: **95%**
- ? Enter the Target FER Specification: **0.5%**
- ? Enable the display of interim results: **Yes**

Arm the Measurement

- ? Place the cursor at the “**Cont**” field under Meas Cntl
- ? Push the Knob

Now that you have a service option 002 call connected, you are ready to make parametric receiver and transmitter measurements. To perform receiver measurements:

- Go to the RX Test screen
- Notice that the RX Test screen also has call status indicators that show if the call is still connected and if the call is a service option 002 call.
- The parameter used to evaluate CDMA receiver quality is frame-error-rate. To setup a FER measurement with the HP 8924C, you need to enter three parameters: Max Frames, Confidence, and FER Spec.
- Enter 10,000 into the Max frames field. This sets an upper bound to the time limit of the test.


5.Enter 95% into the Confidence field. This field sets the desired confidence limit for the test. If confidence limit testing is not desired, you can turn this field off. In that case, the FER test will run until the number of frames tested reaches the value entered into the Max Frames field.

6.Enter 0.5% into the FER spec field. This field sets the desired FER specification to test to.

7.Make sure that the Display Interim Results field is set to yes.

8.Use the knob to place the cursor in front of the Arm field. Press the knob to start the measurement.

Receiver Test Termination



CDMA There are 3 possible outcomes to an FER Test:

- ? **Passed:** this means that the measured FER meets the target FER specification with the specified confidence.
- ? **Failed:** this means that the measured FER does not meet the target FER specification with the specified confidence.
- ? **Max Frames:** this means that the test was indeterminate in that the measured FER could neither pass nor fail the target FER specification with the specified confidence in the number of frames specified.


There are three possible outcomes for a confidence interval receiver frame-error-rate test with the HP 8924C:

1. When the HP 8924C determines that the measured FER will meet the user specified FER specification with the specified confidence level the test is halted and the Passed indicator is activated.

2. The HP 8924C extends the TIA recommendation to also check for failures with the user specified confidence level. In other words, if the HP 8924C detects that the measured FER will fail the user entered FER specification with the specified confidence level, the test is halted and the Failed indicator is activated. This feature eliminates wasted time testing phones that are clearly failing the test.

3. If neither the pass or fail conditions are met, the FER test will run until the number of frames counted equals the value entered into the Max Frames field. When this occurs, the Max Frames indicator is activated. If the confidence interval is turned off, the HP 8924C does not perform any confidence level checking and the FER test will run until the number of frames tested equals Max Frames.

CDMA Transmitter Tests



To make Concurrent RX and TX Measurements:

- ? Restart FER with Confidence Limits Off
- ? Go to the TX Test Screen
- ? Switch to Continuous Measurements

Read Average Power

- ? Check Max Power
- ? Check Open Loop Power Control

Read Rho Measurements

- ? Waveform Quality
- ? Frequency Error
- ? Amplitude & Phase Error

Simultaneous and transmitter tests is another feature of the HP 8924C. Simultaneous measurements results in much reduced test time. To make simultaneous receiver sensitivity and transmitter measurements:

- 1.Go to the TX test screen. (Press TX Test under the CDMA screens area.)
- 2.Make sure that the Meas Cntl is in Continuous mode. The HP 8924C will now make TX measurements.
- 3.Now select several measurement field and change the measurement types. Note: TM Rho(Test Mode Rho) only works with phones that have Test Mode functionality.

Now switch back to the RX Test screen. Notice that the FER test continued to run while you were making TX measurements.

CDMA Transmitter Power Range Test

CDMA CELLULAR MOBILE RECEIVER TEST

Max Power

24.24

dBm

Min Power

-55.36

dBm

Avg Power

2.61

dBm

Ideal Mobile Power:

2.6

dBm

Meas Cntl

Execute

Closed Loop Pwr cntl

Closed Loop Change

always down

Step

50

Execute

Drop timer

On / Off

Traffic Data Mode

Svc Opt 2

Data Rate

Full

Power Meas

Zero

Sctr A Pwr

-80.0

dBm / BW

Traffic

-16.6

dB

Attn Hold

On / Off

To Screen

CDMA

CALL CNTL

Analog

RX TEST

Config

PRNT CNFG

The ability to do min/max power measurements just by selecting Execute is another advanced feature of the HP 8924C. In this screen you can also control and test each power step while comparing Ideal Mobile Power to actual Avg Power measurements.

Select Execute

1.Go to the CDMA Transmitter Power Range Test screen (press the blue Shift key and then the Range key).

2.Now execute the min/max power measure- ment (use the knob and select execute under the min/max power field).

You will also notice in this screen you can select closed-loop power control to manu- ally control power settings of the phone. Note: If "always down" is selected, the phone will step its power down until the call is lost. If power control is changed, be sure to return it to "closed-loop" before proceeding onto the next test.

FER with AWGN Tests

CDMA CELLULAR MOBILE RECEIVER TEST

Test Status

Connected

Service Opt 2/9

Testing

Passed

Failed

Max Frames

FER

0.00

Errors Counted

0

Frames Counted

467

Meas Cntl

Single / Cont

Max Frames

10000

Confidence

95.00

FER Spec

0.50

Display Interim Results

Yes / No

Traffic Data Mode

Svc Opt 2

Data Rate

Full

Eb / Nt

Sctr A Pwr

-80.0

Traffic

-15.6

AWGN

-74

To Screen

CDMA

CALL CNTL

Analog

RX TEST

Config

PRNT CNFG

To make a CDMA FER with AWGN measurement:

- ? Use the same setup as for the receiver sensitivity test
- ? Set Sector A Power to -75 dBm/1.23 MHz
- ? Set AWGN Power to -74 dBm/1.23 MHz

Arm the Measurement

- ? Place the cursor at the “Cont” field under Meas Cntl
- ? Push the knob

The other key receiver measurement for CDMA phones is the FER with AWGN test. In this test, large amounts of uncorrelated noise is added to simulate the actual conditions encountered by a CDMA phone in actual use. To make this measurement:

- 1.Set the Sector A Power to -55 dBm/1.23 MHz.
- 2.Set the AWGN source to -54 dBm/1,23 MHz (this means that the traffic channel is 16.6 dB below the noise level!).
- 3.Arm the measurement by selecting Contin- uous in the Meas Cntl field.
- 4.Under these conditions, a CDMA phone should meet 0.5% FER with 95% confidence. Standards specify other tests for other rates. These can be performed by changing the Data Rate and Traffic level to the specified settings.

Nam Programming

| UI Operation | Procedure |
|---|--|
| Enter the Programming Menu | <p>1.MENU 0 S E T U P *</p> <p>2.Enter the default code security code “000000”, then [ok]</p> <p>Note: If you have trouble opening the Programming Menu in step 1, try the following: after pressing MENU, immediately follow it with 0 when the display changes.</p> |
| Program the phone number | <p>1. Enter Programming Menu (see 1)</p> <p>2. Select “User Activation” or “Extended NAM”</p> <p>3. Select the appropriate NAM then press [CHANGE]</p> <p>4. Highlight “MIN” and press [CHANGE]</p> <p>5. Edit the number then press [OK]</p> <p>6. If “MDN” is needed (Korea only?) then highlight “MDN” and repeat step 7.</p> |
| Program the CDMA primary/secondary channels (for both system A & B) | <p>1. Enter Programming Menu (see 1)</p> <p>2. Select “Extended NAM”</p> <p>3. Select the appropriate NAM then press [CHANGE]</p> <p>4. Select “1st Channel A” then press [CHANGE]</p> <p>5. Edit the number, then [OK]</p> <p>6. Repeat steps 5 to 6 for other channels</p> |
| Program the Analog primary/secondary channels (for both system A & B) | |
| Program the Home Syntem ID | <p>1. Enter Programming Menu (see 1)</p> <p>2. Select “User Activation” or “Extended NAM”</p> <p>3. Select the appropriate NAM then press [CHANGE]</p> <p>4. Select “CDMA Sys ID” then press [CHANGE]</p> <p>5. Edit the number, then [OK]</p> |

| | |
|---|--|
| Read ESN | <ol style="list-style-type: none"> 1. Press MENU 2. Select "Settings" 3. Select "Phone Status" 4. Select "Other Information" 5. Select "ESN" |
| Read software version | <ol style="list-style-type: none"> 1. Press MENU 2. Select "Settings" 3. Select "Phone Status" 4. Select "Other Information" 5. Select S/W Version |
| Set DTMF long/short mode | <ol style="list-style-type: none"> 1. Press MENU 2. Select "Settings" 3. Select "Other Settings" 4. Select "Initial Setup" 5. Select "DTMF" then press [CHANGE] 6. Select the appropriate DTMF setting |
| "Set call processing mode (Analog Only, ...)" | <ol style="list-style-type: none"> 1. Press MENU 2. Select "Settings" 3. Select "Other Settings" 4. Select "Initial Setup" 5. Select "Network" 6. Select "Analog Only" then press [CHANGE] 7. Select the appropriate mode |
| Force preferred vocoder mode (8k, 13K, EVRC) | <ol style="list-style-type: none"> 1. Enter Programming Menu (see 1) 2. Select "Vocode" then press [CHANGE] 3. Select the appropriate setting |

| | |
|---|---|
| Enable/disable voice privacy | Engine always request “voice privacy”. If the call has “voice privacy”, the display will show the icon. |
| Change station class mark (enable/disable slotted mode) | |
| Change slot cycle index | |
| "Change call termination enabled indicator: MOB_TERM (MOB_TERM_FOR_NID, MOB_TERM_FOR_SID, MOB_TERM_HOME, and HOME_REG, FOR_NID_REG, FOR_SID_REG)" | |
| "Change service option (analog, 8/13k voice, 8/13k Markov, 8/13k loopback, ...)" | |
| Disable/enable NAMPS | See procedure 8 for “analog only” option. |
| Program the A key | <ol style="list-style-type: none"> 1. Enter Programming Menu (see 1) 2. Select “AKEY” then press [CHANGE] |
| "Originate, answer, and release a call" | <p>Originate a Call</p> <ol style="list-style-type: none"> 1. Enter the phone number from IDLE 2. Press “SEND” <p>Answer a Call</p> <ol style="list-style-type: none"> 1. Press RIGHT soft key [ANSWER] on the New Call dialog. <p>Or</p> <ol style="list-style-type: none"> 1. 1. Open the phone flip, if “Answer options”/”Open To Answer” is set to “yes” 2. Close the ohone flip |


| | |
|--|---|
| Read and delete Caller ID messages | <p>Accessing "Recent Calls"</p> <ol style="list-style-type: none"> 1. MENU 2. Recent Calls 3. Received Calls or Dialed Calls 4. RIGHT soft key [SELECT] <p>Read Caller ID</p> <ol style="list-style-type: none"> 1. Scroll to a message to delete 2. RIGHT soft key [VIEW] <p>Delete Caller ID</p> <ol style="list-style-type: none"> 1. Scroll to a message to delete 2. MENU 3. Delete 4. RIGHT soft key [SELECT] <p>Or</p> <ol style="list-style-type: none"> 1. Scroll to a message to delete 2. RIGHT soft key [VIEW] 3. MENU 4. Delete" 5. RIGHT soft key [SELECT] |
| Originate call with call forwarding activation/deactivation code | |
| Originate call with call forwarding no answer (CFNA) code | |
| Originate call with call forwarding busy (CFB) code | |
| Originate call with call forwarding busy (CFB) code | |



MOTOROLA
Cellular Subscriber Sector

Replacement Parts

V.60c



Mechanical Parts List

| | | |
|----|------------|------------------------------|
| 1 | 0187985K01 | ASSY PHOENIX FLIP |
| 2 | 1587623K06 | HOUSING, XCVR FRONT |
| 3 | 3887961K01 | KEYPAD HARDTOP |
| 4 | SYN8347F | KEYPAD BRD PHOENIX |
| 5 | 2687960K03 | SHIELD SPACER GASKET PHOENIX |
| 6 | SLG4215B | CDMA PHOENIX PORTABLE KIT |
| 7 | 0387791L01 | SCREW, BUTTON HEAD XCVR |
| 8 | 1588600L01 | REAR HOUSING |
| 9 | SNN5704A | BATTERY |
| 10 | SYN8359A | BATTERY DOOR PHOENIX 7.5 |
| 11 | 8589650K15 | ANT TELESCOPING PHOENIX |
| 12 | 3887988K03 | BUTTON, VOLUME/SMART - GREY |
| 13 | 0387790L01 | SCREW, BUTTON HEAD KNUCKLE |
| 14 | 3887987K03 | BUTTON, VOICE-IT - GREY |

Electrical Parts List

| Reference Des | Part # | Description |
|---------------|------------|--------------------------------|
| A500 | 3989006K03 | CONT ANT PHOENIX |
| A501 | 0987796L01 | RF SWITCH CONNECTOR |
| C100 | 2113743N28 | CAP CHIP 12.0 PF 5% COG |
| C1000 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1001 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1002 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1005 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1006 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1007 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1008 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1009 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1010 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1011 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1012 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1013 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1014 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1015 | 2113743E20 | CAP CHIP .10 UF 10% |
| C1016 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1017 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C102 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1020 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1021 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1022 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1023 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C103 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C104 | 2113743N15 | CAP CHIP 3.6 PF +- .25PF COG |
| C1051 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1052 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C106 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C107 | 2113743N24 | CAP CHIP 8.2 PF + -.5PF COG |
| C108 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C109 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C110 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1100 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1101 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1102 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1103 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1104 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C1105 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C1106 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C1107 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1108 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1109 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C1111 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C1112 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C1113 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C1114 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C1115 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |

| | | |
|-------|------------|--------------------------------|
| C1116 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C1118 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C1119 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C112 | 2113743N20 | CAP CHIP 5.6 PF + -.5PF COG |
| C1120 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C1121 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1122 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C1123 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1124 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1126 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1127 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1128 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1129 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C113 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C114 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C115 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C1150 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1151 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1152 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C116 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C1171 | 2113743N36 | CAP CHIP 27.0 PF 5% COG |
| C1172 | 2113743N26 | CAP CHIP 10.0 PF 5% COG |
| C1173 | 2113743N46 | CAP CHIP 68.0 PF 5% COG |
| C118 | 2113743N03 | CAP CHIP 1.0 PF +-.25PF COG |
| C119 | 2113743N28 | CAP CHIP 12.0 PF 5% COG |
| C120 | 2113743N07 | CAP CHIP 1.5 PF +-.25PF COG |
| C1200 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1201 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1202 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1203 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1204 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1205 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1206 | 2113928C03 | CAP CER CHIP 1.0 UF 6.3V 10% |
| C1207 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1208 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1209 | 2113743N50 | CAP CHIP 100 PF 5% COG |
| C121 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C1210 | 2113743N50 | CAP CHIP 100 PF 5% COG |
| C1211 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1212 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1213 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1214 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1215 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1216 | 2113743L19 | CAP CHIP 1200 PF 10% X7R |
| C1217 | 2113743L03 | CAP CHIP 270 PF 10% X7R |
| C1218 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1219 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C122 | 2113743N12 | CAP CHIP 2.7 PF +-.25PF COG |
| C1220 | 2113743L25 | CAP CHIP 2200 PF 10% X7R |
| C1221 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1222 | 2113743N50 | CAP CHIP 100 PF 5% COG |
| C1223 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |

| | | |
|-------|------------|--------------------------------|
| C1224 | 2113743E20 | CAP CHIP .10 UF 10% |
| C1226 | 2113743L13 | CAP CHIP 680 PF 10% X7R |
| C1227 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1228 | 2113743L07 | CAP CHIP 390 PF 10% X7R |
| C1229 | 2113743E11 | CAP CHIP .039 UF 10% X7R |
| C123 | 2113743N22 | CAP CHIP 6.8 PF + -.5PF COG |
| C1230 | 2113743N50 | CAP CHIP 100 PF 5% COG |
| C1231 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1232 | 2113743E07 | CER CHIP CAP .022UF |
| C1233 | 2113743E07 | CER CHIP CAP .022UF |
| C1234 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1235 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1236 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C1237 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1238 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1239 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1240 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1241 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1242 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1243 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C1245 | 2113928P04 | CAP CER CHIP 1.0UF 20% 6.3V |
| C1247 | 2113928P04 | CAP CER CHIP 1.0UF 20% 6.3V |
| C125 | 2113743N07 | CAP CHIP 1.5 PF +-.25PF COG |
| C1251 | 2113743L13 | CAP CHIP 680 PF 10% X7R |
| C1252 | 2113743L17 | CAP CHIP 1000 PF 10% X7R |
| C1253 | 2113743L25 | CAP CHIP 2200 PF 10% X7R |
| C1255 | 2113928P04 | CAP CER CHIP 1.0UF 20% 6.3V |
| C1261 | 2113743L25 | CAP CHIP 2200 PF 10% X7R |
| C1262 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1263 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1264 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1265 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1266 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1267 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1268 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1270 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1287 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1288 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1289 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1290 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1293 | 2113743L25 | CAP CHIP 2200 PF 10% X7R |
| C1298 | 2113928P04 | CAP CER CHIP 1.0UF 20% 6.3V |
| C1299 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1300 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C1301 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C1302 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1303 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C1304 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| C1305 | 2113743E20 | CAP CHIP .10 UF 10% |
| C1306 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C150 | 2113743N20 | CAP CHIP 5.6 PF + -.5PF COG |
| C151 | 2113743N46 | CAP CHIP 68.0 PF 5% COG |

| | | |
|-------|------------|-----------------------------|
| C152 | 2113743N46 | CAP CHIP 68.0 PF 5% COG |
| C153 | 2113743N24 | CAP CHIP 8.2 PF + -.5PF COG |
| C154 | 2113743N15 | CAP CHIP 3.6 PF +-.25PF COG |
| C155 | 2113743L17 | CAP CHIP 1000 PF 10% X7R |
| C156 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C157 | 2113743N41 | CAP CHIP 43.0 PF 5% COG |
| C158 | 2113743N18 | CAP CHIP 4.7 PF +-.25PF COG |
| C159 | 2113743N18 | CAP CHIP 4.7 PF +-.25PF COG |
| C160 | 2113743L17 | CAP CHIP 1000 PF 10% X7R |
| C161 | 2113743N39 | CAP CHIP 36.0 PF 5% COG |
| C162 | 2113743N27 | CAP CHIP 11.0 PF 5% COG |
| C163 | 2113743N08 | CAP CHIP 1.6 PF +-.25PF COG |
| C164 | 2113743N26 | CAP CHIP 10.0 PF 5% COG |
| C1701 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C1702 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C300 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C3001 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C3002 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C3003 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C3004 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C3005 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C3006 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C3007 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C3008 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C3009 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C301 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C3010 | 2113743L33 | CAP CHIP 4700 PF 10% X7R |
| C3011 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C3012 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C3013 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C3014 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C3015 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C3016 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C3017 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C302 | 2113743N42 | CAP CHIP 47.0 PF 5% COG |
| C303 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C304 | 2113743N27 | CAP CHIP 11.0 PF 5% COG |
| C305 | 2113743N14 | CAP CHIP 3.3 PF +-.25PF COG |
| C325 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C326 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C327 | 2113743N46 | CAP CHIP 68.0 PF 5% COG |
| C328 | 2113743L25 | CAP CHIP 2200 PF 10% X7R |
| C329 | 2113743L17 | CAP CHIP 1000 PF 10% X7R |
| C330 | 2113743N46 | CAP CHIP 68.0 PF 5% COG |
| C400 | 2113743N26 | CAP CHIP 10.0 PF 5% COG |
| C401 | 2113743N26 | CAP CHIP 10.0 PF 5% COG |
| C402 | 2113743N19 | CAP CHIP 5.1 PF + -.5PF COG |
| C403 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C404 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C405 | 2113743N28 | CAP CHIP 12.0 PF 5% COG |
| C406 | 2113743N26 | CAP CHIP 10.0 PF 5% COG |
| C408 | 2113743N07 | CAP CHIP 1.5 PF +-.25PF COG |

| | | |
|-------|------------|--------------------------------|
| C409 | 2113743N09 | CAP CHIP 2.0 PF +-.25PF COG |
| C410 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C411 | 2113743N19 | CAP CHIP 5.1 PF + -.5PF COG |
| C413 | 2113743N26 | CAP CHIP 10.0 PF 5% COG |
| C414 | 2113743N16 | CAP CHIP 3.9 PF +-.25PF COG |
| C415 | 2113743N26 | CAP CHIP 10.0 PF 5% COG |
| C416 | 2113743N10 | CAP CHIP 2.2 PF +-.25PF COG |
| C417 | 2113743N07 | CAP CHIP 1.5 PF +-.25PF COG |
| C418 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C419 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C420 | 2113743N26 | CAP CHIP 10.0 PF 5% COG |
| C421 | 2113743N26 | CAP CHIP 10.0 PF 5% COG |
| C422 | 2113743N26 | CAP CHIP 10.0 PF 5% COG |
| C423 | 2113743N26 | CAP CHIP 10.0 PF 5% COG |
| C424 | 2113743N26 | CAP CHIP 10.0 PF 5% COG |
| C425 | 2113743N26 | CAP CHIP 10.0 PF 5% COG |
| C426 | 2113743N03 | CAP CHIP 1.0 PF +-.25PF COG |
| C428 | 2113743N50 | CAP CHIP 100 PF 5% COG |
| C429 | 2113743N12 | CAP CHIP 2.7 PF +-.25PF COG |
| C430 | 2113743N26 | CAP CHIP 10.0 PF 5% COG |
| C431 | 2113743N26 | CAP CHIP 10.0 PF 5% COG |
| C432 | 2113743N34 | CAP CHIP 22.0 PF 5% COG |
| C433 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C434 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C435 | 2113743N26 | CAP CHIP 10.0 PF 5% COG |
| C439 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C441 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C442 | 2113743N38 | CAP CHIP 33.0 PF 5% COG |
| C443 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C446 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C5001 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C5002 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C51 | 2113740L01 | CAP CER CHIP 2.0 PF +-0.1PF |
| C521 | 2113743N16 | CAP CHIP 3.9 PF +-.25PF COG |
| C522 | 2113743N26 | CAP CHIP 10.0 PF 5% COG |
| C523 | 2113743M24 | CAP CHIP 100000 PF +80-20% Y5V |
| C524 | 2113743N30 | CAP CHIP 15.0 PF 5% COG |
| C525 | 2113743N23 | CAP CHIP 7.5 PF + -.5PF COG |
| C526 | 2113743N26 | CAP CHIP 10.0 PF 5% COG |
| C527 | 2113928A01 | CAP CER CHIP 1.0 UF 10V |
| C528 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C529 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C531 | 2113743N26 | CAP CHIP 10.0 PF 5% COG |
| C532 | 2113743N03 | CAP CHIP 1.0 PF +-.25PF COG |
| C533 | 2113743N30 | CAP CHIP 15.0 PF 5% COG |
| C536 | 2113743N17 | CAP CHIP 4.3 PF +-.25PF COG |
| C537 | 2113743N12 | CAP CHIP 2.7 PF +-.25PF COG |
| C538 | 2113743N30 | CAP CHIP 15.0 PF 5% COG |
| C550 | 2113743M24 | CAP CHIP 100000 PF +80-20% Y5V |
| C551 | 2113743N07 | CAP CHIP 1.5 PF +-.25PF COG |
| C552 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C553 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |

| | | |
|------|------------|--------------------------------|
| C555 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C570 | 2109445U20 | CAP CER COG 5.1 .1% 0402 SMD |
| C571 | 2109445U24 | CAP CER COG 7.5 .1% 0402 SMD |
| C580 | 2113743N42 | CAP CHIP 47.0 PF 5% COG |
| C581 | 2113743N18 | CAP CHIP 4.7 PF +-.25PF COG |
| C585 | 2113743N42 | CAP CHIP 47.0 PF 5% COG |
| C587 | 2109445U25 | CAP CER COG 8.2 .1% 0402 SMD |
| C589 | 2113743N42 | CAP CHIP 47.0 PF 5% COG |
| C59 | 2113740F22 | CAP CHIP REEL CL1 +/-30 6.2 |
| C591 | 2113743M24 | CAP CHIP 100000 PF +80-20% Y5V |
| C592 | 2113928C03 | CAP CER CHIP 1.0 UF 6.3V 10% |
| C594 | 2113743N42 | CAP CHIP 47.0 PF 5% COG |
| C595 | 2113743N12 | CAP CHIP 2.7 PF +-.25PF COG |
| C596 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C598 | 2113928A01 | CAP CER CHIP 1.0 UF 10V |
| C599 | 2113743N50 | CAP CHIP 100 PF 5% COG |
| C600 | 2113928C03 | CAP CER CHIP 1.0 UF 6.3V 10% |
| C601 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C602 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C625 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C628 | 2104801Z04 | CAP CER NPO 0.8PF 16V 1005 SMD |
| C629 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C635 | 2113743N28 | CAP CHIP 12.0 PF 5% COG |
| C636 | 2104801Z01 | CAP CER NPO 0.5PF 16V 1005 SMD |
| C637 | 2113743N28 | CAP CHIP 12.0 PF 5% COG |
| C638 | 2113743N19 | CAP CHIP 5.1 PF + -.5PF COG |
| C640 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C642 | 2113743G26 | CAP CHIP 4.7 UF 16V +80-20% |
| C650 | 2113743N16 | CAP CHIP 3.9 PF +-.25PF COG |
| C651 | 2113743N24 | CAP CHIP 8.2 PF + -.5PF COG |
| C652 | 2113743N32 | CAP CHIP 18.0 PF 5% COG |
| C653 | 2113743N28 | CAP CHIP 12.0 PF 5% COG |
| C654 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C655 | 2113928C03 | CAP CER CHIP 1.0 UF 6.3V 10% |
| C656 | 2104801Z06 | CAP CER NPO 1.0PF 16V 1005 SMD |
| C657 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C658 | 2113928A01 | CAP CER CHIP 1.0 UF 10V |
| C659 | 2113743N50 | CAP CHIP 100 PF 5% COG |
| C660 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C700 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C701 | 2113743L11 | CAP CHIP 560 PF 10% X7R |
| C702 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C703 | 2113743G26 | CAP CHIP 4.7 UF 16V +80-20% |
| C704 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C725 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C728 | 2113928P04 | CAP CER CHIP 1.0UF 20% 6.3V |
| C729 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C731 | 2113743L03 | CAP CHIP 270 PF 10% X7R |
| C750 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C751 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C752 | 2113743L41 | CAP CHIP 10000 PF 10% X7R |
| C753 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |

| | | |
|--------|------------|--------------------------------|
| C754 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C756 | 2113743N46 | CAP CHIP 68.0 PF 5% COG |
| C775 | 2113928G01 | CAP CER CHIP .22 UF 6.3V 10% |
| C776 | 2113743L25 | CAP CHIP 2200 PF 10% X7R |
| C777 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C778 | 2113928P04 | CAP CER CHIP 1.0UF 20% 6.3V |
| C779 | 2113928P04 | CAP CER CHIP 1.0UF 20% 6.3V |
| C780 | 2113928P04 | CAP CER CHIP 1.0UF 20% 6.3V |
| C781 | 2113928P04 | CAP CER CHIP 1.0UF 20% 6.3V |
| C782 | 2113928N01 | CAP CER CHIP 0.1UF 10% 6.3 |
| C783 | 2113928C03 | CAP CER CHIP 1.0 UF 6.3V 10% |
| C870 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C871 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C872 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C873 | 2113743N40 | CAP CHIP 39.0 PF 5% COG |
| C9996 | 2113928C04 | CAP CER CHIP 4.7UF 6.3V10%0805 |
| CPL500 | 5885811G04 | ISLTR CER MLTLYR 1800MHZ 2016 |
| CPL625 | 5803703S01 | COUPLER CER 4 PORT 991MHZ SMD |
| CPL635 | 5804632Z01 | CPLR CER 4 POST 7020MHZ 2012 |
| CR1050 | 4809653F02 | RECT SCHOTTKY 1.0A UPS5817 |
| CR1051 | 4809653F02 | RECT SCHOTTKY 1.0A UPS5817 |
| CR1101 | 4808612Y01 | DIODE SCHOTTKY RB751V-40 |
| CR1102 | 4809606E07 | DIODE DUAL ARRAY DA221 |
| CR1150 | 4809118D02 | LED BICOLOR LNJ115W8POMT |
| CR1200 | 4809606E07 | DIODE DUAL ARRAY DA221 |
| CR1211 | 4809924D18 | DIODE HIGH VOLTAGE/SW RB520S |
| CR1301 | 4809924D18 | DIODE HIGH VOLTAGE/SW RB520S |
| CR1750 | 4809606E02 | DIODE DUAL ARRAY DAN222 |
| CR300 | 4809877C08 | DIODE VARACTOR 1SV279 SMD |
| CR330 | 4809877C08 | DIODE VARACTOR 1SV279 SMD |
| CR550 | 4809606E05 | DIODE DUAL SCHOTTKY SOT-143 |
| CR580 | 4809948D13 | DIODE RF SWITCH BA892 ESC |
| CR650 | 4809877C13 | DIODE VARACTOR ISV305 SMD |
| CR651 | 4809877C08 | DIODE VARACTOR 1SV279 SMD |
| CR652 | 4809948D10 | DIODE PIN BAR63-03 |
| FL100 | 9103913K04 | FLTR SAW TX 818MHZ SMD |
| FL101 | 9109303U03 | FLTR CER LO 991MHZ 3225 SMD |
| FL103 | 9109239M08 | FLTR SAW BP 1960MHZ 3X3MM SMD |
| FL150 | 9109405J08 | FLTR SAW IF 109MHZ 5.3X11.4MM |
| FL160 | 9185838J01 | FLTR XTAL 109.65MHZ 3.8MM SMD |
| FL401 | 9185726J03 | FLTR SAW SPLT TXINT 3MM 1.9GHZ |
| FL403 | 9109247M03 | FLTR SAW BP 836MHZ 3X3MM SMD |
| FL404 | 9103913K03 | FLTR SAW TX 836MHZ SMD |
| FL409 | 9109239M04 | FLTR SAW TX BP 1880MHZ SMD |
| FL50 | 9185911J09 | FLTR CER DP 1880/1960 7X23MM |
| FL51 | 9109361K03 | FLTR SAW DUPLEX 850MHZ SMD |
| FL53 | 9185906G08 | FLTR CER DIPLEX 859\1920 3216 |
| J1000 | 0987636K03 | "I/O CONNECTOR, 17 PINS" |
| J2000 | 0987816K03 | CONN COMPRESSION 1.6MM STACK |
| J3000 | 0987817K01 | RECP BTB 0.5P 1.5 STACK SMD |
| J4 | 5987947K02 | MOTOR VIB 5DIAM SMD |
| J5000 | 0985622G01 | SKT TOP ENTRY 2 POS |

| | | |
|-------|------------|--------------------------------|
| J600 | 0987850K04 | CONNECTOR JACK SMD NEW CONTACT |
| J870 | 3987522K03 | CONT BLOCK BATT |
| L101 | 2409154M61 | IND CER MTLILYR 6.8 NH 1005 |
| L102 | 2409154M62 | IND CER MTLILYR 8.2 NH 1005 |
| L112 | 2409154M29 | IND CER MLTILYR 2.7NH 1005 |
| L114 | 2409154M66 | IND CER MTLILYR 18.0NH 1005 |
| L115 | 2409154M33 | IND CER MLTILYR 5.6NH 1005 |
| L116 | 2409154M43 | IND CER MTLILYR 39.0NH 1005 |
| L1232 | 2589584K11 | IND WW SHLD 47UH 20% 5X5MM |
| L150 | 2404574Z09 | IND CHIP WW 100NH 2% 2012 SMD |
| L151 | 2404574Z09 | IND CHIP WW 100NH 2% 2012 SMD |
| L152 | 2404574Z13 | IND CHIP WW 220NH 2% 2012 SMD |
| L153 | 2409377M16 | IND CHIP WW 82 NH 5% 1608 |
| L154 | 2409377M13 | IND CHIP WW 56 NH 5% 1608 |
| L160 | 2404574Z12 | IND CHIP WW 180NH 2% 2012 SMD |
| L162 | 2404574Z13 | IND CHIP WW 220NH 2% 2012 SMD |
| L300 | 2413926K16 | IND CER CHIP 27.0 NH 5% |
| L400 | 2404574Z13 | IND CHIP WW 220NH 2% 2012 SMD |
| L401 | 2404574Z13 | IND CHIP WW 220NH 2% 2012 SMD |
| L402 | 2409154M31 | IND CER MLTILYR 3.9NH 1005 |
| L404 | 2409154M35 | IND CER MLTILYR 8.2NH 1005 |
| L407 | 2409154M71 | IND CER MLTILYR 47.0NH 1005 |
| L408 | 2409154M65 | IND CER MTLILYR 15.0NH 1005 |
| L409 | 2409154M59 | IND CER MTLILYR 4.7 NH 1005 |
| L410 | 2409154M31 | IND CER MLTILYR 3.9NH 1005 |
| L411 | 2409154M38 | IND CER MLTILYR 15.0NH 1005 |
| L412 | 2409154M32 | IND CER MLTILYR 4.7NH 1005 |
| L415 | 2409154M33 | IND CER MLTILYR 5.6NH 1005 |
| L417 | 2409154M57 | IND CER MTLILYR 3.3 NH 1005 |
| L418 | 2409154M34 | IND CER MLTILYR 6.8NH 1005 |
| L419 | 2409154M40 | IND CER MLTILYR 22.0NH 1005 |
| L421 | 2409154M53 | IND CER MTLILYR 1.5 NH 1005 |
| L50 | 2409377M02 | IND CHIP WW 3.9 NH 5% 1608 |
| L51 | 2409377M08 | IND CHIP WW 22 NH 5% 1608 |
| L520 | 2409154M61 | IND CER MTLILYR 6.8 NH 1005 |
| L521 | 2409646M78 | IN CER MULTILYR 5.6NH 1608 |
| L522 | 2409154M09 | IND CER MLTILYR 4.7NH 1005 |
| L523 | 2409594M12 | IND CHIP 18.0NH 5% ACCU-L |
| L524 | 2409154M58 | IND CER MTLILYR 3.9 NH 1005 |
| L55 | 2409154M27 | IND CER MLTILYR 1.8NH 1005 |
| L580 | 2409154M09 | IND CER MLTILYR 4.7NH 1005 |
| L581 | 2409646M27 | IND CER MULTILYR 4.7NH 1608 |
| L582 | 2409414M09 | IND CHIP WW 18 NH 5 % 2012 |
| L625 | 2409154M65 | IND CER MTLILYR 15.0NH 1005 |
| L626 | 2409154M62 | IND CER MTLILYR 8.2 NH 1005 |
| L635 | 2409154M58 | IND CER MTLILYR 3.9 NH 1005 |
| L636 | 2409646M98 | IN CER MULTILYR |
| L650 | 2409414M09 | IND CHIP WW 18 NH 5 % 2012 |
| L651 | 2409414M14 | IND CHIP WW 47 NH 5 % 2012 |
| L652 | 2413926D28 | IND CER CHIP 270.0 NH 10% |
| LS1 | 5087951K01 | ALERT 2.5V 8.5X10.4MM SMD REFL |
| Q1050 | 4809579E29 | TSTR FET P-CHAN SI3443DV 6TSOP |

| | | |
|-------|------------|--------------------------------|
| Q1204 | 4809579E29 | TSTR FET P-CHAN SI3443DV 6TSOP |
| Q1205 | 4809579E29 | TSTR FET P-CHAN SI3443DV 6TSOP |
| Q1305 | 4809579E29 | TSTR FET P-CHAN SI3443DV 6TSOP |
| Q1306 | 4809579E29 | TSTR FET P-CHAN SI3443DV 6TSOP |
| Q1307 | 4809939C03 | TSTR DUAL NPN/PNP UMH3 |
| Q325 | 4809579E24 | TSTR FET P-CHAN 2SJ347 SC90 |
| Q580 | 4809939C03 | TSTR DUAL NPN/PNP UMH3 |
| Q581 | 4809579E50 | FET DUAL P CHAN SI1905DL SC70 |
| Q635 | 4809939C03 | TSTR DUAL NPN/PNP UMH3 |
| Q636 | 4809579E50 | FET DUAL P CHAN SI1905DL SC70 |
| Q650 | 4809579E02 | TSTR MOSFET N-CHAN 25K1830 |
| R100 | 0662057N02 | RES. CHIP 13K 5% 20X40 |
| R1000 | 0662057N09 | RES. CHIP 27K 5% 20X40 |
| R1001 | 0662057M81 | RES. CHIP 2000 5% 20X40 |
| R1002 | 0662057M26 | RES. CHIP 10 5% 20X40 |
| R1003 | 0662057M26 | RES. CHIP 10 5% 20X40 |
| R1004 | 0662057M26 | RES. CHIP 10 5% 20X40 |
| R1005 | 0662057M26 | RES. CHIP 10 5% 20X40 |
| R1006 | 0662057M26 | RES. CHIP 10 5% 20X40 |
| R1007 | 0662057M26 | RES. CHIP 10 5% 20X40 |
| R1008 | 0662057M26 | RES. CHIP 10 5% 20X40 |
| R1009 | 0662057N23 | RES. CHIP 100K 5% 20X40 |
| R101 | 0662057N06 | RES. CHIP 20K 5% 20X40 |
| R1011 | 0662057M01 | RES. CHIP 0 5% 20X40 |
| R1012 | 0662057N07 | RES. CHIP 22K 5% 20X40 |
| R1013 | 0662057N07 | RES. CHIP 22K 5% 20X40 |
| R1015 | 0662057V02 | RES CHIP 10K 1% 1/16W |
| R1018 | 0662057N33 | RES. CHIP 270K 5% 20X40 |
| R1019 | 0662057V19 | RES CHIP 47K 1% 1/16W |
| R103 | 0662057M26 | RES. CHIP 10 5% 20X40 |
| R104 | 0662057M26 | RES. CHIP 10 5% 20X40 |
| R1052 | 0609175L02 | RES CHIP 0.25 1% .25W 1206 |
| R1053 | 0662057N47 | RES. CHIP 1.0 MEG 5% 20X40 |
| R106 | 0662057M26 | RES. CHIP 10 5% 20X40 |
| R107 | 0662057M26 | RES. CHIP 10 5% 20X40 |
| R108 | 0662057M26 | RES. CHIP 10 5% 20X40 |
| R1102 | 0662057V17 | RES CHIP 39K 1% 1/16W |
| R1104 | 0662057V02 | RES CHIP 10K 1% 1/16W |
| R1108 | 0662057M98 | RES. CHIP 10K 5% 20X40 |
| R1113 | 0662057M50 | RES. CHIP 100 5% 20X40 |
| R1116 | 0662057V02 | RES CHIP 10K 1% 1/16W |
| R1121 | 0662057M01 | RES. CHIP 0 5% 20X40 |
| R1152 | 0662057M50 | RES. CHIP 100 5% 20X40 |
| R1153 | 0662057M64 | RES. CHIP 390 5% 20X40 |
| R1155 | 0662057M90 | RES. CHIP 4700 5% 20X40 |
| R1170 | 0662057N65 | CHIP RES 10 M 5% 20X40 |
| R1209 | 0662057M35 | RES. CHIP 24 5% 20X40 |
| R1210 | 0662057M35 | RES. CHIP 24 5% 20X40 |
| R1211 | 0662057M26 | RES. CHIP 10 5% 20X40 |
| R1212 | 0662057M26 | RES. CHIP 10 5% 20X40 |
| R1213 | 0662057M98 | RES. CHIP 10K 5% 20X40 |
| R1214 | 0662057M01 | RES. CHIP 0 5% 20X40 |

| | | |
|-------|------------|----------------------------|
| R1217 | 0662057M98 | RES. CHIP 10K 5% 20X40 |
| R1220 | 0662057N47 | RES. CHIP 1.0 MEG 5% 20X40 |
| R1227 | 0662057M95 | RES. CHIP 7500 5% 20X40 |
| R1228 | 0662057N12 | RES. CHIP 36K 5% 20X40 |
| R1229 | 0662057N27 | RES. CHIP 150K 5% 20X40 |
| R1230 | 0662057N12 | RES. CHIP 36K 5% 20X40 |
| R1232 | 0662057M74 | RES. CHIP 1000 5% 20X40 |
| R1233 | 0662057N07 | RES. CHIP 22K 5% 20X40 |
| R1234 | 0662057N09 | RES. CHIP 27K 5% 20X40 |
| R1235 | 0662057N09 | RES. CHIP 27K 5% 20X40 |
| R1236 | 0662057N23 | RES. CHIP 100K 5% 20X40 |
| R1237 | 0662057M98 | RES. CHIP 10K 5% 20X40 |
| R1238 | 0662057M68 | RES. CHIP 560 5% 20X40 |
| R1239 | 0662057N23 | RES. CHIP 100K 5% 20X40 |
| R1240 | 0662057M80 | RES. CHIP 1800 5% 20X40 |
| R1241 | 0662057M80 | RES. CHIP 1800 5% 20X40 |
| R1243 | 0662057M90 | RES. CHIP 4700 5% 20X40 |
| R1244 | 0662057V02 | RES CHIP 10K 1% 1/16W |
| R1248 | 0662057M82 | RES. CHIP 2200 5% 20X40 |
| R1249 | 0662057N07 | RES. CHIP 22K 5% 20X40 |
| R1250 | 0662057M42 | RES. CHIP 47 5% 20X40 |
| R1251 | 0662057M90 | RES. CHIP 4700 5% 20X40 |
| R1253 | 0662057M01 | RES. CHIP 0 5% 20X40 |
| R1256 | 0662057N31 | RES. CHIP 220K 5% 20X40 |
| R1257 | 0662057N03 | RES. CHIP 15K 5% 20X40 |
| R1258 | 0662057M01 | RES. CHIP 0 5% 20X40 |
| R1259 | 0662057U81 | RES CHIP 1.5K 1% 1/16W |
| R1260 | 0662057U89 | RES CHIP 3.3K 1% 1/16W |
| R1262 | 0662057M98 | RES. CHIP 10K 5% 20X40 |
| R1263 | 0662057M01 | RES. CHIP 0 5% 20X40 |
| R1267 | 0662057M90 | RES. CHIP 4700 5% 20X40 |
| R1268 | 0662057M92 | RES. CHIP 5600 5% 20X40 |
| R1269 | 0662057M90 | RES. CHIP 4700 5% 20X40 |
| R1275 | 0662057M78 | RES. CHIP 1500 5% 20X40 |
| R1307 | 0662057M90 | RES. CHIP 4700 5% 20X40 |
| R150 | 0662057M81 | RES. CHIP 2000 5% 20X40 |
| R160 | 0662057M95 | RES. CHIP 7500 5% 20X40 |
| R300 | 0662057M86 | RES. CHIP 3300 5% 20X40 |
| R3002 | 0662057M01 | RES. CHIP 0 5% 20X40 |
| R3003 | 0662057M01 | RES. CHIP 0 5% 20X40 |
| R3004 | 0662057M01 | RES. CHIP 0 5% 20X40 |
| R301 | 0662057M98 | RES. CHIP 10K 5% 20X40 |
| R325 | 0662057M74 | RES. CHIP 1000 5% 20X40 |
| R326 | 0662057M92 | RES. CHIP 5600 5% 20X40 |
| R327 | 0662057N10 | RES. CHIP 30K 5% 20X40 |
| R328 | 0662057N23 | RES. CHIP 100K 5% 20X40 |
| R330 | 0662057M76 | RES. CHIP 1200 5% 20X40 |
| R401 | 0662057M60 | RES. CHIP 270 5% 20X40 |
| R402 | 0662057M60 | RES. CHIP 270 5% 20X40 |
| R403 | 0662057M76 | RES. CHIP 1200 5% 20X40 |
| R409 | 0662057M50 | RES. CHIP 100 5% 20X40 |
| R410 | 0662057M67 | RES. CHIP 510 5% 20X40 |

| | | |
|---------|------------|--------------------------------|
| R411 | 0662057M26 | RES. CHIP 10 5% 20X40 |
| R412 | 0662057M67 | RES. CHIP 510 5% 20X40 |
| R418 | 0662057M26 | RES. CHIP 10 5% 20X40 |
| R423 | 0662057M67 | RES. CHIP 510 5% 20X40 |
| R424 | 0662057M67 | RES. CHIP 510 5% 20X40 |
| R520 | 0662057M76 | RES. CHIP 1200 5% 20X40 |
| R521 | 0662057M81 | RES. CHIP 2000 5% 20X40 |
| R522 | 0662057M62 | RES. CHIP 330 5% 20X40 |
| R523 | 0662057M83 | RES. CHIP 2400 5% 20X40 |
| R530 | 0662057M43 | RES. CHIP 51 5% 20X40 |
| R532 | 0662057M50 | RES. CHIP 100 5% 20X40 |
| R550 | 0662057M95 | RES. CHIP 7500 5% 20X40 |
| R551 | 0662057M91 | RES. CHIP 5100 5% 20X40 |
| R552 | 0662057M90 | RES. CHIP 4700 5% 20X40 |
| R554 | 0662057N11 | RES. CHIP 33K 5% 20X40 |
| R555 | 0662057M43 | RES. CHIP 51 5% 20X40 |
| R580 | 0660076N32 | RES CHIP 200 OHM 1/16 W |
| R581 | 0662057U83 | RES CHIP 1.8K 1% 1/16W |
| R582 | 0662057U90 | RES CHIP 3.6K 1% 1/16W |
| R584 | 0662057M71 | RES. CHIP 750 5% 20X40 |
| R600 | 0662057M46 | RES. CHIP 68 5% 20X40 |
| R601 | 0662057M74 | RES. CHIP 1000 5% 20X40 |
| R602 | 0662057M68 | RES. CHIP 560 5% 20X40 |
| R625 | 0662057M43 | RES. CHIP 51 5% 20X40 |
| R627 | 0662057M52 | RES. CHIP 120 5% 20X40 |
| R628 | 0662057M43 | RES. CHIP 51 5% 20X40 |
| R629 | 0662057M52 | RES. CHIP 120 5% 20X40 |
| R635 | 0662057M43 | RES. CHIP 51 5% 20X40 |
| R636 | 0662057M52 | RES. CHIP 120 5% 20X40 |
| R637 | 0662057M52 | RES. CHIP 120 5% 20X40 |
| R638 | 0662057M43 | RES. CHIP 51 5% 20X40 |
| R651 | 0662057M95 | RES. CHIP 7500 5% 20X40 |
| R652 | 0662057M77 | RES. CHIP 1300 5% 20X40 |
| R653 | 0662057N02 | RES. CHIP 13K 5% 20X40 |
| R654 | 0662057N09 | RES. CHIP 27K 5% 20X40 |
| R655 | 0662057M50 | RES. CHIP 100 5% 20X40 |
| R656 | 0662057M84 | RES. CHIP 2700 5% 20X40 |
| R701 | 0662057M46 | RES. CHIP 68 5% 20X40 |
| R750 | 0662057M50 | RES. CHIP 100 5% 20X40 |
| S_SMART | 4087635K01 | SWITCH 3 POLE LOW PROFILE |
| S_VA | 4087635K01 | SWITCH 3 POLE LOW PROFILE |
| S_VDN | 4087635K01 | SWITCH 3 POLE LOW PROFILE |
| S_VUP | 4087635K01 | SWITCH 3 POLE LOW PROFILE |
| SH1 | 2688029K05 | SHIELD FRONT END |
| SH2 | 2688030K07 | "SHIELD, VCO, CDMA PHOENIX" |
| SH3 | 2688031K07 | SHIELD ZFSIN CDMA PHOENIX |
| SH4 | 2688032K05 | SHIELD MEI |
| SH5 | 2688033K05 | SHIELD PA |
| SH7 | 2609827G10 | SHIELD INDUCTOR SURFACE MNT |
| SH8 | 2688473L02 | "SHIELD, FILTER, CDMA PHOENIX" |
| SHIELD3 | 2609827G10 | SHIELD INDUCTOR SURFACE MNT |
| SHIELD4 | 2609827G10 | SHIELD INDUCTOR SURFACE MNT |

| | | |
|---------|-------------|--------------------------------|
| SHIELD5 | 2609827G10 | SHIELD INDUCTOR SURFACE MNT |
| U100 | 5109940K40 | IC LNR MIXER 20 TSSOP1.3FEIC |
| U1000 | 5109817F45 | IC CURRENT LIMIT SWITCH TSOP 6 |
| U1001 | 4813832P70 | TRANS SUP 5.6V QUAD |
| U1002 | 4813832P70 | TRANS SUP 5.6V QUAD |
| U103 | 5109768D08 | IC TEMP SENSOR LM20BIM7X SC 70 |
| U1100 | 5199454C07 | IC WALLY PROG BASEBAND |
| U1130 | 2409377M08 | IC SW ANAL SPDT MAX4544EUT |
| U1131 | 2409377M08 | IC SW ANAL SPDT MAX4544EUT |
| U1132 | 2409377M08 | IC SW ANAL SPDT MAX4544EUT |
| U1200 | 5109879E71 | IC BICMOS CCAP V2.6 121 BG |
| U1300 | 5199443A01 | IC FLASH MEM 2MX16 AM29BDL32 |
| U1308 | 5109781E77 | IC VOLT DECT 3.6V PST995NNR |
| U1400 | 5109509A36 | IC SRAM 256KX16 KM616FR4010ZI |
| U325 | 4809863M17 | OSC MOD REF 16.8MHZ 5032 SMD |
| U326 | 5109522E22 | IC SNGL AND GATE TC7S08FU |
| U400 | 5109940K29 | IC MIX/EXC CDMA/AMPS ME3 32BCC |
| U401 | 5109572E39 | IC GAAS SPDT RF SWITCH SC70-6 |
| U402 | '5109572E39 | IC GAAS SPDT RF SWITCH SC70-6 |
| U520 | 5109730C25 | MMIC GAAS RF PA 2000 5 MLP |
| U525 | 5109731C27 | IC OP AMP SNGL LMV821M7 5SC70 |
| U550 | 5803912K03 | ISLTR CER TX 836MHZ 6MM SMD |
| U551 | 5885810G02 | ISLTR CER 1900MHZ 5X5MM SMD |
| U625 | 5109940K32 | IC MMIC SI BUFF AMPL UPC8151TB |
| U626 | 4809283D34 | OSC MOD VCO 991MHZ SMD |
| U635 | 5109940K32 | IC MMIC SI BUFF AMPL UPC8151TB |
| U636 | 4809283D47 | OSC MOD VCO 2070MHZ 5548 SMD |
| U700 | 5109879E34 | IC BICMOS ZIF/SYNTH SC79882VHR |
| U900 | 5109730C22 | MMIC PA GAAS RF PA2000 4 MLP |
| VR1201 | 4813832P75 | TRANS SUP QUAD 6.8 V |
| VR1202 | 4813830C29 | DIODE 16V 'J1' MMSZ5246BT1 |
| VR1203 | 4809788E06 | DIODE ZENER 6.8V UDZ6.8B |
| VR1204 | | DIODE ZENER 6.8V UDZ6.8B |
| Y1170 | 4809995L05 | XTAL QUARTZ 32.768KHZ CC4V-T1 |
| | 8489102K72 | PCB PHOENIX CDMA MCL |
| | 5409793K02 | LBL FCC THERM TRANSFER |