



One Sprint. Many Solutions.™

**PCS VisionSM Picture Phone
PM-8200**

User's Guide

SANYO

Table of Contents

Welcome to Sprint	i
Introduction	ii
Section 1: Getting Started	1
1A. Setting Up Service	2
Getting Started With PCS Service	3
Setting Up Your Voicemail	4
PCS Account Passwords	5
Getting Help	6
Section 2: Your PCS Vision Phone	8
2A. Your PCS Vision Phone: The Basics	9
Front View of Your Phone	10
Key Features	11
Viewing the Display Screen	13
Features of Your PCS Vision™ Picture Phone PM-8200	14
Turning Your Phone On and Off	15
Using Your Phone's Battery and Charger	16
Displaying Your Phone Number	18
Making and Answering Calls	18
Making Calls	18
Dialing Options	20
Answering Calls	21
Using the Speakerphone	23
Changing the Ringer Volume	24
Adjusting Volume During a Conversation	24
Muting a Call	24
Missed Call Notification	25
Calling Emergency Numbers	25
In-Call Options	26
End-of-Call Options	27
Saving a Phone Number	27
Finding a Phone Number	28
Dialing and Saving Phone Numbers With Pauses	28
Dialing From the Contacts Directory	29

Using Speed Dialing	30
Using Abbreviated Dialing	30
Entering Text	31
Selecting a Character Input Mode	31
Entering Characters Using T9 Text Input	32
Entering Characters by Tapping the Keypad	33
Entering Symbols, Numbers, Preset Suffixes, and Smileys	34
2B. Controlling Your Phone's Settings	35
Sound Settings	36
Ringer Types	36
Selecting a Tone Length	40
Setting a Start-up/Power-off Tone	40
Using Voice Prompt	40
Adjusting the Phone's Volume Settings	41
Alert Notification	42
Silence All	43
Display Settings	44
Changing the Text Greeting	44
Changing the Backlight Time Length	45
Changing the Display Screen Animation	46
Changing the Display for Incoming Calls	47
Changing the Display for Area Name	48
Changing the Display for Standby Mode	49
Changing the Screen Saver	50
Changing the Display for My Buddy	51
Changing the Background	51
Changing the Font Size	52
Location Settings	53
Airplane Mode	54
TTY Use With PCS Service From Sprint	55
Phone Setup Options	56
Shortcut	56
Auto Answer Mode	56
Setting the Open/Close Flip Option	57
Setting Any Key Answer	58

Setting the Side Key Guard	58
Setting Abbreviated Dialing	59
Headset Mode	60
Sleep Mode	60
Setting Message Notification	61
Editing Preset Messages	61
Setting a Callback Number	62
Setting the Current Time	62
Display Language	63
Using the Mini Flashlight	63
2C. Setting Your Phone's Security	64
Accessing the Security Menu	65
Using Your Phone's Lock Feature	66
Locking Your Phone	66
Unlocking Your Phone	66
Locking the Pictures Menu	67
Changing the Lock Code	67
Calling in Lock Mode	67
Restricting Calls	68
Using Special Numbers	69
Erasing the Contacts Directory	69
Erasing All Downloads	70
Resetting Your Pictures Account	70
Resetting Your Phone	70
Resetting and Locking Your Phone Through SMS	71
Security Features for PCS Vision™	72
Enabling and Disabling PCS Vision Services	72
2D. Controlling Your Roaming Experience	73
Understanding Roaming	74
Setting Your Phone's Roam Mode	76
Controlling Roaming Charges Using Call Guard	77
2E. Navigating Through Menus	78
Menu Navigation	79
Menu Structure	79
Viewing the Menus	80

2F. Managing Call History83

Viewing History	84
Call History Options	85
Making a Call From Call History	85
Saving a Phone Number From Call History	86
Prepending a Phone Number From Call History	87
Erasing Call History	87

2G. Using the Contacts Directory88

Displaying the Contacts List	89
Adding a New Contacts Entry	89
Finding Contacts List Entries	90
Contacts List Entry Options	92
Adding a Phone Number to a Contacts Entry	93
Editing a Contacts Entry's Phone Number	93
Assigning Speed Dial Numbers	94
Editing a Contacts Entry	95
Selecting a Ringer/Image Type for an Entry	95
Secret Contacts Entries	97
Dialing PCS Services	98

2H. Personal Organizer99

Managing the Scheduler	100
Using Your Phone's Scheduler	101
Adding an Event to the Scheduler	101
Event Alerts	102
Event Alert Menu	103
Viewing Events	103
Erasing a Day's Events or Call Alarms	103
Adding a Call Alarm to the Scheduler	104
Call Alarm Alerts	105
Call Alarm Menu	105
Editing a Call Alarm	106
Viewing a Future/Past Day's Scheduled Events	106
Adding To Do List Items	107
Viewing the To Do List	107
Editing To Do List Items	107

Adding a To Do List Item to the Schedule	108
Deleting Items From the To Do List	108
Viewing Memory in Your Scheduler	109
Purging All Events, Call Alarms, or To Do List Items	109
Personal Information Management	110
Displaying Your User Address	110
Finding Icon Definitions	110
Displaying the Version Information	110
Displaying Advanced Information	111
Using Your Phone's Tools	111
Using the Alarm Clock	111
Using the Calculator	112
Using the World Clock	112
Downloading Files Through PCS Vision	113
Confirming the Downloaded Data	117
Viewing the Downloaded Data Size	122
2I. Using Your Phone's Voice Services	123
Using Voice-Activated Dialing	124
Making a Call Using Voice-Activated Dialing	124
Programming Voice Dial Tags	124
Reviewing Voice Dial Tags	125
Erasing All Voice Dial Tags	125
Managing Voice Memos	126
Recording Voice Memos	126
Voice Memo Options	127
Erasing Voice Memos	128
Setting Up Screen Call	129
Activating Screen Call	129
Selecting an Announcement for Screen Call	130
Recording Your Name for a Pre-Recorded Announcement	130
Recording a Customized Announcement	131
Reviewing an Announcement	131
Erasing an Announcement	131
2J. Using PCS Ready Link	132
Getting Started With PCS Ready Link	133

Setting PCS Ready Link Mode	133
Preparing Your Phone for PCS Ready Link Service	134
Ready Link Call Alerts	134
Making and Receiving a PCS Ready Link Call	135
Displaying the PCS Ready Link List	135
Selecting Contact Lists	135
Making a PCS Ready Link Call (1-to-1 Call)	136
Making a PCS Ready Link Call (Group Call)	137
Making a PCS Ready Link Call by Entering a Number	138
Missed Call Notification for PCS Ready Link Calls	138
Receiving a PCS Ready Link Call (1-to-1 Call)	139
Receiving a PCS Ready Link Call (Group Call)	139
Redialing a PCS Ready Link Call	140
PCS Ready Link Options	140
Adding and Editing Ready Link Contacts	141
Copying an Entry to Personal List or Personal Group List	141
Saving a PCS Ready Link Number	142
Finding an Entry in the PCS Ready Link List	142
Adding a New Contact to Your Personal List	143
Adding a New Group to Your Personal Group List	144
Editing a Contact in Your Personal List	145
Editing a Group in Your Personal Group List	145
Erasing Ready Link List Entries	147
Erasing an Entry in Your Personal List or Personal Group List	147
Erasing a PCS Ready Link List	147
Updating Your PCS Ready Link Lists	148
Updating the Company List and Personal List	148
Managing PCS Ready Link Settings	148
Setting Speed Dialing for PCS Ready Link Entries	148
Restarting the Ready Link Service	149
Setting Ready Link Guard	149
Setting Ringer Types for PCS Ready Link Calls	150
Setting an Alert Notification for PCS Ready Link Calls	150
Setting the Speakerphone for PCS Ready Link Calls	151
Setting the Default View of the PCS Ready Link List	151

2K. Using Your Phone’s Built-in Camera152

- Taking Pictures153
 - Creating Your Picture Mail™ Password154
 - Camera Mode Options155
 - Selecting Camera Settings159
 - Viewing Your Camera’s Status Area Display160
- Sending Picture Mail™162
 - Sending Picture Mail From the In Camera Folder162
 - Sending Picture Mail from Messaging164
- Storing Pictures in My Pictures165
 - In Camera Folder165
 - In Camera Folder Options166
 - Saved to Phone Folder168
- Managing Picture Mail170
 - Using the Picture Mail Website170
 - Managing Online Picture Mail From Your PCS Vision Phone170
 - Uploading Your Pictures171
 - Sending Online Picture Mail171
 - Accessing Online Picture Mail Options From Your PCS Vision Phone ..172

Section 3: PCS Service Features174

3A. PCS Service Features: The Basics175

- Using Voicemail176
 - Setting Up Your Voicemail176
 - Voicemail Notification176
 - New Voicemail Message Alerts177
 - Retrieving Your Voicemail Messages177
 - Voicemail Options179
 - Clearing the Message Icon181
 - Voicemail Menu Key182
- Using Caller ID183
- Responding to Call Waiting183
- Making a Three-Way Call184
- Using Call Forwarding185

3B. PCS VisionSM186

- Getting Started With PCS Vision187

Your User Name	187
Launching a PCS Vision Connection	189
Net Guard	190
PCS Vision Connection Status and Indicators	190
Navigating the Web	191
Understanding Messaging	193
Message Types	193
New Messages	193
Message Storage	194
Displaying Messages	194
Displaying Picture Mail	194
Sending a Message	195
Sending a Message in the Drafts Folder	196
Sending a Message in the Outbox Folder	197
Message Options	197
Changing the Display Font Size of a Message	199
Prepending a Phone Number From a Message	199
Message Folders	200
Erasing All Messages	201
Moving a Message Into Another Folder	201
Erasing a Folder	202
Erasing Selected Messages in All Folders	202
Signing Up for Updates	203
Using Email	204
Accessing Email Messages	204
Composing Email Messages	204
Accessing Alternate Email Providers	205
Using Alternate Email Providers	205
Using Instant Messaging	206
Accessing Instant Messaging	206
Experiencing Wireless Online Chat	207
Downloading Premium Services Content	208
Accessing Games	210
Accessing Ringers	212
Accessing Screen Savers	214
Exploring the Web	216

Using the Browser Menu	217
Using PCS Business Connection Personal Edition	221
PCS Vision FAQs	222
3C. PCS Voice Command™	223
Getting Started With PCS Voice Command™	224
Creating Your Own Address Book	224
Making a Call With PCS Voice Command	225
Accessing Information Using PCS Voice Command	225
Section 4: Safety Guidelines and Warranty Information ..	226
4A. Safety	227
Getting the Most Out of Your Reception	228
Maintaining Safe Use of and Access to Your Phone	229
Caring for the Battery	231
Acknowledging Special Precautions and the FCC Notice	232
Consumer Information on Wireless Phones	234
Owner's Record	249
User's Guide Proprietary Notice	249
4B. Terms & Conditions and Manufacturer's Warranty	250
Terms and Conditions	251
Manufacturer's Warranty	272
Index	275



Welcome to Sprint

Sprint has the most complete, all-digital wireless network in the nation. Depend on it. We are committed to bringing you the best wireless technology available. With Sprint, you get the most complete, all-digital wireless network in the nation so all your services work the same wherever you go on the network. We built our network right from the start, so no matter where you are on the enhanced Sprint Nationwide PCS Network, all your services – whether it's Voicemail, Caller ID, email, or Picture Mail – will work the same.

This guide will familiarize you with our technology and your new PCS Vision Phone through simple, easy-to-follow instructions. If you have already reviewed the **Start Here to Activate** guide that was packaged with your new phone, then you're ready to explore the advanced features outlined in this guide.

If you have not read your **Start Here to Activate** guide, go to Section One – Getting Started. This section provides all the information you need to unlock your phone, set up your voicemail, and much more. It also contains information on how to contact Sprint if you have any questions about your service, wish to check your account balance, or want to purchase additional products or services.

Sprint is different. All your services work the same wherever you go on the most complete, all-digital wireless network in the nation.

Welcome and thank you for choosing Sprint.

Introduction

This **User's Guide** introduces you to PCS Service and all the features of your new phone. It's divided into four sections:

- ◆ **Section 1:** Getting Started
- ◆ **Section 2:** Your PCS Vision Phone
- ◆ **Section 3:** PCS Service Features
- ◆ **Section 4:** Safety Guidelines and Warranty Information

Throughout this guide, you'll find tips that highlight special shortcuts and timely reminders to help you make the most of your new phone and service. The Table of Contents and Index will also help you quickly locate specific information.

You'll get the most out of your phone if you read each section. However, if you'd like to get right to a specific feature, simply locate that section in the Table of Contents and click on the page number to go directly to that page. Follow the instructions in that section, and you'll be ready to use your phone in no time.

Note: You can view this guide online or print it to keep it on hand. If you're viewing it online, simply click on a topic in the Table of Contents or Index or on any page reference. The PDF will automatically display the appropriate page.

Getting Started



Setting Up Service

In This Section

- ◆ **Getting Started With PCS Service**
 - ◆ **Setting Up Your Voicemail**
 - ◆ **PCS Account Passwords**
 - ◆ **Getting Help**
-

Setting up service on your new PCS Vision Phone is quick and easy.

This section walks you through the necessary steps to set up your phone, unlock your phone, set up your voicemail, establish passwords, and contact Sprint for assistance with your PCS Service.

Getting Started With PCS Service

Determining if Your Phone is Already Activated

If you received your phone in the mail or purchased it at a Sprint Store, it probably has already been activated. All you need to do is unlock your phone.

If your phone is not activated, please refer to the Start Here Guide included with your phone.

Unlocking Your Phone

To unlock your phone, follow these easy steps:

1. Press **END/⓪** to turn the phone on.
2. Press **Unlock** (left softkey).

Note: To select a softkey, press the softkey button directly below the softkey text that appears at the bottom left and bottom right of your phone's display screen. Softkey actions change according to the screen you're viewing and will not appear if there is no corresponding action available.

3. Enter your four-digit lock code. (For security purposes, the code is not visible as you type.)

Tip: If you can't recall your lock code, try using the last four digits of either your Social Security number or PCS Phone Number or try 0000. If none of these work, call PCS Customer Solutions at 1-888-211-4PCS (4727).

Setting Up Your Voicemail

All unanswered calls to your PCS Vision Phone are automatically transferred to your voicemail, even if your phone is in use or turned off. Therefore, you will want to set up your voicemail and personal greeting as soon as your PCS Vision Phone is activated.

To set up your voicemail:

1. Press and hold  1.
2. Follow the system prompts to:
 - Create your passcode
 - Record your greeting
 - Record your name announcement
 - Choose whether or not to activate One-Touch Message Access (a feature that lets you access messages simply by pressing and holding  1, bypassing the need for you to enter your passcode)

Note: The voicemail setup process may vary in certain Affiliate areas.

For more information about using your voicemail, see “Using Voicemail” on page 176.

PCS Account Passwords

As a PCS customer, you enjoy unlimited access to your personal account information, your voicemail account, and your PCS Vision account. To ensure that no one else has access to your information, you will need to create passwords to protect your privacy.

Account Password

If you are the account owner, you'll have an account password to sign on to www.sprintpcs.com and to use when calling PCS Customer Solutions. Your default account password is the last four digits of your Social Security number. If you are not the account owner (if someone else pays for your PCS Service), you can get a sub-account password at www.sprintpcs.com.

Voicemail Password

You'll create your voicemail password (or passcode) when you set up your voicemail. See "Setting Up Your Voicemail" on page 176 for more information on your voicemail password.

PCS Vision Password

If you have a PCS Vision Phone, you can set up a PCS Vision Password. This optional password may be used to authorize purchase of Premium Services content and to protect personal information on multi-phone accounts.

For more information or to change your passwords, sign on to www.sprintpcs.com or call PCS Customer Solutions at 1-888-211-4PCS (4727).

Getting Help

Visit Our Website

You can get up-to-date information on PCS Services and Options by signing onto our Website at www.sprintpcs.com.

When you visit us online, you can

- Review coverage maps
- Learn how to use voicemail
- Access your account information
- Purchase accessories
- Add additional options to your service plan
- Check out frequently asked questions
- And more

Reaching PCS Customer Solutions

You can reach PCS Customer Solutions many different ways:

- Dial **✕ 2 TALK** on your PCS Vision Phone
- Sign on to your account at www.sprintpcs.com
- Call us toll-free at 1-888-211-4727 (Consumer customers), 1-877-CLEARPY (253-2779) (PCS Clear PaySM customers), or 1-888-788-4727 (Business customers)
- Write to us at PCS Customer Solutions, P.O. Box 8077, London, KY 40742

Receiving Automated Invoicing Information

For your convenience, your phone gives you access to invoicing information on your PCS Account. This information includes balance due, payment received, invoicing cycle, and the number of minutes used since your last invoicing cycle. (Normal airtime usage will apply.)

To access automated invoicing information:

- ▶ Press **✕ 4 TALK**.

Note: This service may not be available in all Affiliate areas.

PCS Directory Assistance

You have access to a variety of services and information through PCS Directory Assistance, including residential, business, and government listings; assistance with local or long-distance calls; movie listings; and hotel, restaurant, shopping, and major local event information. There is a per-call charge and you will be billed for airtime.

To call PCS Directory Assistance:

▶ Press **4 1 1 TALK**.

PCS Operator Services

PCS Operator Services provides assistance when placing collect calls or when placing calls billed to a local telephone calling card or third party.

To access PCS Operator Services:

▶ Press **0 TALK**.

For more information or to see the latest in products and services, visit us online at www.sprintpcs.com.

Note: PCS Operator Services may not be available in all Affiliate areas.

Your PCS Vision Phone



Your PCS Vision Phone: The Basics

In This Section

- ◆ **Front View of Your Phone**
 - ◆ **Viewing the Display Screen**
 - ◆ **Features of Your PCS Vision™ Picture Phone PM-8200**
 - ◆ **Turning Your Phone On and Off**
 - ◆ **Using Your Phone's Battery and Charger**
 - ◆ **Displaying Your Phone Number**
 - ◆ **Making and Answering Calls**
 - ◆ **Entering Text**
-

Your PCS Vision Phone is packed with features that simplify your life and expand your ability to stay connected to the people and information that are important to you. This section will guide you through the basic functions and calling features of your phone.

Front View of Your Phone



Key Features

1. **Earpiece:** Lets you hear the caller's voice.
2. **Main LCD (display):** Displays the phone's main menu, features, modes, etc.
3. **Softkey (left):** Lets you select the menu corresponding to the bottom left line on the Main LCD.
4. **Navigation Key:** Lets you navigate quickly and easily through the menu options. You can access menu shortcuts by pressing
Right : Contacts, Left : My Shortcut, Up : Messaging, and
Down : Downloads.
5. **MENU/OK:** Lets you access the phone's menus and select menu options.
6. **Camera Key:** Lets you access the Pictures menu and take pictures.
7. **TALK:** Lets you place or receive calls, answer Call Waiting, or use Three-Way Calling and Voice Dial.
8. **Microphone:** To speak into or record your voice.
9. **Accessories Connector:** Connects optional accessories such as a USB cable.
10. **Charger Jack:** Connects the travel charger (included).
11. **Keypad:** Lets you enter numbers, letters, and characters, and navigate within menus. Press and hold keys 2-9 for speed dialing.
12. **SPEAKER Key:** Lets you place or receive calls in speakerphone mode. You can also use it to activate Voice Dial and Memo recording.
13. **END/POWER:** Lets you turn the phone on/off, end a call, or return to standby mode.
14. **Side Camera Key:** Lets you display the Pictures menu and take pictures.
15. **BACK:** Lets you clear characters from the screen or display the previous page.

16. **Side Call Key:** Lets you place or receive calls without opening the phone.
17. **Softkey (right):** Lets you select the menu corresponding to the bottom right line on the Main LCD.
18. **Speaker:** Lets you hear the different ringers and sounds. You can mute the ringer when receiving incoming calls by pressing , , , , , or Side Camera key.
19. **LED Indicator:** Shows your phone's connection status at a glance.
20. **Sub LCD:** Lets you monitor the phone's status and see who's calling without opening the phone.
21. **Flash:** The built-in flash lets you take pictures in low light. You can also use it as a mini flashlight.
22. **Camera Lens:** The built-in camera lens lets you take pictures.
23. **Antenna:** Fully extend the antenna for the best reception.
24. **Headset Jack:** Lets you insert the plug of a headset (sold separately) for hands-free phone use.
25. **Ready Link (Memo) Button:** Allows you to access the PCS Ready Link List or Voice Memo menu. (See "Using PCS Ready Link" on page 132 or "Managing Voice Memos" on page 126.)
26. **Side Volume Key:** Lets you adjust the receiver volume during a call or ringer volume in standby mode.

Viewing the Display Screen

Your phone's display screen provides a wealth of information about your phone's status and options. This list identifies the symbols you'll see on your phone's display screen:

-  shows your current signal strength. The more lines you have, the stronger your signal.
-  means your phone cannot find a signal.
-  tells you a call is in progress.
-  indicates PCS Vision/PCS Ready Link access is dormant.
-  indicates PCS Vision/PCS Ready Link access is active.
-  indicates PCS Vision/PCS Ready Link access is disabled.
-  indicates you have new text messages waiting.
-  indicates you have new voicemail messages waiting. Press and hold  to call your voicemail box.
-  indicates you have text messages and voicemail messages waiting.
-  indicates you are "roaming" off the Sprint Nationwide PCS Network.
-  indicates the PCS Ready Link Service is enabled.
-  indicates the PCS Ready Link Service is disabled.
-  shows the level of your battery charge. The more black you see, the more power you have left. It displays  while charging.
-  indicates you have menus to scroll (in four directions).
-  indicates a beep sound is set at level 1.
-  indicates the vibrate feature is set.
-  indicates volume level 4 or 1 and vibrate feature is set.
-  indicates the voice call ringer setting is off.
-  indicates all the sound settings are off.
-  indicates the Location Service of your phone is enabled.
-  indicates the Location Service of your phone is disabled.
-  indicates you have a new caller's message.
-  indicates the Screen Call Auto setting is on.
-  indicates you have new downloaded data.
-  indicates your phone is in TTY mode.
-  indicates Headset mode is set to PCS Ready Link and a headset is connected.
-  indicates the speakerphone mode is set to on.

Note: Display indicators help you manage your roaming charges by letting you know when you're off the Sprint Nationwide PCS Network and whether you're operating in digital or analog mode. (For more information, see Section 2D: Controlling Your Roaming Experience on page 73.)

Features of Your PCS VisionSM Picture Phone PM-8200

Congratulations on the purchase of your PCS VisionSM Picture Phone PM-8200 by Sanyo. This phone is lightweight, easy-to-use and reliable, and it also offers many significant features and service options. The following list previews some of those features and options and provides page numbers where you can find out more:

- Dual-band/tri-mode capability allows you to make and receive calls while on the Sprint Nationwide PCS Network and to roam on other analog and 800 and 1900 MHz digital networks where Sprint has implemented roaming agreements (page 73).
- PCS VisionSM provides access to the wireless Internet in digital mode (page 186).
- Email provides quick and convenient text messaging capabilities (page 204).
- PCS Voice CommandSM lets you dial phone numbers by speaking someone's name or the digits of their phone number (page 223).
- Games, ringers, screen savers, and other applications can be downloaded to your phone to make your PCS Vision Phone as unique as you are (page 208).
- The built-in organizer lets you schedule alerts to remind you of important events (page 99).
- Speed Dialing lets you call a phone number stored in your Contacts directory using one touch dialing (page 30).
- The Contacts directory can store up to 500 numbers and 300 email and Web addresses in 300 entries (entries can store up to seven numbers each). A separate PCS Ready Link Contacts List provides easy access to up to 200 personal contacts and 200 company-provided contacts.
- The built-in camera allows you to take full-color digital pictures, view your pictures using the phone's display, and instantly send them to a family and friends using Picture MailSM service (page 152).
- PCS Ready Link allows you to enjoy quick, two-way, "walkie-talkie-style" communication with one or several PCS Ready Link users (page 132).
- Large 1.8-inch, full-color display screen plus external display.
- The Side Call key lets you place or receive calls without opening the phone (page 19).

Turning Your Phone On and Off

Turning Your Phone On

To turn your phone on:

- ▶ Press **END/⓪**.

Once your phone is on, it displays “Looking for service...” which indicates that your phone is searching for a signal. When your phone finds a signal, it automatically enters standby mode – the phone’s idle state. At this point, you are ready to begin making and receiving calls.

If your phone is unable to find a signal after 15 minutes of searching, a Power Save feature is automatically activated. When a signal is found, your phone automatically returns to standby mode.

In Power Save mode, your phone searches for a signal periodically without your intervention. You can also initiate a search for PCS Service by pressing any key (when your phone is turned on).

Tip: The Power Save feature helps to conserve your battery power when you are in an area where there is no signal.

Turning Your Phone Off

To turn your phone off:

- ▶ Press and hold **END/⓪** until you see the powering down animation on the display screen.

Your screen remains blank while your phone is off (unless the battery is charging).

Using Your Phone's Battery and Charger

Battery Capacity

Your PCS Vision Phone is equipped with a Lithium Ion (LiIon) battery. It allows you to recharge your battery before it is fully drained. The battery provides approximately 3.0 hours of continuous digital talk time (1.7 hours in analog) or approximately 288 hours of continuous digital standby time (17 hours in analog).

When the battery reaches 5% of its capacity, the low battery icon appears. When there are approximately two minutes of talk time left, the phone sounds an audible alert and then powers down.


Note: Long backlight settings, searching for service, vibrate mode, PCS Ready Link mode, and browser use affect the battery's talk and standby times.

Tip: Be sure to watch your phone's battery level indicator and charge the battery before it runs out of power.

Installing the Battery

To install the Lilon battery:


1. Place the battery into the space beneath the antenna with the metal contacts at the bottom, facing downward.
2. Gently press down until it's in place and the battery release latch snaps.



Removing the Battery

To remove your battery:

1. Make sure the power is off so that you don't lose any stored numbers or messages.
2. Push the battery release latch up and hold the battery.
3. Pull the battery up and out at a 45-degree angle.



Charging the Battery

Your PCS Vision Phone's LiIon battery is rechargeable and should be charged as soon as possible so you can begin using your phone.

Keeping track of your battery's charge is important. If your battery level becomes too low, your phone automatically turns off and you will lose all the information you were just working on. For a quick check of your phone's battery level, glance at the battery charge indicator located in the upper-right corner of your phone's display screen. If the battery charge is getting too low, the low battery icon () appears and the phone sounds a warning tone.

Always use a Sprint-approved travel charger or vehicle power adapter to charge your battery.

Warning! Using the wrong battery charger could cause damage to your phone and void the warranty.

Using the Travel Charger

To use the travel charger provided with your phone:

1. Plug the travel charger into a wall outlet.
2. Plug the other end of the travel charger into the bottom of your phone (with the battery installed).
 - **Charging when your phone is turned on:**
The battery icon () appears on the display while charging. The battery icon turns to () when charging is complete.
 - **Charging when your phone is turned off:**
The battery icon () appears, and the message "BATTERY CHARGING-Power Off-" is shown on the display while charging. When the battery is completely discharged, you may wait for several minutes until the message is shown on the display. The battery icon turns to () , and the message changes to "CHARGING COMPLETE-Power Off-" when charging is complete.

It takes approximately 3.5 hours to fully recharge a completely rundown battery. With the Sprint-approved LiIon battery, you can recharge the battery before it becomes completely run down.

Displaying Your Phone Number

Just in case you forget your phone number, your PCS Vision Phone can remind you.

To display your phone number:

1. Press  to access the main menu.
2. Select **Contacts** and press .
3. Select **My Phone#** and press .

Note: To access the phone's main menu, press  from standby mode. Menu items may be selected by highlighting them with the navigation key and pressing , or you can press the number corresponding to the menu item on your keypad.

Making and Answering Calls

Making Calls

Placing a call from your PCS Phone is as easy as making a call from any land line phone. Just enter the number and press  and you're on your way to clear calls.

To place a call using your keypad:


1. Make sure your phone is on.
2. Enter a phone number. (If you make a mistake while dialing, press  to erase one digit at a time. Press and hold  to erase the entire number.)
3. Press  or . (To place a call when you are roaming and Call Guard is enabled, see "Controlling Roaming Charges Using Call Guard" on page 77.)
4. When you're finished, press  to end the call.

Tip: To redial your last outgoing call, press  or  twice.

Tip: When making calls off the Sprint Nationwide PCS Network, always dial using 11 digits (1 + area code + phone number).

You can also place calls from your PCS Phone by using PCS Voice Command™ (page 223), Speed Dialing (page 30), and using your Call History listings (page 83).

Important: To maximize performance when using your PCS Phone, extend the antenna before a call and do not touch the antenna during a call (see page 228).



To place a call with the flip closed:

1. Make sure your phone is on.
2. Press and hold the Side Call key () on the right side of the phone. (You will see a message on the Sub LCD.)
3. Follow the system prompts. (The call will be made in speakerphone mode, unless you have a headset attached to the phone.)
 - **Redial** to redial the last number you called.
 - **Voice Dial** to use the Voice Dial function (see “Using Voice-Activated Dialing” on page 124).
4. When you're finished, press and hold .

Note: To use a Voice Dial, you must have stored Voice Dial entries (see “Programming Voice Dial Tags” on page 124).

Dialing Options

Dialing options are displayed when you press **Options** (right softkey) after entering numbers in the phone's standby mode.

To select an option, highlight it and press .

- **Call** to dial the phone number.
- **Call:Speaker On** to dial the phone number in speakerphone mode.
- **Send Message** to send a text message. See page 195 for details.
To send Picture Mail, see page 162.
- **Save Phone#** to save the phone number in your Contacts list. (See "Saving a Phone Number" on page 27.)
- **Find** to display Contacts list entries that end with the digits you entered. (See "Finding a Phone Number" on page 28.)
-  **Hard Pause** to insert a hard pause. (See "Dialing and Saving Phone Numbers With Pauses" on page 28.)
-  **2-Sec. Pause** to insert a 2-second pause. (See "Dialing and Saving Phone Numbers With Pauses" on page 28.)
- **Hyphen** to insert a hyphen. (Hyphens are generally for visual appeal only; they are not necessary when entering numbers.)

Note: To speed dial a phone number, press and hold the appropriate speed dial key (locations 2-9). See "Assigning Speed Dial Numbers" on page 94.

This option appears when you enter four digits and press .

- **Abbrev. Dial** to dial the phone number in your Contacts list that ends with the four digits you entered. (See "Using Abbreviated Dialing" on page 30.)

Answering Calls

To answer an incoming call with the flip open:

1. Make sure your phone is on. (If your phone is off, incoming calls go to voicemail.)
2. Press **TALK** or **SPEAKER** to answer an incoming call. (Depending on your phone's settings, you may also answer incoming calls by opening the phone or by pressing any number key. See "Setting Any Key Answer" on page 58 for more information.)

To answer an incoming call with the flip closed:

1. Make sure your phone is on. (If your phone is off, incoming calls go to voicemail.)
2. When your phone rings or vibrates, press and hold the Side Call key () on the right side of the phone. (The call will be answered in speakerphone mode.)
– or –
Open the phone to use the earpiece.

Note: If the setting for Open Flip is not set to "Answer Call," opening the phone will not answer the call. (See "Setting the Open/Close Flip Option" on page 57.)

Your PCS Vision Phone notifies you of incoming calls in the following ways:

- The phone rings or vibrates.
- The LED flashes.
- The backlight illuminates.
- The screen displays an incoming call message.
- If available, the phone number of the caller is displayed.
- If the phone number is in your Contacts list, the contact's name is displayed.

The following options are also displayed by pressing **Options** (right softkey). To select an option, highlight it and press .

- **Call Guard** to answer the call when you are in roaming mode. See page 77 for setting Call Guard.
- **Answer** to answer the call.
- **Answer:Speaker** to answer the call in speakerphone mode.
- **Don't Answer** to hang up the incoming call and return to the Web or camera mode while you are in Web or Camera operation. (This feature appears only when PCS Vision access is dormant or when your phone is in camera mode.)
- **Screen Call** to answer the call by using a pre-recorded announcement. (This feature appears only when you are in a PCS Service area or digital roaming area. See page 129.)
- **Quiet Ringer** to mute the ringer. (This feature appears only when the ringer is set.)

Tip: Your PCS Phone offers additional ways to answer calls. (See page 56 for Auto Answer and see page 58 for Any Key Answer.)

Answering a Roam Call With Call Guard Enabled

Call Guard is an option that helps you manage your roaming charges when making or receiving calls while outside the Sprint Nationwide PCS Network. Please see Section 2D: Controlling Your Roaming Experience for more information about roaming.

To answer a call when you are roaming and Call Guard is enabled:

1. Press  or . (The following message will appear: "Roaming rate applies. Please press [1] to accept.")
2. Press  to answer the call.

Note: When your phone is off, in an active PCS Vision Connection, or on a PCS Ready Link call, incoming calls go directly to voicemail.

Ending a Call

To disconnect a call when you are finished:

With the Flip open:

- ▶ Close the phone or press **END/⓪**.

With the Flip closed:

- ▶ Press and hold **⓪||**.

Note: If the setting for Close Flip is not set to “end call,” closing the phone will not end the call. (See “Setting the Open/Close Flip Option” on page 57.)

Tip: Time/Date is displayed when you press **BACK** while the phone is in use.

Using the Speakerphone

The speakerphone feature lets you hear audio through the speaker and talk without holding the phone. When the speakerphone is activated, use the volume control keys on the side of the phone to adjust the volume.

To turn the speakerphone on during a call:

- ▶ Press **SPEAKER**.

– or –

Press **Options** (right softkey), highlight **Speaker On**, and press **MENU OK**.

To turn the speakerphone off during a call:

- ▶ Press **SPEAKER**.

– or –

Press **Options** (right softkey), highlight **Speaker Off**, and press **MENU OK**.

Warning! Due to higher volume levels, do not place the phone near your ear during speakerphone use.

Changing the Ringer Volume

To change the ringer volume, press the Side Volume key when the phone is open and in standby mode.

Note: To change the ringer volume from the main menu, see “Adjusting the Phone’s Volume Settings” on page 41.

Adjusting Volume During a Conversation

When you need to adjust the receiver volume during a conversation, use the side volume key, or press the navigation key up or down while a call is in progress.

Muting a Call

There are times when it’s necessary to mute a call so that your caller does not hear you or certain background noise.

To mute a call with the Flip open:

- ▶ Press **Options** (right softkey), highlight **Mute**, and press . (When the phone is muted, “**Mute**” appears on the display.)

To unmute a call with the Flip open:

- ▶ Press **Options** (right softkey), highlight **Unmute**, and press .

To mute a call with the Flip closed:

- ▶ Simply press  (side of the phone).

To unmute a call with the Flip closed:

- ▶ Press  once again during a call.

Missed Call Notification

When an incoming call is not answered, the Missed Call log is displayed on your screen.

To display the Missed Call entry:

- ▶ Press **View** (left softkey). (To call an entry, highlight the entry you want to call and press **TALK** or **SPEAKER**.)

Calling Emergency Numbers

You can place calls to 911 (dial **9** **1** **1** and press **TALK**), even if your phone is locked or your account is restricted. Once you dial the numbers, your phone will enter Emergency mode.

Press **Options** (right softkey) to display the options. To select an option, highlight it and press **MENU OK**.

- **My Phone#** to display your phone number.
- **Speaker On** to activate speakerphone mode. (If you are in speakerphone mode, the option will appear as **Speaker Off** to deactivate.)
- **Unlock Phone** to unlock your phone (appears only if the phone is locked).

To exit Emergency mode:

1. Press **END/⓪**.
2. Press **Options** (right softkey) to display the options.
 - **Call 911** to call 911.
 - **Call 911:Speaker** to call 911 in speakerphone mode.
 - **My Phone#** to display your phone number.
 - **Exit Emergency** to exit Emergency mode.
3. Highlight **Exit Emergency** and press **MENU OK**.

In-Call Options

During a call, your phone displays menu options when you press **Options** (right softkey).

To select an option, highlight it and press .

- **Flash** to answer an incoming Call Waiting call or to connect a third party during Three-Way Calling.
- **Mute** or **Unmute**
Select **Mute** to mute your phone's microphone. Select **Unmute** to reactivate the microphone.
- **Speaker On** or **Speaker Off** to activate or deactivate speakerphone mode. You can adjust the speakerphone volume using the Side Volume key.

Warning! Due to higher volume levels, do not place the phone near your ear during speakerphone use.

- **Three-Way Call** to call a third party.
- **Call History** to access the Call History menu. (See “Managing Call History” on page 83.)
- **Contacts** to access the Contacts menu. (See “Using the Contacts Directory” on page 88.)
- **Messaging** to access the Messaging menu. (See “PCS Messaging” on page 193.)
- **Settings** to access the Settings menu. (See “Controlling Your Phone's Settings” on page 35.)
- **Tools/Extras** to access the Tools/Extras menu. (See “Personal Organizer” on page 99.)
- **Voice Services** to access the Voice Services menu. (See “Using Your Phone's Voice Services” on page 123.)

Note: The Flash menu appears only for Call Waiting and Three-Way Calling. The Mute menu does not appear during a 911 call. The Three-Way Call menu does not appear in Roaming areas.

End-of-Call Options

To display the following options, press **Options** (right softkey) within 10 seconds after disconnecting a call.

To select an option, highlight it and press .

- **Call Again** to dial the phone number.
- **Call:Speaker On** to dial the phone number in speakerphone mode.
- **Save Phone#** to save the phone number in your Contacts list.
Go to Phone Book appears when the number is already in your Contacts list. (See “Saving a Phone Number” below.)

Note: The End-of-Call options are not displayed for calls identified as No ID or Restricted.

Saving a Phone Number

Your PCS Vision Phone can store up to 500 phone numbers in up to 300 Contacts entries (an entry may contain up to seven numbers). Each entry's name can contain 16 characters. Your phone automatically sorts the Contacts entries alphabetically. (For more information, see Section 2G: Using the Contacts Directory on page 88.)

To save a number from standby mode:

1. Enter a phone number.
2. Press **Options** (right softkey).
3. Highlight **Save Phone#** and press .
4. Select a label by highlighting **Mobile, Home, Work, Pager, Fax, Other, or No Label** and press .
5. Enter a name and press .
If you have already stored entries in the Contacts list, you are prompted to select the following entry modes:
 - **New Name** to enter a new name.
 - **From Ph. Book** to select a name from the Contacts entry list.
6. Press **Save** (left softkey).

After you have saved the number, the new Contacts entry is displayed. (See “Contacts List Entry Options” on page 92.)

Finding a Phone Number

You can search Contacts list entries for phone numbers that contain a specific string of numbers.

To find a phone number:

1. Enter the last four or more digits of the number and press **Options** (right softkey). The more numbers you enter, the more specific the search becomes.
2. Highlight **Find** and press . (The Contacts entry that ends with the digits you entered appears.)
3. Highlight your desired entry.
 - Press  to display the entry details.
 - Press  or  to dial.

Dialing and Saving Phone Numbers With Pauses

You can dial or save phone numbers with pauses for use with automated systems, such as voicemail or credit card billing numbers.

There are two types of pauses available on your phone:

- **Hard Pause** sends the next set of numbers when you press .
- **2-Sec. Pause** automatically sends the next set of numbers after two seconds.

Note: You can have multiple pauses in a phone number and combine 2-second and hard pauses.

To dial or save phone numbers with pauses:

1. Enter the phone number and press **Options** (right softkey).
2. Highlight either **Hard Pause** or **2-Sec. Pause** and press . (Hard pauses are displayed as a “H” and 2-second pauses as a “T”.)
3. Enter additional numbers (for example, a passcode or an extension).
4. To dial the number, press  or . (When dialing a number with a hard pause, press  to send the next set of numbers.)
– or –
To save the number in your Contacts list, press **Options** (right softkey), highlight **Save Phone#**, and press .

Dialing From the Contacts Directory

To dial directly from a **Contacts** entry:

1. Press  to access the main menu.
2. Select **Contacts** and press .
3. Select **Find/Add Entry** and press .

Shortcut: Press the navigation key right to list entries.

4. Use your navigation key to scroll through the **Contacts** list, highlight your desired entry, and press .
5. Highlight the number you want to call.
6. Press **Options** (right softkey) for the menu options.
7. Highlight **Call** or **Call:Speaker On** and press  to place a call.

Tip: You can also place a call by pressing , , or **Call** (left softkey) during step 5 above.

Note: The icons next to each entry represent the **Contacts** labels (for example, **Mobile**, **Home**, **Work**, etc.). A triangle next to an icon means there is another number for the entry. Press the navigation key right or left to select the desired label/number.

Using Speed Dialing

With this feature, you can dial your favorite entries using one key press for locations 2-9. (See “Assigning Speed Dial Numbers” on page 94.)

To use speed dial for voice calls:

- ▶ From standby mode, press and hold the appropriate key for approximately two seconds.
 - or –
- ▶ From standby mode, press the appropriate key and press **TALK** or **SPEAKER**.

The display confirms that the number has been dialed when it shows “Connecting...”.

To use speed dial for PCS Ready Link calls:

- ▶ From standby mode, press the appropriate key then press and hold **|||||**. (See “Setting Speed Dialing for PCS Ready Link Entries” on page 148.)

The display confirms that the number has been dialed when it shows “R-Link calling...”.

Note: Speed dialing is not available when you are roaming; when you are roaming off the Sprint Nationwide PCS Network, you must always dial using eleven digits (1 + area code + number).

Using Abbreviated Dialing

Abbreviated Dialing is another form of speed dialing. It allows you to dial a number by entering just the last four digits of any number in your Contacts directory. The Abbreviated Dialing option becomes available when you enter the last four digits of a phone number and press **Options** (right softkey).

To place a call using Abbreviated Dialing:

1. Dial the last four digits of a contact’s phone number.
2. Press **Options** (right softkey) to display the dialing options.
3. Highlight **Abbrev. Dial** and press **MENU OK**, **TALK**, or **SPEAKER**.

Note: If there are two or more matched numbers in your Contacts list, the number that comes first alphabetically will be dialed. If there is no matched number, your phone dials the number you set for abbreviated dial with the last 4-digits you entered. (See “Setting Abbreviated Dialing” on page 59.)

Entering Text

Selecting a Character Input Mode

Your PCS Vision Phone provides convenient ways to enter words, letters, punctuation, and numbers whenever you are prompted to enter text (for example, when adding a Contacts entry or when sending email messages).

To change the character input mode:

1. When you display a screen where you can enter text, press **Mode** (right softkey).
2. Select a character input mode:
 - **T9 Word** to enter characters using predictive T9 Text Input (see next page).
 - **Alphabet** to enter characters by tapping the keypad (see page 33).
 - **SYMBOL** to enter symbols (see page 34).
 - **NUMBER** to enter numbers (see page 34).
 - **PRESET SUFFIX** to enter a preset suffix (see page 34).
 - **SMILEYS** to enter “emoticons” (see page 34).

Entering Characters Using T9 Text Input

T9 Text Input lets you enter text in your PCS Vision Phone by pressing keys just once per letter. (To select the **T9 Word** mode when entering text, see “Selecting a Character Input Mode” on the previous page.)

T9 Text Input analyzes the letters you enter using an intuitive word database and creates a suitable word. (The word may change as you enter more letters.) If the word you want does not display after you have entered all the letters, press **Next O** to scroll through additional word selections. To accept a word and insert a space, press **Space #**.

If you make a mistake, press **BACK** to erase a single character. Press and hold **BACK** to delete an entire entry.

Adding a Word to the T9 Database

If a word you want to enter does not display as an option when you are using T9 Text Input, you can add it to the database.

To add a word to the T9 Text Input database:

1. Select the **Alphabet** input mode. (See “Selecting a Character Input Mode” on the previous page.)
2. Enter the word using multi-tap text entry. (See “Entering Characters by Tapping the Keypad” on the next page.)
3. Press **Mode** (right softkey), highlight **T9 Word**, and press **MENU OK**. (The word will appear as an option the next time you scroll through options during T9 Text Input.)

For more information about T9 Text Input, visit the Tegic Website at www.T9.com.

Entering Characters by Tapping the Keypad

To enter characters by tapping the keypad, select the **Alphabet** mode (see “Selecting a Character Input Mode” on page 31). Press the corresponding key repeatedly until the desired character appears. By default, the first letter of an entry is capitalized and following letters are lowercase.

Characters scroll in the following order:

Key	English Sequence	
	Upper Case	Lower Case
1	., @ 1 ? ! * # /	
2	A B C 2	a b c 2
3	D E F 3	d e f 3
4	G H I 4	g h i 4
5	J K L 5	j k l 5
6	M N O 6	m n o 6
7	P Q R S 7	p q r s 7
8	T U V 8	t u v 8
9	W X Y Z 9	w x y z 9
Next 0	0	
Space #	Space	
Shift ✕	Unshifted One-character- shifted Caps Lock	

In Spanish mode, characters scroll in the following order:

Key	Spanish Sequence	
	Upper Case	Lower Case
1	., @ 1 ¿ ? ¡ ! * # /	
2	A Á B C 2	a á b c 2
3	D E É F 3	d e é f 3
4	G H I Í 4	g h i í 4
5	J K L 5	j k l 5
6	M N Ñ O Ó 6	m n ñ o ó 6
7	P Q R S 7	p q r s 7
8	T U Ú Ü V 8	t u ú ü v 8
9	W X Y Z 9	w x y z 9
Next 0	0	
Space #	Space	
Shift ✕	Unshifted One-character- shifted Caps Lock	

(See page 63 for changing to Spanish language mode.)

After a character is entered, the cursor automatically advances to the next space after two seconds or when you enter a character on a different key.

Tip: The beginning of the word after the space is changed to upper/lower case depending on shift mode. You can change the shift mode by pressing **Shift ✕**.

Entering Symbols, Numbers, Preset Suffixes, and Smileys

To enter symbols:

1. In a text entry field, press **Mode** (right softkey).
2. Highlight **SYMBOL** and press .
3. Highlight the line that includes your desired symbol.
4. Press the corresponding key (1-8) with each symbol.

- or -

Highlight your desired symbol by using the navigation key and press .

To enter numbers:

1. In a text entry field, press **Mode** (right softkey).
2. Highlight **NUMBER** and press .
3. Press the corresponding number key to enter the number.

Shortcut: Press and hold the corresponding number key to enter the number directly in alphabet mode or T9 mode.

To enter preset suffixes:

The Preset Suffix menu is a preprogrammed list of common prefixes, suffixes, and punctuation strings (for example, “www.”, “.com”, and “//”) designed to make text entry easier and more efficient.

1. In a text entry field, press **Mode** (right softkey).
2. Highlight **PRESET SUFFIX** and press .
3. Highlight your desired word by using the navigation key and press .

To enter “emoticons” (smileys):

1. In a text entry field, press **Mode** (right softkey).
 2. Highlight **SMILEYS** and press .
 3. Highlight the line that includes your desired smiley.
 4. Press the corresponding key (1-4) with each smiley.
- or -
- Highlight your desired smiley by using the navigation key and press .

Note: Preset Suffix and Smileys do not apply in PCS Ready Link mode.

Controlling Your Phone's Settings

In This Section

- ◆ **Sound Settings**
 - ◆ **Display Settings**
 - ◆ **Location Settings**
 - ◆ **Airplane Mode**
 - ◆ **TTY Use With PCS Service From Sprint**
 - ◆ **Phone Setup Options**
-

Using the menu options available on your PCS Vision Phone, you can customize your phone to sound, look, and operate just the way you want it to.

This section describes how you can change your phone's settings to best suit your needs. Take a few moments to review these options and to adjust or add settings that are right for you.

Sound Settings

Ringer Types

Ringer types help you identify incoming calls and messages. You can assign ringer types to individual Contacts entries, types of calls, and types of messages.

- **Preprogrammed Ringers** include a variety of standard ringer types and familiar music.
- **Vibrating Ringer** alerts you to calls or messages without disturbing others.
- **Downloaded Ringers** can be downloaded right to your phone. (See “Downloading Premium Services Content” on page 208 and “Ringers” on page 212.)

Selecting Ringer Types for Voice Calls

Your PCS Vision Phone provides a variety of ringer options that allow you to customize your ringer and volume settings. These options allow you to identify incoming calls by the ringer.

To select a ringer type for voice calls:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Sounds** and press .
4. Select **Ringer Type** and press .
5. Select **Voice Calls** and press .
6. Select the menu under **With Caller ID** or **No Caller ID** and press .
7. Select your desired ringer type and press 
 - **Ringer Type** to select a ringer type. Scroll through available ringers to hear previews.
 - **Ringer & Voice** to notify you with Ringer & Voice for voice calls.
 - **Vibrate** to notify you by vibrating.
 - **Get New** to start up the browser so you can select an item to download (see page 115).

To select a distinctive ringer for voice calls while roaming:

1. Follow steps 1-5 on the previous page.
2. Select the menu under **Roaming** and press .
3. Select **Distinctive** and press .
 - To confirm the ringer, press **Play** (right softkey).
 - If you want to deactivate this feature, select **Normal** during step 3 above.

Selecting Ringer Types for PCS Ready Link Calls

To select a ringer type for PCS Ready Link calls:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Sounds** and press .
4. Select **Ringer Type** and press .
5. Select **Ready Link Calls** and press .
6. Select the menu under **Ready Link Calls** and press .
7. Select your desired ringer type and press .
 - **Ringer Type** to select a ringer type. Scroll through available ringers to hear previews.

Selecting Ringer Types for Missed PCS Ready Link Calls

To select a ringer type for Missed PCS Ready Link calls:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Sounds** and press .
4. Select **Ringer Type** and press .
5. Select **R-Link Missed** and press .
6. Select the menu under **R-Link Missed** and press .
7. Select your desired ringer type and press .
 - **Ringer Type** to select a ringer type. Scroll through available ringers to hear previews.
 - **Vibrate** to notify you by vibrating.

Selecting Ringer Types for Voicemail

To select a ringer type for voicemail:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Sounds** and press .
4. Select **Ringer Type** and press .
5. Select **Voicemail** and press .
6. Select the menu under **Voicemail** and press .
7. Select your desired ringer type and press .
 - **Ringer Type** to select a ringer type. Scroll through available ringers to hear previews.
 - **Voice Ringer** to notify you with Voice for voicemail.
 - **Vibrate** to notify you by vibrating.
 - **Get New** to start up the browser so you can select an item to download (see page 115).

Selecting Ringer Types for Messages

To select a ringer type for messages:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Sounds** and press .
4. Select **Ringer Type** and press .
5. Select **Messaging** and press .
6. Select the menu under **Messaging** and press .
7. Select your desired ringer type and press .
 - **Ringer Type** to select a ringer type. Scroll through available ringers to hear previews.
 - **Voice Ringer** to notify you with Voice for Messages.
 - **Vibrate** to notify you by vibrating.
 - **Get New** to start up the browser so you can select an item to download (see page 115).

Selecting Ringer Types for Calendar

To select a ringer type for calendar:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Sounds** and press .
4. Select **Ringer Type** and press .
5. Select **Calendar** and press .
6. Select the menu under **Calendar** and press .
7. Select your desired type and press .
 - **Ringer Type** to select a ringer type. Scroll through available ringers to hear previews.
 - **Voice Ringer** to notify you with Voice for calendar events.
 - **Vibrate** to notify you by vibrating.
 - **Get New** to start up the browser so you can select an item to download (see page 115).

Selecting a Tone Length

Longer tone lengths may be better for tone recognition when dialing voicemail or other automated systems.

To select a tone length:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Sounds** and press .
4. Select **Others** and press .
5. Select the menu under **Tone Length** and press .
6. Select **Short** or **Long** and press .

Setting a Start-up/Power-off Tone

1. Follow steps 1-4 in “Selecting a Tone Length.”
2. Select the menu under **Start-up Tone** or **Power-off Tone** and press .
3. Select your desired tone and press .
- **Tone** to select a tone. Scroll through available tones to hear previews.
- **Get New** to start up the browser so you can select a tone to download (see page 115).

Tip: You can set the volume of Start-up Tone and Power-off Tone. See next page.

Using Voice Prompt

This feature allows you to hear voice prompts at Voice Memo, Screen Call setting, Voice Dial, etc. (default setting is On).

To deactivate this feature:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Sounds** and press .
4. Select **Others** and press .
5. Select the menu under **Voice Prompt** and press .
6. Select **Off** and press .

Tip: When ringer volume is set to “Silence All,” voice prompts cannot be heard.

Adjusting the Phone's Volume Settings

You can adjust your phone's volume settings to suit your needs and your environment.

To adjust the ringer, start-up/power-off, or key beep volume:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Sounds** and press .
4. Select **Ringer/Key Vol.** and press .
5. Select the item you wish to change and press 
 - **Ringer Volume** to adjust Ringer tone volume.
 - **Start-up/Pw-off** to adjust Start-up/Power-off tone volume.
 - **Key Beep** to adjust Key Beep tone volume.
6. Adjust a volume level by pressing the navigation key up or down and press 
 - **Ringer Off** to set the Voice Call ringer volume to off. (Only appears in Ringer Volume setting.)
 - **Silence All** to set all the ringer volumes settings to off. (Only appears in Ringer Volume setting. See "Silence All" on page 43.)

To adjust the earpiece or speaker volume:

1. Follow steps 1-3 above.
2. Select **Receiver Vol.** and press .
3. Select either **Earpiece** or **Speaker** and press .
4. Adjust a volume level by pressing the navigation key up or down and press .

Tip: You can adjust the ringer volume in standby mode (or the earpiece volume during a call) by using the Side Volume key.

Alert Notification

Your PCS Phone can alert you with an audible tone when you change service areas, once a minute during a voice call, for incoming or missed PCS Ready Link calls, or when a call has been connected.

- **Service** sets alert on or off for network services parameter changes.
- **Ready Link Calls** sets an alert to notify you of PCS Ready Link calls.
- **R-Link Missed** sets an alert to notify you of missed PCS Ready Link calls.
- **Voicemail** sets an alert to notify you of voice messages.
- **Messaging** sets an alert to notify you of text messages.
- **Minute Beep** sets a minute reminder that beeps ten seconds before the end of each minute during a call.
- **Signal Fade** sets an alert to notify you when your phone loses a signal during a call.

To set alerts:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Sounds** and press .
4. Select **Alerts** and press .
5. Select your desired option and press .
6. If you selected **Service**, **Minute Beep**, or **Signal Fade**, select **On** and press . If you selected **Ready Link Calls**, **R-Link Missed**, **Voicemail**, or **Messaging**, select **Once** or **Repeat Alert** and press .
 - To deactivate this feature, select **Off** during step 6 above.

Tip: **Repeat Alert** sounds an alert every two minutes for twenty minutes.

Tip: To set alerts for PCS Ready Link calls, see “Setting an Alert Notification for PCS Ready Link Calls” on page 150 for details.

Silence All

There may be times when you need to silence your phone entirely. The phone's Silence All option allows you to mute all sounds without turning your phone off.

To activate Silence All:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Sounds** and press .
4. Select **Ringer/Key Vol.** and press .
5. Select **Ringer Volume** and press .
6. Press the navigation key down until **Silence All** appears on the display and press .

Tip: When Ringer Volume is set as Silence All, other items are changed to Off and cannot be highlighted.

To deactivate Silence All:

- ▶ Press the volume key up repeatedly to select a desired volume level.

Display Settings

Changing the Text Greeting

The text greeting can be up to fifteen characters and is displayed on your phone's screen in standby mode. You may choose to display a custom greeting or you may display "Sprint" on the phone's screen.

To display or change your custom greeting:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Display** and press .
4. Select **Greeting** and press .
5. Select **Custom** and press 
 - You can customize the greeting by entering a personalized greeting. (See "Entering Text" on page 31.)
6. Press .

To display the default greeting ("Sprint"):

1. Follow steps 1-4 above.
2. Select **Default** and press 
 - When you are in PCS Ready Link mode, "Ready Link" appears on the display instead of "Sprint."

Changing the Backlight Time Length

The backlight setting lets you select how long the display screen and keypad are backlit after any key press is made.

To change the Main LCD or Sub LCD backlight setting:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Display** and press .
4. Select **Backlight** and press .
5. Select **Main LCD** or **Sub LCD** and press .
6. Select **Always On**, **Always Off**, or your defined time length and press .
 - **Always Off** always turns the backlight off.
 - **Always On** keeps the backlight on indefinitely.

Note: The **Always On** setting returns to the previous value the next time you turn on the phone.

To change the Keypad backlight setting:

1. Select **Key** during step 5 above, and press .
2. Select **Always Off** or your defined time length and press .

Note: Long backlight settings affect the battery's talk and standby times.

Changing the Display Screen Animation

Your new PCS Vision Phone offers options for what you see on the display screen during various phone functions.

To change the display animation:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Display** and press .
4. Select **Animation** and press .
5. Select **Standby**, **Outgoing Calls**, or **Service Search**, and press .
6. Select the menu under the item and press .
7. Select your desired option and press 
 - Press **Preview** (right softkey) to see a sample display.
 - For standby, you will also set the animation starting time. Select the option under **after** and press , then highlight your desired setting time and press .
 - **Get New** to start up the browser so you can select an item to download (see page 116).
 - To deactivate this feature, select **Off** during step 7 above.

Changing the Display for Incoming Calls

You can set the color or downloaded image to be shown on the Incoming Calls display.

To set your incoming calls display:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Display** and press .
4. Select **Incoming Calls** and press .
5. Select the menu under **Incoming Calls** and press .
6. Select your desired color or downloaded image and press .
 - **Preset** to select the pre-programmed color image.
 - **Off** to turn the image type off.
 - **Downloads** to set a downloaded image saved in your phone.
 - **Get New** to start up the browser so you can select an item to download (see page 116).
 - **In Camera** to set a picture saved in your In Camera folder.
 - **Saved to Ph.** to set a picture saved in your Saved to Phone folder.
 - Press **Preview** (right softkey) during step 6 above to see an example display. Press the right softkey to switch between Main/Sub LCD's display preview.

Changing the Display for Area Name

This feature enables you to show the area of the phone number you are calling or are called from when the number is not registered in your Contacts list. For example, a call to or from 213-555-5555 will display “California.”

To set your area name display:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Display** and press .
4. Select **Match Area Code** and press .
5. Select **On** or **Off** and press .
 - This feature is available only when the phone number is 10 digits, or 11 digits beginning with 1 and matches an area code.
 - The area name will not be displayed for numbers in your Contacts list or for incoming calls when an Animation Ringer is assigned.

Changing the Display for Standby Mode

This feature enables you to select a variety of items to display in standby mode.

To set your standby display:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Display** and press .
4. Select **Standby Display** and press .
5. Select your desired item and press .
 - **Screen Saver** selects the screen saver to display.
 - **Calendar** displays the Calendar.
 - **Digital Clock** displays the local time in digital view.
 - **Analog Clock** displays the local time in analog view.
 - **World Clock** displays the time of the selected city or country along with the local time. You can scroll the World Clock list by pressing the navigation key right or left. Press **Summer** (left softkey) or **Standard** (right softkey) to change between Daylight Savings and standard time if applicable. (The “” icon indicates Daylight Savings time.)

Tip: You can also display the World Clock from Tools/Extras menu. (See “Using the World Clock” on page 112.)

- **Default** returns the standby display to its default setting.
6. Press  to save the setting to follow each system prompt or when confirming the preview display.

Tip: In an area without service, Screen Saver, Calendar, Digital Clock, Analog Clock, or World Clock cannot be shown on the standby display.

Changing the Screen Saver

Your new PCS Phone offers you the option of displaying a screen saver while in standby mode.

To assign a screen saver:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Display** and press .
4. Select **Standby Display** and press .
5. Select **Screen Saver** and press .
6. Select the menu under **Screen Saver** and press .
7. Select your desired screen saver and press 
 - **Preset** to select a pre-installed screen saver.
 - **Downloads** to set a downloaded image saved in your phone.
 - **Get New** to start up the browser so you can select an item to download (see page 116).
 - **In Camera** to set a picture saved in your In Camera folder.
 - **Saved to Ph.** to set a picture saved in your Saved to Phone folder.
8. Press **Save** (left softkey) to save the screen saver.
 - To see a display preview of an image, press **Preview** (right softkey) during step 7 above. Press the right softkey to switch between Main/Sub LCD's display preview.

Changing the Display for My Buddy

This feature enables you to see a funny animation for 30 seconds on the Main LCD by opening the flip.

To activate or deactivate My Buddy:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Display** and press .
4. Select **My Buddy** and press .
5. Select **On** or **Off** and press .
 - Press **Preview** (right softkey) during step 5 above to see a display preview. Press the right softkey to switch between Main/Sub LCD's display preview.
 - Press **Info** (left softkey) to see My Buddy information.

Changing the Background

You can customize your phone display's appearance by selecting a color scheme to reflect your personality.

To change the display's background:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Display** and press .
4. Select **Background** and press .
5. Select **Main LCD** or **Sub LCD** and press .
6. Select your desired color and press .

Changing the Font Size

You can change the font size settings for the message notification and browser.

To change the font size:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Display** and press .
4. Select **Font Size** and press .
5. Select either **Message** or **Browser** and press .
6. Select your desired font size.
 - Press **Preview** (right softkey) to display a font size example.
7. Press  to set the selected font.

Tip: From the font example display, select your desired font size by pressing the navigation key right or left.

Location Settings

Your PCS Vision Phone is equipped with a Location feature for use in connection with location-based services that may be available in the future.

The Location feature allows the network to detect your position. Turning Location off will hide your location from everyone except 911.

Note: Even if the Location feature is enabled, no service may use your location without your express permission.

To enable your phone's Location feature:

1. Press  to access the main menu.
 2. Select **Settings** and press .
 3. Select **Location** and press .
 4. You will see a message on the display. Press  or **OK** (left softkey) to continue.
 - Press the navigation key down to read the whole message.
 5. Select **On** and press .
- To deactivate this feature, select **Off** during step 5 above.

When the Location feature is on, your phone's standby screen will display the  icon. When Location is turned off, the  icon will display.

Airplane Mode

Airplane Mode allows you to use many of your phone's features, such as Games, Voice Memos, etc., when you are in an airplane or in any other area where making or receiving calls or data is prohibited. When your phone is in Airplane Mode, it cannot send or receive any calls or access online information.

To set your phone to Airplane Mode:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Others** and press .
4. Select **Airplane Mode** and press .
5. You will see a message on the display. Press  or **OK** (left softkey) to continue.
 - Press **Cancel** (right softkey) to return to previous menu.
6. Select **On** and press .

While in Airplane Mode, your phone's standby screen will display "Phone Off."



TTY Use With PCS Service From Sprint

A TTY (also known as a TDD or Text Telephone) is a telecommunications device that allows people who are deaf or hard of hearing, or who have speech or language disabilities, to communicate by telephone.

Your phone is compatible with select TTY devices. Please check with the manufacturer of your TTY device to ensure that it supports digital wireless transmission. Your phone and TTY device will connect via a special cable that plugs into your phone's headset jack. If this cable was not provided with your TTY device, contact your TTY device manufacturer to purchase the connector cable.

When establishing your PCS Service, please call PCS Customer Solutions via the state Telecommunications Relay Service (TRS) by first dialing **7 1 1 TALK**. Then provide the state TRS with this number: 866-727-4889.

To turn TTY mode on or off:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Others** and press .
4. Select **TTY** and press . (You will see a message on the display.)
5. Press  or **OK** (left softkey) to continue.
6. Select **Enable** or **Disable** and press .

Note: When you connect TTY devices, your phone will display  in TTY mode. If TTY mode is enabled, the audio quality of non-TTY devices connected to the headset jack may be impaired.

IMPORTANT NOTICE: 911 Emergency Calling

Sprint recommends that TTY users make Emergency calls by other means, including Telecommunications Relay Services (TRS), analog cellular, and landline communications. Wireless TTY calls to 911 may be corrupted when received by public safety answering points (PSAPs) rendering some communications unintelligible. The problem encountered appears related to TTY equipment or software used by PSAPs. This matter has been brought to the attention of the FCC, and the wireless industry and PSAP community are currently working to resolve this.

Phone Setup Options

Shortcut

Your phone offers you the option of assigning a shortcut key to a favorite or often-used function. Pressing the navigation key to the left in standby mode will launch your personally designated shortcut.

To assign your shortcut key:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Others** and press .
4. Select **My Shortcut** and press .
5. Select the menu under **My Shortcut** and press .
6. Select your desired menu option and press .
 - Press **Info** (right softkey) during step 5 above to see an information screen.

Auto Answer Mode

You may set your phone to automatically pick up incoming calls when connected to an optional hands-free car kit and headset (sold separately).

To set Auto Answer mode:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Others** and press .
4. Select **Auto Answer** and press .
5. Select **Car Kit/Headset** or **Speaker Phone** and press .
6. Select either **5 Seconds** or **15 Seconds** and press .
 - To deactivate this feature, select **Off** during step 6 above.

Setting the Open/Close Flip Option

This feature enables you to answer an incoming call by opening the flip or to end a call by closing the flip.

To activate the Open Flip feature:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Others** and press .
4. Select **Open/Close Flip** and press .
5. Select **Open** and press .
6. Select **Answer Call** and press .
 - To deactivate this feature, select **No Action** during step 6.

To activate the Close Flip feature:

1. Follow steps 1-4 above.
2. Select **Close** and press . (You will see a message on the display.)
3. Press **OK** (left softkey) to continue.
4. Select **End Call** and press .
 - To deactivate this feature, select **Mute** during step 4.

Note: This feature does not apply when you are using the speakerphone, a headset, or a car kit.

Setting Any Key Answer

This feature allows you to answer incoming calls by pressing any key (except **END/⓪**, **BACK**, **MENU OK**, **|||||**, **◀||▶**, **●||**, Side Camera Key, Softkey [right], or Navigation Key).

To activate this feature:

1. Press **MENU OK** to access the main menu.
2. Select **Settings** and press **MENU OK**.
3. Select **Others** and press **MENU OK**.
4. Select **Any Key Answer** and press **MENU OK**.
5. Select **On** and press **MENU OK**.
 - To deactivate this feature, select **Off** during step 5 above.

Setting the Side Key Guard

This feature enables you to lock your side keys (Ready Link [Memo] button, Side Volume key, Side Call key, and Side Camera key) while the flip is closed.

To activate this feature:

1. Press **MENU OK** to access the main menu.
2. Select **Settings** and press **MENU OK**.
3. Select **Others** and press **MENU OK**.
4. Select **Side Key Guard** and press **MENU OK**.
5. Select **On** and press **MENU OK**.
 - **Key Guard** appears on the Sub LCD when you press any side key while the flip is closed.
 - To deactivate this feature, select **Off** during step 5 above.

Note: This feature does not apply when the flip is open.

Setting Abbreviated Dialing

Abbreviated Dialing is another form of speed dialing. It allows you to dial a number by entering just the last four digits of any number in your Contacts Directory. If the last four digits you enter do not match any stored Contacts entry, the digits are automatically prepended with the area code and prefix you specify.

To activate this feature:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Others** and press .
4. Select **Abbrev. Dial** and press .
5. Select **Enable** and press .
6. Enter a six-digit number (area code and prefix) and press  or **OK** (left softkey).
 - To deactivate this feature, highlight **Disable** during step 5 above.

Tip: If you enter fewer than 6 digits, the display shows a warning message. (See "Using Abbreviated Dialing" on page 30.)

Headset Mode

This feature allows you hands-free phone use. Set the headset mode to Voice Call or Ready Link and press the Turbo Button (the operation button) on the headset to activate useful functions.

To set headset mode:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Others** and press .
4. Select **Headset Mode** and press .
5. Select **Voice Call** or **Ready Link** and press .
 - Press **Info** (right softkey) during step 5 above to see the Headset Mode information screen.
 - To deactivate this feature, select **Off** during step 5 above.

Using the phone with headset mode activated:

- **Voice Call:** Press the Turbo Button to activate Voice dial. Press twice to redial the last call. Press and hold the button to record a Voice Memo.
- **Ready Link:** Press and hold the Turbo Button to redial the last PCS Ready Link call.

Note: If your headset doesn't have a Turbo Button, set headset mode to Off.

Sleep Mode

This feature helps conserve your battery power by restricting the display.

To set sleep mode:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Display** and press .
4. Select **Sleep Mode** and press .
5. Select **Main LCD** or **Sub LCD** and press .
6. Select your desired option and press .
 - To deactivate this feature, highlight **Off** during step 6 above.

Setting Message Notification

You can see a pop-up message notification when you receive a text message or Voicemail while you are in PCS Vision applications, browser mode, or Voice Calls.

To set message notification:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Messaging** and press .
4. Select **Display Pop-up** and press .
5. Highlight the box and press  to check/uncheck the box next to **Games/Apps**, **Browser**, or **Voice Calls**.
6. Press **Save** (left softkey).
 - Press **Info** (right softkey) during step 5 above to see the Messages information.

Editing Preset Messages

Your phone can store pre-set messages for use with text messaging and Picture Mail. You can edit your phone's default preset messages through the Settings menu. (For more information on using preset messages, see page 195.)

To edit your phone's preset messages:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Messaging** and press .
4. Select **Preset Msgs** and press .
5. Select the message you want to edit and press .
6. Use your keypad to edit the message and press **OK** (left softkey) or  to save your changes. ("Preset Msg Saved" will display).
 - To reset all messages, press **Options** (right softkey), select **Reset All Msgs**, and press  during step 5 above.

Note: For information on editing text, see "Entering Text" on page 31.

Setting a Callback Number

With this feature, you can notify your recipients of your callback number with the text message.

To set the callback number:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Messaging** and press .
4. Select **Send Callback#** and press .
5. Select an option from the following and press .
 - **None** to send no callback number.
 - **My Phone#** to send your phone number.
 - **Other** to send a specific callback number. To set a number, enter a phone number and press .

Setting the Current Time

To set the current time when you are roaming in an area with no digital network:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Others** and press .
4. Select **Set Time/Date** and press .
5. Set the current time and date and press .

Note: This feature is only available when you are in an area with no digital network available.

Display Language

You can choose to display your PCS Phone's onscreen menus in English or in Spanish.

To assign a language for the phone's display:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Others** and press .
4. Select **Language** and press .
5. Select **English** or **Español** and press .

Using the Mini Flashlight

This function allows you to use the phone's camera flash as a miniature flashlight. To use this function, your phone must be in standby mode with the Side Key Guard unlocked. (See page 58 for unlocking the Side Key Guard.)

To use the mini flashlight:

- ▶ With the phone closed and in standby mode, press and hold the Side Volume key (). (The light flashes for 8 seconds.)

Note: This function doesn't apply when a Missed Call or Notification is displayed.

Setting Your Phone's Security

In This Section

- ◆ **Accessing the Security Menu**
 - ◆ **Using Your Phone's Lock Feature**
 - ◆ **Restricting Calls**
 - ◆ **Using Special Numbers**
 - ◆ **Erasing the Contacts Directory**
 - ◆ **Erasing All Downloads**
 - ◆ **Resetting Your Pictures Account**
 - ◆ **Resetting Your Phone**
 - ◆ **Resetting and Locking Your Phone Through SMS**
 - ◆ **Security Features for PCS VisionSM**
-

By using the security settings on your PCS Vision Phone, you receive peace of mind without sacrificing flexibility. This section will familiarize you with your phone's security settings. With several options available, you can customize your phone to meet your personal needs.

Accessing the Security Menu

All of your phone's security settings are available through the Security menu. You must enter your lock code to view the Security menu.

To access the Security menu:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Security** and press .
4. Enter your lock code. (The Security menu is displayed.)

Tip: If you can't recall your lock code, try using the last four digits of either your Social Security number or PCS Phone Number or try 0000. If none of these work, call PCS Customer Solutions at 1-888-211-4PCS (4727).

Using Your Phone's Lock Feature

Locking Your Phone

When your phone is locked, you can only receive incoming calls or make calls to 911, PCS Customer Solutions, or special numbers.

To lock your phone:

1. From the Security menu (see “Accessing the Security Menu” on the previous page), select **Lock Phone** and press .
2. Highlight **Lock Now** or **On Power-up** and press .
3. Depending on your preference, highlight either **Full Lock** or **Excp. Incom.Calls** and press .
 - **Full Lock:** No phone calls can be made, except for Emergency number,   (PCS Customer Solutions), or special numbers. No phone calls can be received except for special numbers.
 - **Excp. Incom.Calls:** No phone calls can be made, except for Emergency number,   (PCS Customer Solutions), or special numbers, but all incoming calls can be received.

Tip: If you want to cancel the “On Power-up” setting before turning the phone off, select **Unlocked** during step 2 above.

Unlocking Your Phone

To unlock your phone:

1. Press **Unlock** (left softkey).
2. Enter your lock code. (Your phone will unlock and return to standby mode.)

Locking the Pictures Menu

With this feature, you must enter your lock code when you access the Pictures menu.

To lock the Pictures menu:

1. From the Security Menu (see “Accessing the Security Menu” on page 65), select **Lock Picture** and press .
2. Select **Lock Now** and press 
 - To deactivate this feature, select **Unlocked** during step 2 above.

Changing the Lock Code

To change your lock code:

1. From the Security Menu display (see “Accessing the Security Menu” on page 65), select **Others** and press .
2. Select **Change Lock** and press .
3. Enter a new lock code, (“1234” for example) under **New Code**.
4. Reenter the new code under **Reenter Code**.

Calling in Lock Mode

You can place calls to 911, PCS Customer Solutions, and to your special numbers when in lock mode. (For information on special numbers, see “Using Special Numbers” on page 69.)

To place an outgoing call in lock mode:

- ▶ To call an Emergency number, special number, or PCS Customer Solutions, enter the phone number and press .

Restricting Calls

There may be occasions when you want to limit the numbers your phone can call or from which it can receive calls. You can use the Restrict Calls setting to do just that. (The Restrict Calls setting does not apply to 911 or PCS Customer Solutions.)

To restrict calls:

1. From the Security Menu display (see “Accessing the Security Menu” on page 65), select **Others** and press .
2. Select **Limit Use** and press .
3. Select **Outgoing Calls** or **Incoming Calls** and press .
4. Select your desired option and press 
 - **Allow All** lets you make or receive all calls.
 - **Phone Book Only** lets you make or receive calls to or from Contacts entries, Voicemail, or special numbers only.
 - **Special #s Only** lets you make or receive calls to or from three special numbers only. (See “Using Special Numbers” on the next page.)

Note: Restricted incoming calls are forwarded to voicemail.

Using Special Numbers

Special numbers are important numbers that you have designated as being “always available.” You can call and receive calls from special numbers even if your phone is locked.

You can save 3 special numbers in addition to your Contacts entries (the same number may be in both directories).

To add or replace a special number:

1. From the Security Menu display (see “Accessing the Security Menu” on page 65), select **Others** and press .
2. Select **Special #s** and press .
3. Select the box under an entry number and press .
4. Enter your desired phone number and press 
– or –
Press **Options** (right softkey), select **From Phone Book** or **Voicemail**, and press .
5. When you have finished entering or changing your special numbers, press **Done** (left softkey).

To insert pauses into a special number:

1. From step 4 above, enter the phone number and press **Options** (right softkey) for the options.
2. Highlight **Hard Pause**, **2-Sec. Pause**, or **Hyphen** and press .
3. Finish entering the rest of the numbers and press .

Erasing the Contacts Directory

You can quickly and easily erase all of the contents of your Contacts Directory.

To erase all the names and phone numbers in your Contacts Directory:

1. From the Security Menu display (see “Accessing the Security Menu” on page 65), select **Erase Ph. Book** and press .
2. If you’re sure you want to erase your Contacts, select **Yes** and press .

Erasing All Downloads

To erase all data downloaded from the Web:

1. From the Security Menu display (see “Accessing the Security Menu” on page 65), select **Erase Download** and press .
2. If you're sure you want to erase all data downloaded from the Web, select **Yes** and press .
 - If you have assigned downloaded data, the function returns to its default setting.

Resetting Your Pictures Account

This option resets your authentication ID for your PCS Vision pictures account.

To reset your pictures account:

1. From the Security Menu display (see “Accessing the Security Menu” on page 65), select **Reset Pictures** and press .
2. If you're sure you want to reset your pictures account, select **Yes** and press .

After resetting, you are prompted to reenter the password when you use Online Pictures.

Note: Your account will be locked if you enter wrong password 10 times after resetting your account. In this case, please contact Sprint PCS Customer Solutions.

Resetting Your Phone

Resetting the phone restores all the factory defaults, including the ringer types and display settings. The Contacts, Call History, Scheduler, and Messaging are not affected.

To reset your phone:

1. From the Security Menu display (see “Accessing the Security Menu” on page 65), select **Reset Phone** and press .
2. If you're sure you want to reset your phone, select **Yes** and press .

Resetting and Locking Your Phone Through SMS

When your phone is lost or stolen, you can erase your important personal information (such as Contacts entries, call history, and messages) and lock your phone by sending a special formatted SMS message to your phone.

From your computer, sign on to www.sprintpcs.com and send a message to your phone (input your 10-digit PCS Phone Number followed by “@messaging.sprintpcs.com.”) in the following format:

\\RESET **<Passcode>** RESET

<Passcode> – your defined passcode.

The default passcode is your phone’s 11-digit ESN (Electronic Serial Number), which is written on the package or on the phone itself.

The locked phone will display the following message:

“If found, please call PCS Customer Solutions 1-888-211-4727.”

To activate this feature, the following presetting is required:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Security** and press .
4. Enter your lock code.
5. Select **Others** and press .
6. Select **Found Me** and press .
7. Select **Reset/Lock** and press .
8. Select **Enable** and press .

To unlock a phone that has been locked through SMS, bring the phone to a Sprint Store.

Changing the Passcode

To change the passcode for the special formatted SMS messages:

1. Follow steps 1-6 above.
2. Select **Chg Passcode** and press .
3. Enter new passcode in the box under **New Passcode** (11 digits).
4. Reenter the new passcode in the box under **Reenter Code**.

Security Features for PCS VisionSM

Enabling and Disabling PCS Vision Services

You can disable PCS Vision services without turning off your phone; however, you will not have access to all PCS Vision services, including Web and messaging. Disabling PCS Vision will avoid any charges associated with PCS Vision services. While signed out, you can still place or receive phone calls, check voicemail, and use other voice services. You may enable PCS Vision services again at any time.

To disable PCS Vision services:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **PCS Vision** and press .
4. Select **Disable Vision** and press . (A message will appear.)
5. Press **Disable** (right softkey) to confirm that you want to sign out.

To enable PCS Vision services:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **PCS Vision** and press .
4. Select **Enable Vision** and press .
5. Press **OK** (left softkey) to sign in.

Controlling Your Roaming Experience

In This Section

- ◆ **Understanding Roaming**
 - ◆ **Setting Your Phone's Roam Mode**
 - ◆ **Controlling Roaming Charges Using Call Guard**
-

Roaming is the ability to make or receive calls when you're off the Sprint Nationwide PCS Network. Your new dual-band/tri-mode PCS Vision Phone works anywhere on the Sprint Nationwide PCS Network and allows you to roam on other analog and 1900 and 800 MHz digital networks where we've implemented roaming agreements with other carriers.

This section explains how roaming works as well as special features that let you manage your roaming experience.

Understanding Roaming

Recognizing Icons on the Display Screen

Your phone's display screen always lets you know when you're off the Sprint Nationwide PCS Network and whether your phone is operating in analog or digital mode. The following chart indicates what you'll see depending on where you're using your phone.

Main LCD/Sub LCD	Roaming Indicator	Analog Indicator
Sprint Nationwide PCS Network		
Other Digital Networks		
Analog Networks		

Tip: Remember, when you are using your phone off the Sprint Nationwide PCS Network, always dial numbers using 11 digits (1 + area code + number).

Note: Unless your PCS Service Plan includes roaming, you will pay a higher per-minute rate for roaming calls.

Roaming on Other Digital Networks

When you're roaming on digital networks, your call quality and security will be similar to the quality you receive when making calls on the Sprint Nationwide PCS Network. However, you may not be able to access certain features, such as PCS Vision.

Note: PCS Ready Link Service is not available in roaming areas.

Roaming on Analog Networks

When you roam on analog networks, you will experience a similar quality provided by other analog carriers today. Although some features, such as PCS Vision, PCS Ready Link, and PCS Voice Command, will be unavailable, you can still make and receive calls and access voicemail. If you are accustomed to PCS Service, you may notice some of the following differences when using analog service:

- You are more likely to experience static, cross-talk, fade-out, and dropped calls.
- Some features which are standard on the enhanced Sprint Nationwide PCS Network, such as call waiting, PCS Vision, PCS Ready Link, and direct international dialing, may not be available.
- Though callers can leave voicemail messages while you are roaming, you may not receive notification until you return to the Sprint Nationwide PCS Network. (See “Checking for Voicemail Messages While Roaming” on the next page).
- There are security and privacy risks (eavesdropping and cloning) that exist with conventional analog services today.
- Your battery’s charge will deplete more quickly and you will need to recharge it more often when you use your phone for analog roaming.

Note: If you’re on a call when you leave the Sprint Nationwide PCS Network and enter an area where roaming is available (whether digital or analog), your call is dropped. If your call is dropped in an area where you think PCS Service is available, turn your phone off and on again to reconnect to the Sprint Nationwide PCS Network.

Note: When using your phone in analog mode, the phone may feel warm. This is normal for analog operation.

Checking for Voicemail Messages While Roaming

When you are roaming off the Sprint Nationwide PCS Network, you may not receive on-phone notification of new voicemail messages. Callers can still leave messages, but you will need to periodically check your voicemail for new messages if you are in a roaming service area for an extended period of time.

To check your voicemail while roaming:

- ▶ Dial 1+area code+your PCS Phone Number.

When you return to the Sprint Nationwide PCS Network, voicemail notification will resume as normal.

Setting Your Phone's Roam Mode

Your PCS Vision Phone allows you to control your roaming capabilities. By using the **Roaming** menu option, you can determine which signals your phone accepts.

Set Mode

Choose from three different settings on your dual-band/tri-mode phone to control your roaming experience.

To set your phone's roam mode:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Roaming** and press .
4. Select **Set Mode** and press .
5. Select an option from the following, and press .
 - **Sprint** allows you to access the enhanced Sprint Nationwide PCS Network only and prevents roaming on other networks.
 - **Automatic** seeks PCS Service. When PCS Service is unavailable, the phone searches for an alternate system.
 - **Analog** forces the phone to seek an analog roaming system. The previous setting (Sprint or Automatic) is restored the next time the phone is turned on.

Controlling Roaming Charges Using Call Guard

Your phone has two ways of alerting you when you are roaming off the Sprint Nationwide PCS Network: the onscreen roaming icon and Call Guard. Call Guard makes it easy to manage your roaming charges by requiring an extra step before you can place or answer a roaming call. (This additional step is not required when you make or receive calls while on the Sprint Nationwide PCS Network.)

To turn Call Guard on or off:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Roaming** and press .
4. Select **Call Guard** and press .
5. Select **On** or **Off** and press .

To place roaming calls with Call Guard on:

1. From standby mode, dial 1 + area code + the seven-digit number. (You can also initiate a call from the Contacts directory, Call History, or Messaging.)
2. Press  or  (or press **Options** (right softkey) and highlight **Call** or **Call:Speaker On**) and press .
3. Press  to proceed while the pop-up message is displayed.
– or –
Press any key to erase the pop-up message, press **Options** (right softkey), highlight **Roam Call**, or **Roam:Speaker On**, and press .

To answer incoming roaming calls with Call Guard on:

- ▶ Press **Options** (right softkey), highlight **Answer** or **Answer:Speaker**, and press .
- or –
- 1. Press  or .
- 2. Press  to proceed while the pop-up message is displayed.

Reminder: If the Call Guard feature is set to **On**, you need to take extra steps to make and receive roaming calls, even if you have selected the **Analog** setting (see the previous page).

Navigating Through Menus

In This Section

- ◆ **Menu Navigation**
 - ◆ **Menu Structure**
 - ◆ **Viewing the Menus**
-

Every function and feature of your PM-8200 by Sanyo can be accessed through an onscreen menu. This section is a road map to using your PCS Vision Phone. Please take a few moments to learn your way around and you'll find your phone easier to use.

Menu Navigation

The navigation key on your PCS Vision Phone allows you to scroll through menus quickly and easily. The scroll bar at the right of the menu keeps track of your position in the menu at all times.

To navigate through a menu, simply press the navigation key up or down.

Menu Structure

Selecting Menu Items

As you navigate through the menu, menu options are highlighted. Select any numbered option by simply pressing the corresponding number on the phone's keypad. You may also select any item by highlighting it and pressing .

For example, if you want to view your last incoming call:

1. Press  to access the main menu.
2. Select **Call History** by pressing . (It may already be highlighted.)
3. Select **Incoming** by pressing  or by highlighting it and pressing . (If you have received any calls, they are displayed on the screen.)

Backing Up Within a Menu

To go to the previous menu:

- ▶ Press .

To return to standby mode:

- ▶ Press .

Shortcuts

Right navigation key to take a shortcut to the **Contacts** menu.

Left navigation key to take a shortcut to the **My Shortcut** menu.
(See page 56 for setting.)

Up navigation key to take a shortcut to the **Messaging** menu.

Down navigation key to take a shortcut to the **Downloads** menu.

Viewing the Menus

Menu Diagram

The following list outlines your phone's menu structure.

1. Call History

1. Outgoing
2. Incoming
3. Missed
4. Erase History

2. Contacts

1. Find/Add Entry
2. Speed Dial #s
3. My Phone#
4. Services

3. Messaging

1. Send Message
2. Picture Mail
3. Text Msg
4. Go to Email
5. Voicemail

4. Web

5. Pictures

1. Camera
2. My Pictures
3. Online Albums
4. Account Info

6. Downloads

1. Games
2. Ringers
3. Screen Savers
4. Applications
5. Dynamic 1-10 (If applicable)
6. Others

7. Settings

1. Sounds
 1. Ringer/Key Vol.
 2. Ringer Type
 3. Alerts
 4. Receiver Vol.
 5. Others
2. Display
 1. Backlight
 2. Greeting
 3. Font Size
 4. Background
 5. Animation
 6. Incoming Calls
 7. Match Area Code
 8. Standby Display
 9. My Buddy
 10. Sleep Mode
3. PCS Vision
 1. Enable (or Disable) Vision
 2. Net Guard
 3. Update Profile
4. Ready Link
 1. Enable/Disable
 2. List Update
 3. Restart R-Link
 4. R-Link Guard
 5. Ringer Type
 6. Alerts
 7. Speakerphone
 8. Default View
5. Location
6. Roaming
 1. Set Mode
 2. Call Guard
7. Messaging
 1. Display Pop-up
 2. Preset Msgs
 3. Send Callback#
8. Security
 1. Lock Phone
 2. Lock Picture
 3. Erase Ph. Book
 4. Erase Download
 5. Reset Pictures
 6. Reset Phone
 7. Others

9. Others
 1. Any Key Answer
 2. Auto Answer
 3. Open/Close Flip
 4. Abbrev. Dial
 5. Headset Mode
 6. TTY
 7. Side Key Guard
 8. My Shortcut
 9. Airplane Mode
 10. Set Time/Date
 11. Language
0. Phone Info
 1. Phone#/User ID
 2. Help
 3. Version
 4. Advanced

8. Tools/Extras

1. Calendar
2. Alarm Clock
3. Calculator
4. World Clock
5. PC Sync
 1. Ringers
 2. Images
 3. Erase Data

9. Voice Services

1. Voice Memo
 1. Record
 2. Play
 3. Play:Speaker
 4. Erase All
2. Screen Call
 1. Auto
 2. Announcement
3. Voice Dial
 1. Program
 2. Review
 3. Review:Speaker
 4. Erase All

Managing Call History

In This Section

- ◆ **Viewing History**
 - ◆ **Call History Options**
 - ◆ **Making a Call From Call History**
 - ◆ **Saving a Phone Number From Call History**
 - ◆ **Prepending a Phone Number From Call History**
 - ◆ **Erasing Call History**
-

The Call History keeps track of incoming calls, calls made from your PCS Vision Phone, and missed calls. This section guides you through accessing and making the most of your Call History.

Viewing History

You'll find the Call History feature very helpful. They are lists of the last 20 voice calls and the last 10 Ready Link calls that you placed, accepted, or missed. Call History makes redialing a number fast and easy. It is continually updated as new numbers are added to the beginning of the list and the oldest entries are removed from the bottom of the list.

Each entry contains the phone number (if it is available) and contact's name (if the phone number is in your Contacts). Duplicate calls (same number and type of call) may only appear once on the list.

To view a Call History entry:

1. Press  to access the main menu.
2. Select **Call History** and press .
3. Select **Outgoing**, **Incoming**, or **Missed** and press . (The selected Call History list will display.)

Tip: You can switch the Voice Call history to the PCS Ready Link call history by pressing **R-Link** (left softkey). To return to the Voice Call history, press **Voice Call** (left softkey).

Call History Options

For additional information and options on a particular call, highlight a Call History entry and press **Options** (right softkey).

- **Call** to dial the phone number.
- **Call:Speaker On** to dial the phone number in speakerphone mode.
- **Send Message** to send a text message. See page 195 for details.
To send Picture Mail, see page 162.
- **Save Phone#** to save the phone number (if applicable). If the caller's phone number is already saved in your Contacts list, **Go to Phone Book** appears. (See "Saving a Phone Number From Call History" on the next page.)
- **Prepend** to add numbers to the beginning of the phone number. (See "Prepending a Phone Number From Call History" on page 87.)
- **Copy to Personal** to copy the phone number to the Ready Link Personal List. (Only appears when PCS Ready Link mode is set to Enable and the number does not match any stored entry in your Personal List.)
- **Erase** to erase the entry.

Making a Call From Call History

To place a call from Call History:

1. Press  to access the main menu.
 2. Select **Call History** and press .
 3. Select **Outgoing**, **Incoming** or **Missed** and press .
 4. Highlight the entry you want to call by scrolling through the list.
 5. Press  or .
- or –
- Press **Options** (right softkey), highlight **Call** or **Call:Speaker On**, and press .

Note: You cannot make calls from Call History to entries identified as **No ID** or **Restricted**.

Saving a Phone Number From Call History

Your PCS Vision Phone can store up to 500 phone numbers in up to 300 Contacts entries (an entry may contain up to seven numbers). Each entry's name can contain sixteen characters.

To save a phone number from Call History:

1. Highlight the call history entry you want to save.
2. Press **Options** (right softkey) to display the options.
3. Highlight **Save Phone#** and press .
4. Highlight the appropriate label (Mobile, Home, Work, Pager, Fax, Other, or No Label) and press .
5. Enter a name and press .
If you have already stored entries in the Contacts list, you are prompted to select the following entry mode:
 - **New Name** to enter a name directly.
 - **From Ph. Book** to select a name from the Contacts list.
6. Press **Save** (left softkey).

After you have saved the number, the new Contacts entry is displayed. (See "Contacts List Entry Options" on page 92.)

Note: You cannot save phone numbers already in your Contacts list or from calls identified as **No ID** or **Restricted**. If the selected entry has already been stored in the Contacts list, **Go to Phone Book** appears during step 3 above.

Prepending a Phone Number From Call History

If you need to place a call from Call History and you happen to be outside your local area code, you can add the appropriate prefix by prepending the number.

To prepend a phone number from Call History:

1. Highlight a call history entry and press **Options** (right softkey).
2. Highlight **Prepend** and press .
3. Enter the digits you want to add to the number.
4. Press  or  to place a call.

To select another option, press **Options** (right softkey), highlight it and press .

- **Call** to dial the phone number.
- **Call:Speaker On** to dial the phone number in speakerphone mode.
- **Save Phone#** to store the phone number in your Contacts directory.
-  **Hard Pause** to insert a hard pause.
-  **2-Sec. Pause** to insert a 2-second pause.

Erasing Call History

To erase individual Call History entries, see “Call History Options” on page 85.

To erase Call History:

1. Press  to access the main menu.
2. Select **Call History** and press .
3. Select **Erase History** and press .
4. Select **Outgoing**, **Incoming**, **Missed**, or **All** and press .
5. Select **Voice Calls** or **Ready Link** and press 
 - **Voice Calls** to erase call history for voice calls.
 - **Ready Link** to erase call history for PCS Ready Link calls.
6. Select **Yes** and press .

Using the Contacts Directory

In This Section

- ◆ **Displaying the Contacts List**
 - ◆ **Adding a New Contacts Entry**
 - ◆ **Finding Contacts List Entries**
 - ◆ **Contacts List Entry Options**
 - ◆ **Adding a Phone Number to a Contacts Entry**
 - ◆ **Editing a Contacts Entry's Phone Number**
 - ◆ **Assigning Speed Dial Numbers**
 - ◆ **Editing a Contacts Entry**
 - ◆ **Selecting a Ringer/Image Type for an Entry**
 - ◆ **Secret Contacts Entries**
 - ◆ **Dialing PCS Services**
-

Now that you know the basics that make it easier to stay in touch with people and information, you're ready to explore your phone's more advanced features. This section explains how to use your phone's Contacts and helps you make the most of your contacts and time when you are trying to connect with the important people in your life.

Displaying the Contacts List

- ▶ Press the navigation key right.
 - or -
- 1. Press  to access the main menu.
- 2. Select **Contacts** and press .
- 3. Select **Find/Add Entry** and press .

Adding a New Contacts Entry

Your PCS Vision Phone can store up to 500 phone numbers in up to 300 Contacts entries (an entry may contain up to seven numbers). Each entry's name can contain sixteen characters.

To add a new entry:

1. Press  to access the main menu.
2. Select **Contacts** and press .
3. Select **Find/Add Entry** and press 
 - Press the navigation key right for the shortcut (steps 1 through 3).
4. Highlight **<Add Contact>** and press .
5. Enter a name and press .
6. Select a label by using your navigation key and press .
7. Enter the phone number or address and press .
8. Press **Save** (left softkey).
 - or -
1. Press the navigation key right to display the Contacts list.
2. Highlight an entry and press **Options** (right softkey).
3. Highlight **Add New Contact** and press .
4. Follow steps 5-8 above.

After you have saved the number, the new Contacts entry is displayed. (See "Contacts List Entry Options" on page 92.)

Tip: You can also add a new Contacts entry by entering a number from standby mode. See "Saving a Phone Number" on page 27.

Finding Contacts List Entries

There are several ways to display your Contacts entries: by name, by speed dial number, by group, and by voice dial tags. Follow the steps outlined in the sections below to display entries from the Contacts list menu.

Finding Names

To find Contacts list entries by name:

1. Press  to access the main menu.
2. Select **Contacts** and press .
3. Select **Find/Add Entry** and press 
 - Press the navigation key right for the shortcut (steps 1 through 3).
4. Use your navigation key to scroll through the Contacts list.
 - or –
 - Enter the first letter of the name or part of the name. (The display shows the entries beginning with the letter entered.)
5. Press  to display the entry's details.

To find PCS Ready Link List entries:

1. From standby mode, press the navigation key right to display your Contacts list.
2. Press **Go to** (left softkey). Highlight your desired list and press 
 - **Phone Book** to display the Contacts list.
 - **Company List** to display the Company List.
 - **Company Groups** to display the Company Group List.
 - **Personal List** to display the Personal List.
 - **Personal Groups** to display the Personal Group List.
3. Scroll through the list to select your desired entry.

Note: The **Go to** (left softkey) option does not appear when PCS Ready Link mode is set to Disable (see “Setting PCS Ready Link Mode” on page 133).

Finding Speed Dial Numbers

To find phone numbers you have stored in speed dial locations:

1. Press  to access the main menu.
2. Select **Contacts** and press .
3. Select **Speed Dial #s** and press . (The Speed Dial numbers list appears.)

Finding Voice Dial Numbers

To find phone numbers you have stored in Voice Dial:

1. Press  to access the main menu.
2. Select **Voice Services** and press .
3. Select **Voice Dial** and press .
4. Select **Review** or **Review:Speaker** and press . (The Voice Dial numbers list appears.)

Contacts List Entry Options

To access a contact's options, display the Contacts list, highlight an entry and press . Then select a phone number and press **Options** (right softkey). To select an option, highlight it and press .

- **Edit** to edit the selected entry.
- **Call** to dial the selected number.
- **Call:Speaker On** to dial the phone number in speakerphone mode.
- **Send Message** to send a text message. (See page 195 for details.)
To send Picture Mail, see page 162.
- **Call Alarm** to set a call alarm for the entry. (See page 104 for Call Alarm.)
- **Set Speed Dial** to assign speed dial numbers to your favorite entries. (See "Assigning Speed Dial Numbers" on page 94.)
- **Set Voice Dial** to set a voice dial for the entry. (See page 124 for Voice Dial.)
- **Prepend** to alter a phone number by adding numbers to the beginning of the entry. (See "Prepending a Phone Number From Call History" on page 87.)
- **Copy to Personal** to copy the phone number to your Ready Link Personal List. (Only appears when PCS Ready Link mode is set to Enable and the number does not match any stored entry in your Personal List.)

To erase the selected entry from the Contacts list:

1. From standby mode, press the navigation key right to display the Contacts list.
2. Highlight the entry you wish to delete by using the navigation key.
3. Press **Options** (right softkey).
4. Highlight **Erase Contact** and press .
5. Select **Yes** and press .

Adding a Phone Number to a Contacts Entry

To add a phone number to an entry:

1. Display a Contacts entry (see “Finding Contacts List Entries” on page 90).
2. Highlight a phone number, press **Options** (right softkey), highlight **Edit**, and press .
3. Highlight the label field you want to add and press .
4. Enter the number and press .
5. Press **Save** (left softkey).

Editing a Contacts Entry's Phone Number

To edit an entry's phone number:

1. Press the navigation key right.
2. Highlight the entry you wish to edit and press .
3. Highlight a phone number, press **Options** (right softkey), highlight **Edit**, and press .
4. Select the number you want to edit and press .
5. Edit the entry by using your keypad and press .
6. Press **Save** (left softkey) to save your changes.

Assigning Speed Dial Numbers

With this feature you can dial Contacts Directory entries with one key press for locations 2-9. Save your memory locations 2-9 for speed dialing your most commonly used phone numbers. Speed Dial numbers must be stored in your Contacts to use this feature.

To set Speed Dial:

1. Press  to access the main menu.
2. Select **Contacts** and press .
3. Select **Speed Dial #s** and press .
4. To select a corresponding speed dial number from 2-9, highlight an unassigned number and press .
5. Select an entry from the list and press .
6. Select the phone number you want to set as a speed dial and press .
- or -
1. Press the navigation key right.
2. Highlight your desired entry by scrolling through the Contacts list and press .
3. Highlight the phone number you want to set as a speed dial and press **Options** (right softkey).
4. Highlight **Set Speed Dial** and press .
5. Highlight an unassigned number and press .
- When you highlight an assigned number and press , you'll be asked whether you want to overwrite the assigned number. Select **Yes** to overwrite or **No** to cancel.

To cancel a stored speed dial number:

1. Press  to access the main menu.
2. Select **Contacts** and press .
3. Select **Speed Dial #s** and press .
4. Highlight the stored speed dial number you want to cancel and press .
5. Highlight **Unassign** and press .

To use Speed Dial:

- From standby mode, just press and hold the appropriate key.

Editing a Contacts Entry

To make changes to an entry:

1. Press the navigation key right.
2. Highlight the entry you wish to edit and press .
3. Highlight a phone number, press **Options** (right softkey), highlight **Edit**, and press .
– or –
Highlight an email address or Web address and press **Edit** (right softkey).
4. Select the field you want to edit and press .
5. Edit the entry by using your keypad and press .
6. Press **Save** (left softkey) to save your changes.

Selecting a Ringer/Image Type for an Entry

You can assign a ringer or an image type to a Contacts entry so you can identify the caller by the ringer or image type. (See “Ringer Types” on page 36.)

To select a ringer type for an entry:

1. Press the navigation key right.
2. Select the entry for which you want to set the incoming ringer and press .
3. Highlight a phone number, press **Options** (right softkey), highlight **Edit**, and press .
– or –
Highlight an email address or Web address and press **Edit** (right softkey).
4. Scroll to **Ringer** and press .
5. Use your navigation key to scroll through available ringers.
(When you highlight a ringer type, a sample ringer will sound.)

6. Highlight your desired ringer type and press .

- **Ringer Type** to select a ringer type. Scroll through available ringers to hear previews.
- **Ringer & Voice** to notify you with Ringer and Voice.
- **Vibrate** to notify you by vibrating.
- **Normal** to set Ringer to the incoming calls setting (see page 36).
- **None** to turn the ringer type off.
- **Downloads** to set a downloaded image saved in your phone.
- **Get New** to start up the browser so you can select an item to download.

7. Press **Save** (left softkey) to save the ringer type.

- To confirm the ringer, highlight **Ringer** and press **Play** (right softkey).

To select an image type for an entry:

1. Follow steps 1-3 on the previous page.

2. Scroll to **Picture ID** and press .

3. Select a menu by scrolling up or down and press .

4. Highlight your desired image type and press .

- **Normal** to set Image to the incoming calls setting (see page 47).
- **None** to turn the image type off.
- **Downloads** to set a downloaded image saved in your phone.
- **Get New** to start up the browser so you can select an item to download.
- **In Camera** to set a picture saved in your In Camera folder.
- **Saved to Ph.** to set a picture saved in your Saved to Phone folder.

5. Press **Save** (left softkey) to save the image type.

- To see a display preview of an image, press **Preview** (right softkey) during step 5 above. Press the right softkey to switch between Main/Sub LCD's display preview.

Note: If you set an animation ringer (indicated with  icon) and an image, your PCS Phone plays the ringer (audio) of the animation ringer and displays the image you selected.

Secret Contacts Entries

You can hide an entry's phone number(s) and require your lock code to edit the entry by making it secret. The entry name is still displayed, but the entry's phone numbers are replaced with "(Secret)".

To make an entry secret:

1. Press the navigation key right.
2. Scroll to the Contacts entry you want to tag secret.
3. Press **Options** (right softkey) to display the menu options.
4. Highlight **Set Secret** and press .
5. Enter the 4-digit lock code.
6. Select **On** and press .

To make an entry public:

1. Press the navigation key right.
2. Scroll to the Contacts entry you want to tag public.
3. Press **Options** (right softkey) to display the menu options.
4. Highlight **Set Secret** and press .
5. Enter the 4-digit lock code.
6. Select **Off** and press .

Tip: If you can't recall your lock code, try using the last four digits of either your Social Security number or your PCS Phone Number or try 0000.

If none of these work, call PCS Customer Solutions at 1-888-211-4PCS (4727).

Dialing PCS Services

Your Contacts list is preprogrammed with contact numbers for various PCS Services. You must be in digital mode to access PCS Services.

To dial a service:

1. Press  to access the main menu.
 2. Select **Contacts** and press .
 3. Select **Services** and press .
 4. Select **Cust Solutions**, **Dir Assistance**, **Account Info**, **Sprint Operator**, or **Voice Command** and press .
 5. Press  or .
- or –
- Press **Options** (right softkey), highlight **Call** or **Call:Speaker On**, and press .

Personal Organizer

In This Section

- ◆ **Managing the Scheduler**
 - ◆ **Using Your Phone's Scheduler**
 - ◆ **Adding a Call Alarm to the Scheduler**
 - ◆ **Adding To Do List Items**
 - ◆ **Purging All Events, Call Alarms, or To Do List Items**
 - ◆ **Personal Information Management**
 - ◆ **Using Your Phone's Tools**
 - ◆ **Downloading Files Through PCS Vision**
-

Your PCS Vision Phone is equipped with several personal information management features that help you manage your busy lifestyle.

This section shows you how to use these features to turn your phone into a time management planner that helps you keep up with your contacts, schedules, and commitments. It takes productivity to a whole new level.

Managing the Scheduler

Calendar

Use the Calendar to remind you of events or important calls you need to make. You can schedule up to 100 events, 15 Call Alarms, and 20 To-Do List items.

Setting the Time/Date

In a no-service area or an analog service area, it's necessary to set the actual time and date to use the Calendar function. Set the current Time/Date by using numeric keys and/or the navigation key (Right/Left: move cursor, Up/Down: change value). To display the time setting mode, press , select **Tools/Extras** and press . Then select **Calendar** and press .

You can set any time from 12:00 AM, Jan 1, 2000 to 11:59 PM, Dec 31, 2099.

Setting Holidays

You can set your personal holidays by displaying the date in red on the Calendar display. The default holidays displayed in red are Sundays and national holidays.

Note: You can set holidays from Jan 1, 2000 to Dec 31, 2020.

To set personal holidays:

1. Press  to access the main menu.
2. Select **Tools/Extras** and press .
3. Select **Calendar** and press .
4. Highlight the day you want to set to the holiday by using the navigation key (Left: previous day, Right: next day, Up: previous week, Down: next week,  : previous/next month).
5. Press **Options** (right softkey), highlight **Holiday**, and press .
6. Highlight **Set Date** or **Set Weekly** from the options and press .

Options:

- **Set Date** sets the selected date for the holiday.
 - **Set Weekly** sets weekly holidays.
 - **Reset Date** resets the holiday setting for the selected date.
 - **Reset Weekly** resets the weekly holiday setting.
 - **Reset All** resets all the holiday settings and returns to the default settings.
7. If you selected **Set Weekly**, **Reset Weekly**, or **Reset All**, you'll be prompted to select **Yes** or **No**.

Tip: The current day is framed by a rectangle.

Using Your Phone's Scheduler

Adding an Event to the Scheduler

Your Scheduler helps organize your time and reminds you of important events (up to 100 events).

To add an event:

1. Press  to access the main menu.
2. Select **Tools/Extras** and press .
3. Select **Calendar** and press .
4. Select the day you want to add an event to by using the navigation key and press .
5. Press **Options** (right softkey) to display the options.
6. Select **Add Event** and press .
7. Select **Schedule** and press .
8. Enter the description using your keypad, and press  (or press **Mode** [right softkey] to select a description from "From To Do List").

Note: The "From To Do List" option will not appear if there are no items stored in the To Do List. See "Adding To Do List Items" on page 107 for details.

9. Select the menu under the following options and press .

- **Description** to enter a description of your event (up to 14 characters).
- **From** to schedule the start time.
- **To** to schedule the end time.
- **Location** to edit the location of your event (up to 14 characters).
- **Alarm** to select your desired ringer.
- **Alarm Time** to edit the alarm time (number of hours or minutes before the event starts). Default alarm time is 10 minutes before.
- **Repeat** to set the event's repeating status. Select **None**, **Daily**, **Weekly**, **Monthly**, or **Yearly**.

10. Press **Save** (left softkey) to schedule the event.

Tip: The date you have scheduled events for is indicated by "►".

Tip: Press the navigation key up or down to scroll by week through the Scheduler calendar and the Side Volume key to scroll by month.

Event Alerts

There are several ways your PCS Vision Phone alerts you of scheduled events:

- By playing the alert tone (depending on the Ringer Type and Ringer Volume setting).
- By blinking the LED.
- By displaying the event's description on the Main LCD when the flip is open.
- By displaying the event's description on the Sub LCD when the flip is closed.
- By lighting the LCD backlight (depending on the backlight setting).

Event Alert Menu

When your phone is turned on and you have an event alarm scheduled, your phone alerts you and displays the event summary.

To respond to an event alert:

1. Press  or **View** (left softkey) to silence the alarm and see the event details.
2. Highlight the unchecked event and press  to see the event details or press **Options** (right softkey) for the following options. To select an option, highlight it and press .
 - **Snooze** to repeat the alarm in ten minutes.
 - **Exit** to exit the options.

Note: If you press **Exit** (left softkey) during step 2 above, you are prompted to erase the unchecked event. Select **Yes** to erase or **No** to cancel.

Viewing Events

To view your scheduled events:

1. Press  to access the main menu.
2. Select **Tools/Extras** and press .
3. Select **Calendar** and press .
4. Select the date for which you set events and press . (The selected day's events list will display.)

Erasing a Day's Events or Call Alarms

To erase a scheduled day's events or call alarms:

1. From the Event list display (see above), highlight one of the events or call alarms and press **Options** (right softkey).
2. Highlight **Erase Event** and press .
3. Select **Yes** and press .

Adding a Call Alarm to the Scheduler

You can set call alarms to notify you when you need to place a call. The call alarm will let you know when and to whom to place a scheduled call. You can set up to 15 call alarms.

To add a call alarm to the Scheduler:

1. Press  to access the main menu.
2. Select **Tools/Extras** and press .
3. Select **Calendar** and press .
4. Select the day you want to add a call alarm to by using the navigation key and press .
5. From the event list display, press **Options** (right softkey) to display the options.
6. Select **Add Event** and press .
7. Select **Call Alarm** and press .
8. Enter the phone number directly or press **Options** (right softkey) for options.
 - **From Phone Book** to select the desired number from your Contacts list.
 - **Voicemail** to select the number for voicemail access.
9. Select the box under the following items and press .
- **Time/Date** to edit the start time/date.
 - **Alarm** to select the ringer alarm.
 - **Repeat** to set the Call Alarm's repeat status. Select **None**, **Daily**, **Weekly**, **Monthly**, or **Yearly**.
10. Press **Save** (left softkey).

Tip: You can also add a call alarm from the Contacts menu (see "Contacts List Entry Options" on page 92).

Call Alarm Alerts

There are several ways your PCS Phone alerts you of a scheduled call alarm:

- By playing the alert tone (depending on the Ringer Type and Ringer Volume setting).
- By blinking the LED.
- By displaying the call alarm notification on the Main LCD when the flip is open.
- By displaying the call alarm notification on the Sub LCD when the flip is closed.
- By lighting the LCD backlight (depending on the backlight setting).

Call Alarm Menu

When your phone is turned on and you have scheduled a call alarm, your phone alerts you and displays the name or phone number you wish to call.

To respond to a call alarm:

1. Press  or **View** (left softkey) to silence the alarm and see the call alarm details.
2. Highlight the unchecked event and press  to see the call alarm details, or press **Options** (right softkey) for the following options (to select an option, highlight it and press ):
 - **Call** to dial the scheduled phone number.
 - **Call:Speaker On** to dial the scheduled phone number in speakerphone mode.
 - **Snooze** to repeat the alarm in ten minutes.
 - **Save Phone#** to save the scheduled phone number in your Contacts list. **Go to Phone Book** appears when the number is already in your Contacts list. (See “Saving a Phone Number” on page 27.)

Note: If you press **Exit** (left softkey) during step 2 above, you are prompted to erase the unchecked event. Select **Yes** to erase or **No** to cancel.

Editing a Call Alarm

To edit a call alarm:

1. From the Event list display (see page 103), highlight one of the call alarms and press . (The call alarm details appear.)
2. Select the box you want to edit and press .
3. Enter or select a new setting and press .
4. Press **Save** (left softkey).

Viewing a Future/Past Day's Scheduled Events

To view a future/past day's scheduled events:

1. From the Event list display (see page 103), press **Options** (right softkey).
2. Highlight **Go To Date** and press .
3. Enter the date by using numeric keys and the navigation key and press  or **OK** (left softkey).
4. Press  once again to view the day's Event list.

Adding To Do List Items

Your phone can store and manage up to 20 To Do List items.

To add an item to your To Do List:

1. From the Event list display (see page 103), press **Options** (right softkey).
2. Highlight **To Do List** and press .
3. Press **Options** (right softkey).
4. Highlight **Add Item** and press .
5. Enter the description (up to 14 characters) and press .
6. Select the menu under **Priority** and press  to edit the To Do's priority. You can select from **Normal**, **!Urgent**, or **√Done**.
7. Press **Save** (left softkey).

Viewing the To Do List

To view your To Do List:

1. From the Event list display (see page 103), press **Options** (right softkey).
2. Highlight **To Do List** and press .
 - To see the details of each To Do List item, select an item and press .

Editing To Do List Items

To edit a To Do List item:

1. From the To Do List display, highlight the item you want to edit and press .
2. Highlight the box you want to edit and press .
3. Edit the description or change the priority and press .
4. Press **Save** (left softkey).

Adding a To Do List Item to the Schedule

To add your To Do List item to the schedule:

1. From the To Do List display, highlight the item you want to add to the schedule and press **Options** (right softkey).
2. Highlight **Add To Schedule** and press .
 - **Add To Schedule** to extract the item from the To Do List and make it a scheduled event.
3. Enter the description using your keypad and press . (See “Adding an Event to the Scheduler” on page 101 for entering.)
4. Press **Save** (left softkey).

Deleting Items From the To Do List

To delete To Do List items:

1. From the To Do List display (see the previous page), highlight the item you want to erase and press **Options** (right softkey).
2. Highlight your desired option and press .
 - **Erase Item** erases an item from the To Do List.
 - **Erase Selection** erases multiple selected To Do List items at one time. Press  to check the box(es) next to the To Do List item(s) you want to delete and press **Erase** (left softkey) to erase. To check all boxes, press **Options** (right softkey), highlight **Check All**, and press .
 - **Erase All** erases all To Do List items.
3. Select **Yes** and press .

Viewing Memory in Your Scheduler

To view available memory space and options:

1. From the Event list display (see page 103), press **Options** (right softkey).
2. Highlight **View Memory** and press .
3. Highlight **Schedule**, **Call Alarm**, or **To Do List** and press . (The available memory space and options display.)

For further options:

4. Press **Options** (right softkey).
5. Highlight an option and press 
 - **Erase Old** deletes old events or call alarms.
 - **Erase Selection** deletes the To Do List items you selected. (See “Deleting Items From the To Do List ” on the previous page.)
 - **Erase Done** deletes the To Do List items that have been completed.
 - **Erase All** deletes all events, call alarms, or To Do List items.
6. Select **Yes** or **No** and press .

Purging All Events, Call Alarms, or To Do List Items

To delete all scheduled events, call alarms, or To Do List items:

1. From the Event list display (see page 103), press **Options** (right softkey).
2. Highlight **Erase Memory** and press .
3. Highlight one item from the options and press 
 - **Erase Old** deletes old events, call alarms, and To Do List items that are done.
 - **Erase All** deletes all events, call alarms, and To Do List items.
4. Select **Yes** or **No** and press .

Personal Information Management

Displaying Your User Address

To display the phone's current user address:

1. Press  to access the main menu.
 2. Select **Settings** and press .
 3. Select **Phone Info** and press .
 4. Select **Phone#/User ID** and press .
- If you sign out, <PCS Vision Disabled> appears on the display.

Finding Icon Definitions

To view an explanation of icons that appear on the display:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Phone Info** and press .
4. Select **Help** and press .
5. Select the item for which you want to see the explanation and press . (The icon's explanation appears.)
6. Press **Done** (left softkey) or  to end.

Tip: Press the navigation key up or down to scroll the message manually.

Displaying the Version Information

To display the version number of the software, hardware, PRL (Preferred Roaming List), PRI (Product Release Instructions), etc., installed on your PCS Phone:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Phone Info** and press .
4. Select **Version** and press .

Displaying Advanced Information

To display advanced information such as technology and frequency:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Phone Info** and press .
4. Select **Advanced** and press .

Using Your Phone's Tools

In addition to helping you be more efficient and organized, your PCS Vision Phone offers useful and entertaining tools.

Using the Alarm Clock

Your phone comes with a built-in alarm clock with alarm capabilities.

To use the alarm clock:

1. Press  to access the main menu.
2. Select **Tools/Extras** and press .
3. Select **Alarm Clock** and press .
4. A caution message will appear on the display. Press **Continue** (left softkey) to continue.
5. Select the box under the following items and press 
 - **Alarm** to set the alarm On/Off. Select **On** and press .
 - **Time** to enter the alarm time. Enter the desired alarm time and press .
 - **Repeat** to select the alarm frequency. Select **None** to set your alarm once or **Daily** to set your alarm daily.
6. Press **Done** (left softkey) to save the alarm settings.

Note: Alarm will not sound when the phone is powered off.

To stop the alarm:

- ▶ Press any key to stop the alarm.
 - Press **Exit** (right softkey) to exit the alarm clock display.

Tip: The alarm stops in 30 seconds automatically.

Note: You can adjust the ringer type and ringer volume in your Settings menu. To change the ringer type, see "Selecting Ringer Types for Calendar" on page 39. To change the ringer volume, see "Adjusting the Phone's Volume Settings" on page 41.

Using the Calculator

Your phone comes with a built-in calculator.

To use the calculator:

1. Press  to access the main menu.
2. Select **Tools/Extras** and press .
3. Select **Calculator** and press .
4. Enter numbers using your keypad. Press the left softkey to insert a decimal point.
5. Press the appropriate navigation key for an arithmetic option (Up for addition, Down for subtraction, Left for multiplication, Right for division).
6. Enter numbers and press  for the result.
 - To clear the numbers, press **CLR** (right softkey).
 - To exit the Calculator, press .

Using the World Clock

This feature is available only in digital service areas.

To set the world clock display:

1. Press  to access the main menu.
2. Select **Tools/Extras** and press .
3. Select **World Clock** and press .
4. The world clock display appears.
 - Press the navigation key right or left to change countries.

Press **Summer** (left softkey) or **Standard** (right softkey) to select between daylight savings and standard time (if applicable). “” is shown in summer mode.

Downloading Files Through PCS Vision

Your PCS Phone allows you to download images (screen savers), ringers, games, etc., from a PCS Vision connection. It is also possible to download from certain menus (Contacts list, Ringer Setting, or Display Setting).

To download a file from the Web:

1. Press  to access the main menu.
2. Select **Downloads** and press .
3. Select your desired data folder (for example, Games, Ringers, Screen Saver, or Applications) and press .
4. Select **Get New** and press .
5. Select your desired file and follow the system prompts.
6. Press the left softkey to start downloading.
7. Wait for the download to complete.
8. Press  to end or press the right or left softkey for further operation.
 - **Right softkey** returns to the Download page and you can continue to download.
 - **Left softkey** assigns the downloaded data. (See “Confirming the Downloaded Data” on page 117.)

To download a file from a Contacts list entry:

1. Press  to access the main menu.
2. Select **Contacts** and press .
3. Select **Find/Add Entry** and press .
4. Select the entry for which you want to set the downloaded ringer or image and press .
5. Highlight a phone number and press **Options** (right softkey). Then highlight **Edit** and press .
– or –
Highlight an email address or Web address, then press **Edit** (right softkey).
6. Scroll to **Ringer** or **Picture ID** and press .
7. Highlight **Get New** and press . (The browser launches and displays the Download page.)
8. Select your desired image or ringer file and follow the system prompts.
9. Press the left softkey to start downloading.
10. Wait for the download to complete.
11. Press  to end or press the right or left softkey for further operation.
 - **Right softkey** returns to the Download page and you can continue to download.
 - **Left softkey** assigns the downloaded data. (See “To confirm the downloaded ringers folder” on page 117 or “To confirm the downloaded images [screen savers] folder” on page 118.)

To download a ringer file from the Ringer Setting Menu (Ringer Type and Start-up/Power-off Tone):

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Sounds** and press .
4. Select **Ringer Type** and press .
5. Select one item from **Voice Calls**, **Voicemail**, **Messaging**, or **Calendar**, and press . The following item requires an extra step:
 - For **Voice Calls**, select the menu under **With Caller ID** or **No Caller ID**.
6. Select the menu under each item and press .
7. Select **Get New** and press . (The browser launches and displays the Download page.)
8. Select your desired ringer file and follow the system prompts.
9. Press the left softkey to start downloading.
10. Wait for the download to complete.
11. Press  to end or press the right or left softkey for further operation.
 - **Right softkey** returns to the Download page and you can continue to download.
 - **Left softkey** assigns the downloaded data. (See “To confirm the downloaded ringers folder” on page 117.)

To download a ringer file from the Start-up/Power-off Tone menu:

1. Select **Others** during step 4 above and press .
2. Select the menu under **Start-up Tone** or **Power-off Tone** and press .
3. Follow the previous steps 7 to 11.

To download an image file from the Display Setting Menu (Animation, Incoming Calls, and Screen Saver):

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Display** and press .
4. Select **Animation** or **Incoming Calls** and press .
The following item requires an extra step:
 - For **Animation**, select the menu under **Standby, Outgoing Calls, or Service Search**.
5. Select the menu under each item and press .
6. Select **Get New** and press . (The browser launches and displays the Download page.)
7. Select your desired image file and follow the system prompts.
8. Press the left softkey to start downloading.
9. Wait for the download to complete.
10. Press  to end or press the right or left softkey for further operation.
 - **Right softkey** returns to the Download page and you can continue to download.
 - **Left softkey** assigns the downloaded data. (See “To confirm the downloaded images [screen savers] folder” on page 118.)

To download an image file from the Screen Saver menu:

1. Select **Standby Display** during step 4 above and press .
2. Select **Screen Saver** and press .
3. Select the menu under **Screen Saver** and press .
4. Follow the previous steps 6 to 10.

Confirming the Downloaded Data

The downloaded data will be classified as games, ringers, images (screen savers), or applications automatically. However, if any data has a different category, it is classified as Dynamic. If data doesn't belong to any of the above, it is classified as Others.

To confirm the downloaded games folder:

1. Press  to access the main menu.
2. Select **Downloads** and press .
3. Select **Games** and press .
4. Select the downloaded game you want to confirm and press .
5. Select **Run** from the options and press .

Options:

- **Run** to play the downloaded game.
- **Settings** to set the Network Access availability.
- **Options** to select the options of the downloaded game.
 - Properties** shows the downloaded game properties.
 - Online Info** shows the downloaded game online information (if applicable).
 - Shop** allows you to continue downloading (if applicable).
 - Logo/Trademark** displays logo and description.
 - Erase** erases the selected downloaded game.
- **Exit** to return to the downloaded data list display.

To confirm the downloaded ringers folder:

1. Press  to access the main menu.
2. Select **Downloads** and press .
3. Select **Ringers** and press .
4. Select the downloaded ringer you want to confirm and press .
5. Select **Play** from the options and press .

Options:

- **Play** to play the downloaded ringer.
- **Assign** to assign the downloaded ringer to the Voice Calls, Voicemail, Messaging, Calendar, Start-up/Power-off Tone, or Phone Book.
- **Options** to select the options of the downloaded ringer.
 - Properties** shows the downloaded ringer properties.
 - Online Info** shows the downloaded ringer online information (if applicable).
 - Shop** allows you to continue downloading (if applicable).
 - Erase** erases the selected downloaded ringer.
- **Exit** to return to the downloaded data list display.

To confirm the downloaded images (screen savers) folder:

1. Press  to access the main menu.
2. Select **Downloads** and press .
3. Select **Screen Savers** and press .
4. Select the downloaded image you want to confirm and press .
5. Select **View** from the options and press .

Options:

- **View** to display the downloaded image.
- **Assign** to assign the downloaded image to the Incoming Calls, Screen Saver, or Phone Book.
- **Options** to select the options of the downloaded image.
 - Properties** shows the downloaded image properties.
 - Online Info** shows the downloaded image online information (if applicable).
 - Shop** allows you to continue downloading (if applicable).
 - Erase** erases the selected downloaded image.
- **Exit** to return to the downloaded data list display.

Note: Depending on the data, you can select where to assign your downloaded files: Image data can be assigned to **Incoming Calls**, **Screen Saver**, or **Phone Book**. Animation data can be assigned to **Standby**, **Outgoing Calls**, or **Service Search**.

To confirm the downloaded applications folder:

1. Press  to access the main menu.
2. Select **Downloads** and press .
3. Select **Applications** and press .
4. Select the downloaded application you want to confirm and press .
5. Select **Run** from the options and press .

Options:

- **Run** to play the downloaded application.
- **Settings** to set the Network Access availability.
- **Options** to select the options of the downloaded application.
 - Properties** shows the downloaded application properties.
 - Online Info** shows the downloaded application online information (if applicable).
 - Shop** allows you to continue downloading (if applicable).
 - Logo/Trademark** displays logo and description.
 - Erase** erases the selected downloaded application.
- **Exit** to return to the downloaded data list display.

To confirm the downloaded Dynamic folder:

The downloaded data in the Dynamic folder are varied (options subject to change).

1. Press  to access the main menu.
2. Select **Downloads** and press .
3. Select **Dynamic-(1 to 10)** and press .
4. Select the downloaded data you want to confirm and press .
5. Select **Open** from the options and press .

Options:

- **Open** to play the downloaded content.
- **Options** to select the options of the downloaded data.
 - Properties** shows the downloaded data properties.
 - Online Info** shows the downloaded data online information (if applicable).
 - Shop** allows you to continue downloading (if applicable).
 - Logo/Trademark** displays logo and description (if applicable).
 - Erase** erases the selected downloaded data.
- **Exit** to return to the downloaded data list display.

To confirm the downloaded Others folder:

The downloaded data in the Others folder are varied (options subject to change).

1. Press  to access the main menu.
2. Select **Downloads** and press .
3. Select **Others** and press .
4. Select the downloaded data you want to confirm and press .
5. Select **Open** from the options and press .

Options:

- **Open** to play the downloaded content.
- **Options** to select the options of the downloaded data.
 - Properties** shows the downloaded data properties.
 - Online Info** shows the downloaded data online information (if applicable).
 - Shop** allows you to continue downloading (if applicable).
 - Logo/Trademark** displays logo and description (if applicable).
 - Erase** erases the selected downloaded data.
- **Exit** to return to the downloaded data list display.

Icon Indication

Type	Item	Icon (appears at the left side of the downloaded data)
From Web	Ringers (~128KB)	+  (New Data)  (Assigned Data)
	Voice (~128KB)	+  (New Data)  (Assigned Data)
	Screen Savers/Images (~128KB)	+  (New Data)  (Assigned Data)
	Animation (~128KB)	+  (New Data)  (Assigned Data)
	Animation Ringer (~128KB)	+  (New Data)  (Assigned Data)
	Game (~128KB)	+  (New Data)
	Application (~128KB)	+  (New Data)
	Unknown type (~128KB)	+  (New Data)
		Note: Download icon subject to change

Sorting the Downloaded Data

Files downloaded via the Web are stored in alphabetical order. You may also store the data in memory size order.

To sort downloaded files:

1. Press  to access the main menu.
2. Select **Downloads** and press .
3. Select one of each folder that includes the downloaded data you want to sort.
4. Press .
5. Press **Options** (right softkey).
6. Highlight **Sorting** from the options and press .
 - **Sorting** to sort the downloaded data in alphabetical (**Name**) or memory size (**Size**) order.
 - **Icon/Size** to show the downloaded data list with memory size.
 - **Erase All** to erase all downloaded files you selected during step 3. (Downloaded data that has already been assigned cannot be erased.)
7. Highlight **Name** or **Size** and press .

Viewing the Downloaded Data Size

This feature allows you to confirm each downloaded file's size and the remaining download capacity.

To view the data size:

1. Press  to access the main menu.
2. Select **Downloads** and press .
3. Select one of each folder that includes the downloaded data you want to confirm and press .
4. Press **Options** (right softkey).
5. Highlight **Icon/Size** and press . (Data size is displayed at the left of the downloaded data name.)

Viewing the Memory Space Available for Downloads

This feature allows you to confirm how much memory is left and may be used for downloading files.

To view the available memory space:

1. Press  to access the main menu.
2. Select **Downloads** and press .
3. Press **Options** (right softkey).
4. Highlight **View Memory** and press . (Used and Free memory size are displayed.)

Erasing Old Downloaded Data

If you try to download new data when the downloaded data's memory is full, a warning message appears and you will be prompted to erase some old downloaded data.

To erase downloaded data:

1. When the warning message appears, press **Erase** (left softkey) to make a space for new download data. (Press the right softkey to cancel the download.)
2. Select one of each folder that includes the data you want to erase and press .
3. Select the data you want to erase and press **Erase** (left softkey).
4. Select **Yes** and press . (You can now continue to download the new file.)

Using Your Phone's Voice Services

In This Section

- ◆ **Using Voice-Activated Dialing**
 - ◆ **Managing Voice Memos**
 - ◆ **Setting Up Screen Call**
-

Your PCS Vision Phone's Voice Services let you place calls using your voice, store voice reminders, and record memos right on your phone.

This section includes easy-to-follow instructions on using voice-activated dialing and managing voice memos.

Using Voice-Activated Dialing

In addition to PCS Voice Command™ (see page 223), you can use a voice dial tag to automatically dial a phone number in your Contacts. (A voice dial tag is a command you record and use to place calls without using the keypad.) Your phone can store up to 30 voice dial tags. (To create a voice dial tag, see “Adding a New Contacts Entry” on page 89 or “Editing a Contacts Entry’s Phone Number” on page 93.)

Making a Call Using Voice-Activated Dialing

To use a voice dial tag to call a phone number:

With the flip open:

1. Press **TALK** or **SPEAKER** briefly.
2. Follow the voice prompts and recite the entry’s Voice Dial tag into your phone’s microphone.

With the flip closed:

1. Press and hold **END CALL**.
2. Follow the voice prompts and recite the entry’s Voice Dial tag into your phone’s microphone.

Note: To use the Voice Dial function, you must have a stored entries for Voice Dial (see “Programming Voice Dial Tags” below).

Programming Voice Dial Tags

To program a voice dial tag:

1. Press **MENU** to access the main menu.
2. Select **Voice Services** and press **MENU**.
3. Select **Voice Dial** and press **MENU**.
4. Select **Program** and press **MENU**.
5. The phone will prompt you to say the name you want to program. Wait for the beep and then say the name.
6. Respond to the prompt by repeating the name after the beep.

7. Enter or highlight the Voice Dial entry (name) in the Contacts list and press .
8. Select the labeled category that includes your desired phone number and press . (The display shows “Voice Dial Recorded.”)

Note: Record Voice Dial tags in a quiet environment and without the aid of an accessory (for example, a headset or hands-free car kit).

Reviewing Voice Dial Tags

To review voice dial tags:

1. Press  to access the main menu.
2. Select **Voice Services** and press .
3. Select **Voice Dial** and press .
4. Select **Review** or **Review:Speaker** and press .
5. Select the desired entry and press .
– or –
Select the desired entry and press **Options** (right softkey). To select an option, highlight it and press .

Options:

- **Play** to play the recorded voice dial tag.
- **Speaker On** to play the recorded voice dial tag in speakerphone mode. (If you are in speakerphone mode, the option will appear as **Speaker Off** to deactivate.)
- **Erase** to erase the voice dial tag. Select **Yes** to erase and **No** to cancel.

Erasing All Voice Dial Tags

To erase all voice dial tags:

1. Press  to access the main menu.
2. Select **Voice Services** and press .
3. Select **Voice Dial** and press .
4. Select **Erase All** and press .
5. Select **Yes** and press .

Managing Voice Memos

You can use your phone's Voice Services to record brief memos to remind you of important events, phone numbers, or grocery list items.

Tip: If you haven't signed up for the PCS Ready Link service and PCS Ready Link mode is set to **Disable**, you can use the Ready Link (Memo) Button () as a Voice Memo button in standby mode. You can use it to record memos or display Memo options.

Recording Voice Memos

To record a voice memo:

1. Press  to access the main menu.
2. Select **Voice Services** and press .
3. Select **Voice Memo** and press .
4. Select **Record** and press .
5. Start recording after the beep.

To end the recording of your memo:

- ▶ Press , , or .

Tip: Recording terminates automatically after 18 seconds.

Tip: To record in speakerphone mode, press and hold  in standby mode.

To record a conversation during a phone call:

1. During a call, press  to see the options.
2. Select **Voice Services** and press .
3. Select **Voice Memo** and press .
4. Select **Record** and press .
5. Start recording after the beep.

To end the recording of your conversation:

- ▶ Press  or  while recording.

– or –

Press  to stop recording and disconnect the call.

Recording also stops when the other party hangs up the call.

- Memo recording is disabled while you are roaming in analog service areas.
- When the recording capacity is full, highlight an old memo, and press **Erase** (left softkey). Then select **Yes** and press  to make room for additional memos.

Note: Your phone can store up to 12 memos and the total available recording time is 72 seconds (maximum of 18 seconds per memo).

Tip: Voice Memos are stored with the date and time stamp in reverse chronological order, except when recorded in a no service area.

Voice Memo Options

To play the voice memos you have recorded:

1. Press  to access the main menu.
 2. Select **Voice Services** and press .
 3. Select **Voice Memo** and press .
 4. Select **Play** or **Play:Speaker** and press .
 5. Select one memo from the list and press .
- or -

If you want to play all memos continuously, highlight **All** and press .

6. Press  to stop playing.
 - Press **Slow** (left softkey) or **Fast** (right softkey) to change the playing speed.
 - To play the newer/older memo, press the navigation key right or left.

Tip: To set the speakerphone mode on or off, press **Options** (right softkey), highlight **Speaker On/Off**, and press  during step 5 above.

Erasing Voice Memos

To erase all voice memos:

1. Follow steps 1-4 on the previous page.
2. Press **Options** (right softkey).
3. Select **Erase All** and press .
4. Select **Yes** and press .

– or –

1. Press  to access the main menu.
2. Select **Voice Services** and press .
3. Select **Voice Memo** and press .
4. Select **Erase All** and press .
5. Select **Yes** and press .

To erase individual memos:

1. Press  to access the main menu.
2. Select **Voice Services** and press .
3. Select **Voice Memo** and press .
4. Select **Play** or **Play:Speaker** and press .
5. Display the memo list, highlight the memo you want to erase, and press **Options** (right softkey).
6. Select **Erase** and press .
7. Select **Yes** and press .

Setting Up Screen Call

This feature enables you to screen incoming calls by using a recorded announcement, either one that is pre-recorded or one that you record. You can also record the caller's message into the Voice Memo list. To listen to the message, see "Voice Memo Options" on page 127.

Activating Screen Call

To start Screen Call when you have incoming calls:

1. When the phone rings or vibrates, press **Options** (right softkey) to display the options.
2. Highlight **Screen Call** and press .

To set Auto Screen Call:

1. Press  to access the main menu.
2. Select **Voice Services** and press .
3. Select **Screen Call** and press .
4. Select **Auto** and press .
5. Select **On** and press .
6. Set the answering time by using numeric keys or by pressing the navigation key up or down.
7. Press  or **OK** (left softkey). (The  icon is displayed on the standby display.)

Tip: If a new caller's message is waiting,  appears on the display. The memos recorded while activating "Screen Call" are shown with "✓" or "!" icon in the list ("✓": once played, "!": not played yet).

Tip: While the caller's message is being recorded: Pressing  stops recording and disconnects the call, pressing  answers the call.

Selecting an Announcement for Screen Call

To select a Screen Call announcement:

1. Press  to access the main menu.
2. Select **Voice Services** and press .
3. Select **Screen Call** and press .
4. Select **Announcement** and press .
5. Depending on your preference, highlight **Pre-Recorded** or **Custom** and press .

Recording Your Name for a Pre-Recorded Announcement

You can use a pre-recorded announcement with or without your name. If you record your name, your phone uses your name to announce that you are not available to answer the call.

To record your name:

1. Press  to access the main menu.
2. Select **Voice Services** and press .
3. Select **Screen Call** and press .
4. Select **Announcement** and press .
5. Select **Pre-Recorded** and press **Edit** (right softkey).
6. Select **Record Name** and press 
 - If your name has already been recorded, select **Yes** or **No** to overwrite the existing recording.
7. Press  to start the first recording. (Press  to stop recording.)
8. After the first recording, press  again to start the second recording.
9. Press  to stop recording.

Tip: Recording terminates automatically after 12 seconds.

Recording a Customized Announcement

To record an announcement:

1. Follow steps 1-4 on the previous page.
2. Select **Custom** and press **Edit** (right softkey).
3. Highlight **Record** and press .
 - When an announcement has already been recorded, select **Yes** or **No** to overwrite the existing recording.
4. Press  to start the first recording. (Press  to stop recording.)
5. After the first recording, press  again to start the second recording.
6. Press  to stop recording.

Tip: Recording terminates automatically after 12 seconds.

Reviewing an Announcement

To review an announcement:

1. Press  to access the main menu.
2. Select **Voice Services** and press .
3. Select **Screen Call** and press .
4. Select **Announcement** and press .
5. Select **Pre-Recorded** or **Custom** and press **Edit** (right softkey).
6. Highlight **Play** or **Play:Speaker** and press .

Erasing an Announcement

To erase an announcement:

1. Follow steps 1-5 above.
2. Select **Erase Name** to erase the name for a Pre-Recorded announcement and press .
– or –
Select **Erase** to erase the message for a Custom announcement and press .
3. Select **Yes** and press .

Using PCS Ready Link

In This Section

- ◆ **Getting Started With PCS Ready Link**
 - ◆ **Making and Receiving a PCS Ready Link Call**
 - ◆ **Adding and Editing Ready Link Contacts**
 - ◆ **Erasing Ready Link List Entries**
 - ◆ **Updating Your PCS Ready Link Lists**
 - ◆ **Managing PCS Ready Link Settings**
-

Your PCS Vision Ready Link Phone gives you the ability to quickly connect with other PCS Ready Link users for walkie-talkie-style communication from anywhere, to anywhere on the Sprint Nationwide PCS Network.

It's ideal for quick two-way conversations with your friends, family, and co-workers.

This section explains the features and options of your PCS Vision Ready Link Phone.

Getting Started With PCS Ready Link

PCS Ready Link allows you to enjoy quick, two-way, “walkie-talkie-style” communication with your friends, family, and co-workers. You can make 1-to-1 or 1-to-many calls (up to 5 others on the same call) to any other PCS Ready Link user, anywhere on the Sprint Nationwide PCS Network. You can make and receive PCS Ready Link calls when your phone displays .

Setting PCS Ready Link Mode

To enable or disable PCS Ready Link mode:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Ready Link** and press .
4. Select **Enable/Disable** and press .
5. Select **Enable** and press . (The default setting is **Disable**.)
 - **Enable:** Lets you make or receive PCS Ready Link calls any time your phone is not in use.
 - **Disable:** Disables your phone’s PCS Ready Link service; you will not be able to make or receive PCS Ready Link calls or access your Ready Link contacts.

Tip: If you haven’t signed up for the PCS Ready Link service and PCS Ready Link mode is set to **Disable**, you can use the Ready Link (Memo) Button () as a Voice Memo button in standby mode.

Preparing Your Phone for PCS Ready Link Service

The first time you use your PCS Vision Ready Link Phone, your phone must identify itself and make itself available to the Ready Link network.

1. When you activate PCS Ready Link for the first time, you will be prompted to activate Ready Link service. Press **OK** (left softkey) to activate. (You will see “**Preparing Ready Link service... Please wait.**”)
2. Press **R-Link** (left softkey) or the Ready Link (Memo) button on the side of your phone (). (The PCS Ready Link Help message will appear.)
3. Press **Yes** (left softkey) to read a brief introduction to PCS Ready Link, and press **Next** (left softkey) to continue through the tutorial.

Your phone is now ready to make and receive PCS Ready Link calls.

Ready Link Call Alerts

There are several ways your PCS Phone alerts you during PCS Ready Link calls.

When you make or receive a PCS Ready Link call:

- The phone sounds (depending on the Ringer Type and Ringer Volume setting).
- The backlight illuminates.
- The screen displays a PCS Ready Link call message.
- The other party's PCS Ready Link number and name (if available) are displayed.
- The screen displays who has the floor.

The status of a PCS Ready Link call:

- The Green LED On indicates you have the floor and may speak.
- The Red LED On indicates another contact has the floor.
- The LED Off indicates the floor is open. (You can take the floor and speak by pressing and holding .)

Making and Receiving a PCS Ready Link Call

Displaying the PCS Ready Link List

- ▶ From standby mode, press **R-Link** (left softkey) or the Ready Link (Memo) button on the side of your phone () to access the PCS Ready Link List.

Selecting Contact Lists

When your phone displays a PCS Ready Link List, the left softkey is labeled **Go to**. To switch to another contact list, press **Go to** (left softkey), highlight your desired list, and press .

- **Company List/Company Groups** contain company-provided contacts (up to 200 entries). Your company list can only be created and modified by an authorized administrator on the PCS Ready Link server. You cannot add, edit, or delete Company List items, but you can copy entries to your Personal Lists.
- **Personal List/Personal Groups** contain your personal Ready Link contact names and numbers, separately or in groups. You can create and edit your own Personal List. Your phone can store a total of 200 entries (you may include up to five contacts per group).
- **Outgoing** shows the last 10 different PCS Ready Link calls you placed.
- **Incoming** shows the last 10 different PCS Ready Link calls you accepted.
- **Missed** shows the last 10 PCS Ready Link calls you missed.

Note: The  icon next to the group name indicates a group.

Making a PCS Ready Link Call (1-to-1 Call)

You can place a 1-to-1 PCS Ready Link call by entering a PCS Ready Link number or by selecting a contact from the PCS Ready Link List.

To place a PCS Ready Link call by selecting a contact:

1. Press **R-Link** (left softkey) or press **MEMO** to access the PCS Ready Link List.
2. Press **Go to** (left softkey), highlight the list from which you want to place a call (**Company List**, **Personal List**, **Outgoing**, **Incoming**, or **Missed**), and press **MENU OK**.

Tip: You can also select **Enter R-Link#** from the **Go to** option to enter a PCS Ready Link number directly. (See page 138 for details.)

3. Highlight the contact you want to call, and press and hold **MEMO** to place the call and get the floor. (You will see **R-Link calling...** and **Connecting...** followed by **"You have floor."** You can now begin speaking.)
– or –
Highlight the contact you want to call and press and release **MEMO** to place the call. (The call will connect as described above, but **"Floor is open."** will appear on the screen and either you or your contact may press and hold **MEMO** to take the floor and speak.)
 - To see an entry's information, press **MENU OK** during step 3 above.

Note: During a PCS Ready Link call, the **"floor"** is the right to speak. When you see **"Floor is open,"** the first person to press the Ready Link (Memo) button (**MEMO**) can speak (while holding the button). Only the person who has the floor can speak. The phone beeps if you press the Ready Link (Memo) button when another contact has the floor.

4. Continue holding **MEMO** as you speak. When you are finished speaking, release the Ready Link (Memo) button to allow other contacts to speak. (When the other party takes the floor, you will see the speaker's name and phone number and the text **"has floor."**)
5. When you are finished, press **END/0**.

Note: When neither party has the floor during a PCS Ready Link call, **"Floor is open."** appears on the display. If no one takes the floor for 20 seconds, the PCS Ready Link call ends automatically.

Tip: If you press **TALK** or **SPEAKER** during step 3 above, you can make a standard voice call.

Making a PCS Ready Link Call (Group Call)

You can make a PCS Ready Link call to all members in a Group entry, which you have in your PCS Ready Link List. You can communicate with up to five members at a time.

To place a PCS Ready Link Group call:

1. Press **R-Link** (left softkey) or press  to access the PCS Ready Link List.
2. Press **Go to** (left softkey), highlight the list from which you want to make a Group call (**Company Groups** or **Personal Groups**), and press .
3. Highlight the group you want to call, and press and hold  to place the call and take the floor. (You will see **R-Link calling...** and **Connecting...** followed by “**You have floor.**” Continue with the PCS Ready Link call as described on the previous page.)
 - To display a group member's details, press , highlight your desired group member, then press **View** (left softkey) during step 3 above. Press  to make a PCS Ready Link call to the member.
 - If one of the group members takes the floor, you will see the member's name and PCS Ready Link number on the display. The phone beeps if you press the Ready Link (Memo) button when another contact has the floor.
4. When the call is finished, press .

Tip: You can also make a Group Call after checking the group member. Press  to display group members, highlight **<Call Group>** and press and hold  during step 3 above.

Making a PCS Ready Link Call by Entering a Number

To place a PCS Ready Link call by entering a number:

1. From standby mode, enter the PCS Ready Link number you want to dial.
2. Press **|||||** to place the PCS Ready Link call. Continue holding **|||||** to take the floor and speak.
 - The contact's name appears on the display if there is a matched number in your PCS Ready Link List.
3. Continue with the PCS Ready Link call, pressing and holding **|||||** to speak and releasing it to allow others to reply.
4. When the call is finished, press **END/⓪**.
- or -
 1. Press **R-Link** (left softkey) or press **|||||** to access the PCS Ready Link List.
 2. Press **Go to** (left softkey), highlight **Enter R-Link#** and press **MENU OK**.
 3. Enter the PCS Ready Link number you want to dial.
 4. Follow steps 2-4 above.

Note: PCS Ready Link numbers must contain ten digits (area code + phone number). Your PCS Ready Link number is the same as your PCS Phone number.

Missed Call Notification for PCS Ready Link Calls

When an incoming PCS Ready Link call is not answered, the Missed Call Notification is displayed on your screen.

To call the last Missed PCS Ready Link call:

- ▶ Simply press and hold **|||||** while the Missed Call Notification is displayed. (Continue with the PCS Ready Link call as described previously.)

To display the Missed Ready Link Call Log:

- ▶ Press **View** (left softkey). To call the entry, highlight the entry you want to call, and press and hold **|||||**. (Continue with the PCS Ready Link call as described previously.)

Note: When you display Missed Calls entries, you will see the  icon next to the name. The  icon will remain until you make or receive a PCS Ready Link call to or from the entry. The  icon appears next to the new missed call entry.

Receiving a PCS Ready Link Call (1-to-1 Call)

1. Make sure your phone's PCS Ready Link mode is enabled (see "Setting PCS Ready Link Mode" on page 133).
2. When you receive a PCS Ready Link call from a contact, "R-Link Call," the contact's name, and the PCS Ready Link number appear on the display. (You do not need to take any action to answer the call.)
3. If the person placing the call has kept the floor (held the Ready Link [Memo] button), you will see the contact name and PCS Ready Link number along with "**has floor.**", and you will hear the caller speaking.
4. When the caller finishes speaking and releases the Ready Link (Memo) button, you will see "**Floor is open.**" on the display screen. Press and hold **[MEMO]** to take the floor and reply to the caller. (You will see "**You have floor.**" and hear a tone confirming that you may speak.)
5. When the conversation is finished, press **[END/0]**.

Receiving a PCS Ready Link Call (Group Call)

1. When you receive a PCS Ready Link call from one of the group members, "Group Call," the group member's name, and the PCS Ready Link number appear on the display.
2. Continue with the PCS Ready Link call as described previously.
3. When the conversation is finished, press **[END/0]**.

Redialing a PCS Ready Link Call

You can redial to the last PCS Ready Link call that you dialed or received (whichever was more recent).

To redial a PCS Ready Link call:

1. From the PCS Ready Link List, highlight **Redial**, and press and hold **|||||**.
 - You will see **R-Link redialing...** and **Connecting...** followed by the text “**You have floor.**”
2. Speak after the beep (keep pressing down **|||||** while you are speaking). After speaking, release the button to allow others to reply.
3. When you are finished, press **END/⓪**.

Note: You can change the volume and the speaker setting while a PCS Ready Link call is activated. **Volume:** Adjust the voice volume by using the Side Volume key or by pressing the navigation key up or down except when you are pressing and holding **|||||**. **Speaker:** Switch the speaker on or off by pressing **SPEAKER**.

PCS Ready Link Options

When you use PCS Ready Link, several user options are available by pressing **Options** (right softkey). To select an option, highlight it and press **MENU OK**.

- **Copy** to copy a contact to the Personal List. **Copy Group** appears when you highlight a group. (This option doesn't appear if the entry is already in the Personal List or when you select Personal List/Personal Groups.)
- **Edit** to edit a PCS Ready Link number and/or name. See page 145.
- **Erase** to erase a contact. **Erase Group** appears when you highlight a group.
- **Add Contact** to add a new contact. **Add Group** appears when you highlight a group list. See page 143 for details.
- **Erase R-Link List** to erase entries saved in the PCS Ready Link List (except Company List/Company Groups).
- **Help** to see the PCS Ready Link instruction page.

Note: When you use additional accessories, the volume of Ready Link floor tones is fixed as follows. **Speaker/Car Kit:** Level 3. **Earpiece/Headset:** Level 2.

Adding and Editing Ready Link Contacts

Copying an Entry to Personal List or Personal Group List

You can copy an entry to your Personal Lists from several different sources. If the selected entry is already stored in the Personal Lists, the “copy” option does not appear.

To copy an entry from the last PCS Ready Link call:

1. From the PCS Ready Link List, highlight **Redial** and press .
2. Press **Copy** (right softkey).
3. Press **Yes** (left softkey) to complete copying.

To copy an entry from the PCS Ready Link List:

1. Press **R-Link** (left softkey) or press  to access the PCS Ready Link List.
2. Press **Go to** (left softkey), highlight the list from which you want to copy a contact (**Company List**, **Company Groups**, **Outgoing**, **Incoming**, or **Missed**), and press .
3. Highlight the entry you want to copy (or scroll to highlight the **Redial** entry at the top of your screen) and press **Options** (right softkey).
4. Highlight **Copy** and press .
 - **Copy Group** appears when you highlight a group during step 3 above.
5. Press **Yes** (left softkey) to copy and save the entry to your Personal List or Personal Group List.

To copy an entry from the Company List:

1. Press  to access the main menu.
2. Select **Contacts** and press .
3. Select **Find/Add Entry** and press .
4. Press **Go to** (left softkey), highlight **Company List**, and press .
5. Highlight a contact you want to copy and press **Options** (right softkey). To select an option, highlight it and press .
 - **Copy to Personal** to copy the entry to the Personal List.
 - **Copy to Ph. Book** to copy the entry to the Contacts list.
6. Press **Yes** (left softkey) to complete copying.

To copy an entry from the Company Group List:

1. From step 4 on the previous page, highlight **Company Groups** and press .
2. Highlight a group you want to copy and press **Options** (right softkey). To select an option, highlight it and press 
 - **Copy to Personal** to copy the entry to your Personal Group List.
 - **Exit** to exit the options.
3. Press **Yes** (left softkey) to complete copying.

Note: Your Company Lists can only be set up and edited by an authorized administrator on the PCS Ready Link server. You cannot add or edit contacts/groups to your Company Lists.

Saving a PCS Ready Link Number

When you have finished a PCS Ready Link call, you will see the caller's name, PCS Ready Link number, and the text "R-Link call ended." on the display. You can save a PCS Ready Link number from the ending display to your Personal Lists.

To save the number:

1. From the ending display, press **Save** (right softkey).
2. Press **Yes** (left softkey).
 - If the entry has no name, you are prompted to enter a name.

Note: If the number is already stored in the Personal List or Personal Groups, the "Save" softkey does not appear.

Finding an Entry in the PCS Ready Link List

You can find your desired entry by entering a few letters.

To find a PCS Ready Link entry:

1. Press **R-Link** (left softkey) or press  to access the PCS Ready Link List.
2. Press **Go to** (left softkey), highlight your desired list (**Company List**, **Company Groups**, **Personal List**, or **Personal Groups**), and press .
3. Enter the first letter or the first few letters of the name.
 - The display shows the list beginning with the letter(s) you entered.
4. Scroll through the list and press  to select your desired entry.

Adding a New Contact to Your Personal List

You can store a total of 200 entries in the Personal Lists.

To add a new PCS Ready Link contact:

1. Press **R-Link** (left softkey) or press  to access the PCS Ready Link List.
2. Press **Go to** (left softkey), highlight **Personal List**, and press .
3. Highlight **<Add Contact>** and press .
– or –
Highlight an entry and press **Options** (right softkey). Then highlight **Add Contact** and press .
 - If the Personal List is full, you will see a warning message on the display. (Your phone can store a total of 200 Ready Link Personal List or Personal Group contacts.)
4. Enter a name for the new contact and press . (This is the name you will see when calling or receiving a call from the contact.)
5. Highlight the **R-Link Number** field, enter the contact's 10-digit PCS Ready Link number (their PCS Phone number) and press .
6. Press **Save** (left softkey) to save the new contact to your Personal List.

Tip: You are not allowed to use the following symbols during step 4: ":", "@", ";", "/", "*", ")", and "(".

Adding a New Group to Your Personal Group List

You can add new groups to the Personal Group List. Each group can include up to five members. You can enter a group member directly, or select the member from the Company List or Personal List.

To add a new PCS Ready Link group entry:

1. Press **R-Link** (left softkey) or press **|||||** to access the PCS Ready Link List.
2. Press **Go to** (left softkey), highlight **Personal Groups**, and press **MENU OK**.
3. Highlight **<Add Group>** and press **MENU OK**.
– or –
Highlight an entry and press **Options** (right softkey). Then highlight **Add Group** and press **MENU OK**.
4. Enter a Group Name, press **MENU OK**, and press **Next** (left softkey).
5. To add contacts to the group, press **Add** (right softkey).
6. Highlight one item from the following and press **MENU OK**:
 - **New** to add a new contact. See the previous page for details.
 - **from Company** to add a contact from your Company List.
 - **from Personal** to add a contact from your Personal List.
7. Scroll to select the contacts you want to add and press **MENU OK** or **Pick** (right softkey) to include the entries.
8. Press **Done** (left softkey) when you are finished selecting contacts, then press **Update** (left softkey) to update your Personal Group List with the new group entry.

Tip: You can also add members directly. From step 5 above, highlight **<Add Members>** and press **MENU OK**. Enter the new member's name and R-Link number and press **Save** (left softkey) to save the entry.

Editing a Contact in Your Personal List

To edit a Personal List contact:

1. Follow steps 1-2 in “Adding a New Contact to Your Personal List” on page 143.
2. Highlight the entry you want to edit and press **Options** (right softkey).
 - **Edit** to edit the selected contact.
 - **Erase** to erase the selected contact.
 - **Add Contact** to add a new contact.
 - **Erase R-Link List** to erase the PCS Ready Link List. See page 147 for details.
 - **Help** to view the PCS Ready Link instruction page.
3. Highlight **Edit** and press .
4. Highlight the field you want to edit (**Name** or **R-Link Number**), and press .
5. Edit the entry, press **OK** (left softkey), and press **Save** (left softkey) to save your changes.

Editing a Group in Your Personal Group List

To edit a group name:

1. Follow steps 1-2 in “Adding a New Group to Your Personal Group List” on the previous page.
2. Highlight the group entry you want to edit and press **Options** (right softkey).
 - **Edit** to edit the selected group.
 - **Erase Group** to erase the selected group.
 - **Add Group** to add a new group.
 - **Erase R-Link List** to erase the PCS Ready Link List. See page 147 for details.
 - **Help** to view the PCS Ready Link instruction page.

3. Highlight **Edit** and press .
4. Edit the group name and press  or **OK** (left softkey).
 - If you don't need to edit the group name, press **Next** (left softkey) during step 4 above and skip step 5.
5. Press **Save** (left softkey) to save your changes.
6. To edit a group member, highlight the contact you want to edit and press **Options** (right softkey).
 - **Edit** to edit a group member's name and phone number.
 - **Erase** to erase the group member.
 - **Add New** to add a new group member in the Personal Group List.
 - **Add (Company)** to add a new group member from the Company List.
 - **Add (Personal)** to add a new group member from the Personal List.
 - **Details** to display a group member's information.
7. Highlight **Edit** and press .
8. Highlight the field you want to edit (**Name** or **R-Link Number**) and press .
9. Edit the entry, press **OK** (left softkey), and press **Save** (left softkey) to save your changes.
10. Press **Update** (left softkey) to update your Personal Group List.

Erasing Ready Link List Entries

Erasing an Entry in Your Personal List or Personal Group List

To erase a contact or a group:

1. From the PCS Ready Link List, press **Go to** (left softkey), highlight **Personal List** or **Personal Groups**, and press .
2. Highlight the entry you want to erase and press **Options** (right softkey).
3. Highlight **Erase** and press .
 - **Erase Group** appears when you select Personal Groups.
4. Select **Yes** and press .

To erase a group member:

1. From the PCS Ready Link List, press **Go to** (left softkey), highlight **Personal Groups**, and press .
2. Highlight your desired group and press  to display the group members.
3. Highlight the contact you want to erase and press **Options** (right softkey).
4. Highlight **Erase** and press .
5. Select **Yes** and press .
6. Press **Update** (left softkey) to update your Personal Group List.

Erasing a PCS Ready Link List

You can erase all entries saved in the PCS Ready Link List (except Company List/Company Groups).

To erase a PCS Ready Link List:

1. From the PCS Ready Link List, press **Options** (right softkey).
2. Highlight **Erase R-Link List** and press .

3. Highlight your desired option and press 
 - **Outgoing** to erase all outgoing PCS Ready Link calls.
 - **Incoming** to erase all incoming PCS Ready Link calls.
 - **Missed** to erase all missed PCS Ready Link calls.
 - **All** to erase all PCS Ready Link call history, except redial.
 - **All Personal Ent.** to erase all entries in Personal List and Personal Groups. You are prompted to enter your 4-digit lock code. (See “Unlocking Your Phone” on page 66.)
4. Select **Yes** and press .

Tip: The Redial number will not be erased.

Updating Your PCS Ready Link Lists

Updating the Company List and Personal List

To update your Company List and Personal List manually through the PCS Ready Link server:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Ready Link** and press .
4. Select **List Update** and press .

Managing PCS Ready Link Settings

Setting Speed Dialing for PCS Ready Link Entries

To set Speed Dialing for PCS Ready Link entries:

1. Press  to access the main menu.
2. Select **Contacts** and press .
3. Select **Speed Dial #s** and press .
4. Highlight an unassigned number and press 
 - When you highlight an assigned number and press , you'll be asked whether you want to overwrite the assigned number. Select **Yes** or **No**, or you can also select **Unassign** to cancel the stored speed dial.
5. Press **Go to** (left softkey), highlight the list from which you want to set a speed dial (**Company List**, **Company Groups**, **Personal List**, or **Personal Groups**) and press .

6. Select the contact and press .

– or –

Select the group and press , select an option, and press .

- **Assign** to assign the selected group as a speed dial.
- **Details** to display the group details. You can select the entry from the group list.

To use Speed Dial for a PCS Ready Link entry:

- From standby mode, press the appropriate key and press and hold .

Restarting the Ready Link Service

To restart the PCS Ready Link service:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Ready Link** and press .
4. Select **Restart R-Link** and press .

Setting Ready Link Guard

This feature enables you to display the warning message when you cannot receive PCS Ready Link calls. The warning message will appear when you are launching a Web or Java application, or sending/uploading your pictures.

To set the Ready Link Guard:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Ready Link** and press .
4. Select **R-Link Guard** and press . (A message will appear.)
5. Press **OK** (left softkey) to continue.
6. Select **On** and press .
 - To deactivate this feature, select **Off** during step 6 above.

Setting Ringer Types for PCS Ready Link Calls

Your PCS Vision Phone provides a variety of ringer types that allow you to customize your ringer and volume settings.

To select a ringer type for PCS Ready Link calls:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Ready Link** and press .
4. Select **Ringer Type** and press .
5. Select the menu under **Ready Link Calls** and press .
6. Select your desired ringer type and press .
 - To confirm the ringer, press **Play** (right softkey).

Tip: You can also change the ringer type from the Settings menu (see “Selecting Ringer Types for PCS Ready Link Calls” on page 37).

Setting an Alert Notification for PCS Ready Link Calls

Your PCS Phone can alert you with an audible tone when you receive a PCS Ready Link call.

To set alerts for PCS Ready Link calls:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Ready Link** and press .
4. Select **Alerts** and press .
5. Select **Once** or **Repeat Alert** and press .

Tip: You can also set alerts from the Settings menu (see “Alert Notification” on page 42).

Setting the Speakerphone for PCS Ready Link Calls

You can set the speakerphone on or off when PCS Ready Link call is activated. By default, the speakerphone is set to on.

To set the speakerphone on or off:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Ready Link** and press .
4. Select **Speakerphone** and press .
5. Select **On** or **Off** and press .

Note: If the phone's ringer volume is set to Vibrate, Ringer off, or Silence All, the speakerphone turns off. Press  to turn the speakerphone mode on.

Setting the Default View of the PCS Ready Link List

You can select the default PCS Ready Link List when PCS Ready Link is launched.

To select the default view of the PCS Ready Link List:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **Ready Link** and press .
4. Select **Default View** and press . (The default setting is **Company List**.)
5. Select your desired list and press .

Note: If there are no data in the Company lists, your phone will display your **Personal List**.

Using Your Phone's Built-in Camera

In This Section

- ◆ Taking Pictures
 - ◆ Sending Picture Mail™
 - ◆ Storing Pictures in My Pictures
 - ◆ Managing Picture Mail™
-

Your PCS Vision Picture Phone's built-in camera gives you the ability to take full-color digital pictures, view your pictures using the phone's display, and instantly send them to your family and friends. It's fun and as easy to use as a traditional point-and-click camera: just take a picture, view it on your phone's display, and send it from your phone to up to ten people.

This section explains the features and options of your PCS Vision Picture Phone's built-in camera.

Taking Pictures

Taking pictures with your phone's built-in camera is as simple as choosing a subject, pointing the lens, and pressing a button. You can activate camera mode and take pictures whether the phone is open or closed.

To take a picture with the phone open:

1. Press  to access the main menu.
2. Select **Pictures** and press  to access the Pictures menu.
3. Select **Camera** and press  to activate camera mode.
(Additional user options are available through the camera mode **Options** menu. See "Camera Mode Options" on page 155 for more information.)

Shortcut: To activate camera mode, you can also press and hold  or the side camera key (see illustration on page 10).

4. Using the phone's main LCD as a viewfinder, aim the camera lens at your subject.
5. To take the picture, press , , **Capture** (left softkey), or the Side Camera key. (The picture will be saved automatically in your In Camera folder.)
 - To return to camera mode to take another picture, press .
6. Press **Next** (right softkey) to go to the next step.

Steps:

- **Send Picture** to send the picture. (See page 162 for details.)
- **Upload** to upload the picture you just took to the Picture Mail Website. Depending on your settings, you may be prompted to accept a PCS Vision connection.
- **Set as Picture ID** to assign the picture as a Picture ID.
- **Set as Scrn Saver** to assign the picture as a Screen Saver.
- **Go to Camera** to return to camera mode to take another picture.
- **Pics in camera** to go to the In Camera folder to review your saved pictures.
- **Delete** to delete the picture you just took.

To take a picture with the phone closed:

1. Press and hold the side camera key to activate camera mode.
2. Point the camera lens at your subject. (You can check the picture framing through the Sub LCD.)

Note: When taking a picture with the phone closed, the subject image appears in reverse on the external display. The captured image will not be saved in reverse.

3. Press the side camera key to take the picture. (The picture will be saved automatically in your In Camera folder.)
 - Open the flip to review the picture and go to the next step.

Note: While you are taking a picture, the backlight turns on even if your backlight is set to **Always Off**.

Note: In some cases, the screen may flicker and the stripes may appear on the display under fluorescent lighting.

Creating Your Picture MailSM Password

The first time you use any of the Picture Mail management options involving the Picture Mail Website, you will need to establish a Picture Mail password through your PCS Vision Picture Phone. This password will also allow you to sign in to the Picture Mail Website at picturemail.sprintpcs.com to access and manage your uploaded pictures and albums.

To create your Picture Mail password:

1. Press  to access the main menu.
2. Select **Pictures** and press  to access the Pictures menu.
3. Select **Online Albums** and press .
4. Select **View Albums** and press . (You will be prompted to create a pictures password.)

Note: If your PCS Service Plan does not include Picture Mail, you will first be prompted to subscribe to the service for an additional monthly charge.

5. Enter a four- to eight-digit password and press  or **OK** (left softkey).
6. Please wait while the system creates your account.

Tip: Write down your Picture Mail password in a secure place.

Once your account has been successfully registered, you may upload and send pictures and access the Picture Mail Website.

Camera Mode Options

When the phone is open and in camera mode, several user options are available.

Press **Options** (right softkey) to display additional user options:

- **Flash** to activate the flash function. (See “Setting the Flash Function” on the next page for details.)
- **Self-timer** to activate the camera’s timer function. (See “Setting the Self-timer” on the next page for details.)
- **Fun Tools** to select an option from the following:
 - **Fun Frames** to select your favorite fun picture frame to decorate your picture.
 - **Multiple Shots** to take multiple shots. (See “Taking Multiple Shots” on page 157 for details.)
 - **Color Tone** to select a wide variety of color tones for the picture (**Normal**, **Sepia**, **Black & White**, **Negative**, **Posterization** or **Emboss**).
- **Image Controls** to select an option from the following:
 - **Brightness** to select **Auto** or **Manual** brightness control. If you select **Manual**, press the navigation key right (increase) or left (decrease) to select a setting and press  to apply the desired setting.
 - **White Balance** to adjust white balance based on changing conditions. Select from **Auto**, **Sunny**, **Cloudy**, **Tungsten**, **Fluorescent**, or **Manual**.
- **Camera Settings** to select **Resolution**, **Quality**, **Shutter Sound**, **Status Area**, or **Auto Delete**. (See “Selecting Camera Settings” on page 159 for details.)
- **Pics in camera** to go to your phone’s In Camera folder. (See “In Camera Folder” on page 165 for details.)

Setting the Flash Function

To activate the flash function:

1. With the phone open and in camera mode, press **Options** (right softkey).
2. Select **Flash** and press .
3. Select an option from the following and press 
 - **On This Shot** to activate the flash for one shot.
 - **On Always** to activate the flash all the time.
 - **Auto** to activate the flash automatically.
4. Take a picture using the phone's main LCD as a viewfinder.
 - To deactivate this feature, select **Off** during step 3.

Tip: When the phone is open and in camera mode, press  to switch between flash modes.

Setting the Self-timer

To activate the Self-timer:

1. With the phone open and in camera mode, press **Options** (right softkey).
2. Highlight **Self-timer** and press .
3. Highlight the length of delay you want the timer to use (**10 seconds** or **5 seconds**) and press .
4. Press **Start** (left softkey) when you are ready to start the timer. ( appears on the lower left portion of the main LCD during the Self-timer countdown.)
5. Get ready for the picture. (When the timer is down to three seconds, the Self-timer icon will turn red and the phone will begin to beep.)

Note: After taking a picture, Self-timer settings return to their default settings.

To cancel the Self-timer after it has started:

- ▶ Press **Cancel** (right softkey).

Note: While the Self-timer is active, all keys are disabled except , , and **Cancel** (right softkey).

Taking Multiple Shots

This feature allows you to take up to 8 continuous shots of one moment. When you take multiple shots,  will appear in the viewfinder.

To take multiple shots:

1. With the phone open and in camera mode, press **Options** (right softkey).
2. Highlight **Fun Tools** and press .
3. Highlight **Multiple Shots** and press .

Note: If your phone's memory is full, the "Multiple Shots" option will not appear.

4. Select your desired option from the following and press .
 - **2 Shots** to take series of 2 shots.
 - **4 Shots** to take series of 4 shots. (Only appears when the resolution setting is Low or Medium.)
 - **8 Shots** to take series of 8 shots. (Only appears when the resolution setting is Low.)
5. Select the duration of the interval between shots from **Normal** or **Fast** and press .
6. To take the pictures, press . (The Multiple Shots folder will display, up to four thumbnail pictures per screen.)
 - To deactivate this feature, select **Off** during step 4 above.

Tip: After taking multiple shots, the pictures are automatically saved in the In Camera folder. (See "In Camera Folder" on page 165 for details.)

When you are in Multiple Shots folder, several user options are available.

Press **Options** (right softkey) to display the following options:

- **Upload** to upload pictures saved in your phone to the Picture Mail Website.
- **Set as Picture ID** to display the picture as a Picture ID.
- **Set as Scrn Saver** to display the picture as a screen saver.
- **Go to Camera** to activate camera mode.
- **Pics in camera** to access the In Camera folder.
- **Delete** to delete pictures in the In Camera folder.

- **Slideshow** to display your pictures as a slideshow. (Only appears when you have two or more pictures in the folder.)
- **Info Bar** to display information on the currently highlighted picture. (Expanded picture only)
- **Thumbnail/Expand** to switch the display from full-screen to thumbnail view (up to four pictures per screen).

Using the Zoom Function

This feature allows you to zoom in on an object when you take a picture. Depending on your resolution settings, you can adjust the zoom from 1-step to 20-step.

To use the zoom function:

1. With the phone open and in camera mode, press the navigation key right or left to adjust the zoom. (The zoom icon changes as you press.)
2. Press  to take the picture. (The picture will be saved automatically in your In Camera folder.)

Note: The Zoom icons will not appear when the Resolution setting is High.

Selecting Camera Settings

To select your camera settings:

1. With the phone open and in camera mode, press **Options** (right softkey).
2. Select **Camera Settings** and press .
3. Select an option from the following and press .
 - **Resolution** to select a file size (**High**, **Medium**, or **Low**) for a picture.
 - **Quality** to select **Economy**, **Normal**, or **Fine** picture quality.
 - **Shutter Sound** to select a shutter sound. (See “Setting the Shutter Sound” below for details.)
 - **Status Area** to select a picture status display setting. Select **Off** to hide picture status, such as icons and number of captured pictures. To display the status, select **On**. (See “Viewing Your Camera’s Status Area Display” on the next page for details.)
 - **Auto Delete** to set the auto delete function. (See “Setting the Auto Delete Function” on the next page for details.)

Setting the Shutter Sound

To select the Shutter Sound:

1. With the phone open and in camera mode, press **Options** (right softkey).
2. Select **Camera Settings** and press .
3. Select **Shutter Sound** and press .
4. Select an option from the following and press .
 - **Default** plays the default shutter sound.
 - **Say “Cheez”** plays a recording of the phrase “Say Cheez.”
 - **Off** makes no sound.
 - **Record Your Own** allows you to record your own voice. Press  to display options, highlight **Record** and press . Press  to start recording. (Maximum recording time is 5 seconds.) To save the recording, press **Save** (right softkey).

Setting the Auto Delete Function


With this feature, pictures which have been uploaded to your online Picture Mail account will be erased automatically from your phone.

To set the Auto Delete function:

1. With the phone open and in camera mode, press **Options** (right softkey).
2. Select **Camera Settings** and press .
3. Select **Auto Delete** and press .
4. Select **Yes** and press  to activate the auto delete function.
 - To deactivate this feature, select **No** during step 4 above.

Note: The locked pictures will not be deleted automatically.

Viewing Your Camera's Status Area Display



Icon Indication

No.	Function		Icons	Details
1	Flash	On This Shot		To use a flash only one shot after setting this function.
		On Always		To use a flash every time you take a picture.
		Auto		To use the auto flash function.
2	White Balance	Sunny		Use this setting for sunny weather.
		Cloudy		Use this setting for cloudy weather.
		Tungsten		Use this setting for tungsten lighting.
		Fluorescent		Use this setting for fluorescent lighting.
		Manual		For the manual setting of white balance.
3	Brightness	Manual		For the manual setting of brightness.
4	Zoom	1 step		For 1-step zoom. Appears when the resolution setting is Medium or Low.
		2 step		For 2-step zoom. Appears when the resolution setting is Medium or Low.
		8 step		For 8-step zoom. Appears when the resolution setting is Low.
				For 8-step zoom. Appears when the resolution setting is Medium.
		20 step		For 20-step zoom. Appears when the resolution setting is Low.
5	Multiple Shots			Use this setting for Multiple Shots.
6	Memory Gauge			Shows the remaining memory.
	Picture Number			The number of stored pictures.
	Remaining Pictures			The count of pictures you can take with current resolution.
7	Self-timer			Use this setting for self portraits. Numeric countdown will appear during the self-timer countdown.
8	Resolution	High		For high picture resolution.
		Medium		For medium picture resolution.
		Low		For low picture resolution.

Sending Picture MailSM

Once you've taken a picture, you can use the messaging capabilities of your PM-8200 by Sanyo to instantly send it to family and friends. You can send a picture to up to ten people at a time using their email addresses or their PCS Vision Phone numbers.

Sending Picture Mail From the In Camera Folder

To send Picture Mail from the In Camera folder:

1. With the clamshell open, press  to access the Pictures menu.
2. Select **My Pictures** and press .
3. Select **In Camera** and press .
4. Press  to select a picture. (The check box on the lower right corner will be marked. You can select multiple pictures.)
If there is no selected picture, the currently highlighted picture will be selected.
5. Press **Send** (left softkey).
6. Select an option from the following and press .
 - **From Phone Book** to select a recipient from your Contacts list.
Highlight a recipient and press  to select.
 - **Mobile Phone#** to enter a mobile phone number directly.
 - **Email Address** to enter an email address directly.

Note: If there are no entries in your contact list, you will be prompted to enter either an email address or a mobile phone number.

Note: The  and  icons next to contact's names represent Mobile Phone and email. When entering a new contact, use your navigation key to select the correct icon for the entry. You can also select both the mobile phone number and email address at once by selecting  icon.

7. Press **Next** (left softkey) when you are finished selecting/entering recipients. (You may include up to ten recipients per Picture Mail.)

8. If you wish to record and include a Voice Memo with the picture you are sending, highlight the box under **Voice Memo** and press **Record** (right softkey). Press  to start recording. (Maximum recording time is 10 seconds.)
9. If you wish to enter a text message, highlight the box under **Message** and press **Change** (right softkey). Enter your message using your keypad (or press **Mode** [right softkey] to select from **Preset Messages** or **Recent Messages**) and press . (See “Entering Text” on page 31.)
10. Confirm the recipients, message, voice memo, and picture.
 - To change a recipient, highlight the recipient, press **Change** (right softkey), and follow the instructions in step 6 on the previous page to select or edit the recipient.
 - To change Voice Memo, highlight the box beneath **Voice Memo** and press **Options** (right softkey) to display options:
 - VoiceMemo Play** to play the attached voice memo.
 - VoiceMemo Rec** to re-record the voice memo.
 - VoiceMemo Erase** to delete the voice memo from the Picture Mail.
 - To change the attached message, highlight the box beneath **Message** and press **Change** (right softkey).
 - To change the attached pictures, select a thumbnail picture using your navigation key and press **Change** (right softkey). Select an alternate picture and press , then press **Next** (left softkey).
11. Press **Send** (left softkey) to send the Picture Mail.

Sending Picture Mail from Messaging

You can also send your pictures from your phone's Messaging menu.

To send Picture Mail from the Messaging menu:

1. Press  to access the main menu.
2. Select **Messaging** and press  to access the Messaging menu.

Shortcut: Press the navigation key up from standby mode to access the Messaging menu.

3. Select **Picture Mail** and press .
4. Select **Send Picture** and press .
5. Select **From My Pics.** and press . (The In Camera folder will display, up to four thumbnail pictures per screen.)
6. Use the navigation key to display the picture you wish to send and press . (You can select multiple pictures.)

Tip: To expand a selected picture from thumbnail to full-screen, press and hold .

7. Press **Next** (left softkey). To complete and send the Picture Mail, follow steps 6-11 in "Sending Picture Mail From the In Camera Folder" on page 162.

Tip: If you want to take a new picture and send it, select **Take Picture** during step 5 above. Take the new picture, press **Next** (right softkey) and follow steps 6-11 in "Sending Picture Mail From the In Camera Folder" on page 162.

Storing Pictures in My Pictures

My Pictures is your phone's picture storage area. There are two types of folders in My Pictures that can be used separately according to your needs. They are:

- **In Camera Folder** (see below)
- **Saved to Phone Folder** (see page 168)

In Camera Folder

Once a picture is taken, it is automatically saved to the folder called "In Camera." You can enter the In Camera folder from **My Pictures** menu by selecting **In Camera**. From the In Camera folder, you can view all the pictures you have taken, store selected images in your phone, send pictures to the Picture Mail Website, delete images, and access additional picture options.

To review your stored pictures in the In Camera folder:

1. Press  to access the main menu.
2. Select **Pictures** and press  to access the Pictures menu.
3. Select **My Pictures** and press .
4. Select **In Camera** and press . (Thumbnail pictures will display, up to four pictures at a time.)
5. Use your navigation key to view and scroll through pictures.

In Camera Folder Options

When you are in the In Camera folder, several user options are available.

Press **Options** (right softkey) to display the following options:

- **Upload** to select an option from the following to upload pictures saved in your phone to the Picture Mail Website. Depending on your settings, you may be prompted to accept a PCS Vision connection.
 - **This Picture** to upload the currently highlighted picture.
 - **Selected Pictures** to upload the selected pictures. Press  to select a picture (the check box on the lower right corner will be marked).
 - **All Pictures** to upload all the pictures in your phone.

Note: Erasing pictures will free up memory space in your phone to enable you to take more pictures. Once erased, pictures cannot be uploaded to your online Picture Mail account or saved to the Saved to Phone folder.

- **Set as Picture ID** to display the currently highlighted picture for incoming calls from a specific Contacts List entry. Select your desired entry and press .
- **Set as Scrn Saver** to display the currently highlighted picture as a screen saver.
- **Details/Edit** to display the currently highlighted picture's details or edit the pictures. You can select from **Text Caption**, **Picture Info**, **Color Tone**, or **Rotate Picture**.
- **Delete** to delete pictures in the In Camera folder. Select **This Picture**, **Selected Pictures**, or **All Pictures**.
- **Lock** to lock your picture to protect from unintentional deletion.
- **Unlock** to unlock your picture.
- **Save to Phone** to save the selected images in the Saved to Phone folder.
- **Sort by Date** to sort pictures by date. (Thumbnail picture only.) Select **Taken-Descending**, **Taken-Ascending**, **Uploaded-Descend**, or **Uploaded-Ascend**.
- **Slideshow** to display your pictures as a slideshow. (Only appears when you have two or more pictures in the folder.)

- **Info Bar** to display information on the selected picture, such as folder name, picture number, caption, etc. Select **On** to display the caption of a picture; select **Off** to hide the information. (Expanded picture only.)


Tip: From expanded picture display, press the navigation key up or down to hide or display the Info Bar.

- **Thumbnail/Expand** to switch the display from full-screen to thumbnail view (up to four pictures per screen).
- **Go to Saved to Ph.** to access the Saved to Phone folder.
- **Go to Camera** to activate camera mode.

Note: **Save to Phone** and **Upload** copy pictures from your phone's In Camera folder to your Saved to Phone folder or your online Picture Mail account. Pictures that have been stored to your Saved to Phone folder or uploaded to your online account will remain available in the In Camera folder until you erase them.

Note: If this is the first time you have accessed the Picture Mail account, you will be prompted to create your Picture Mail password. (See "Creating Your Picture Mail Password" on page 154.)

In Camera Folder



Saved to Phone Folder

When you assign or download a picture, the picture will be saved automatically to the separate folder called “Saved to Phone.”

The Saved to Phone folder allows you to store copies of pictures on your phone and to assign pictures to various phone tasks.

To save a picture to the Saved to Phone folder:

1. From the In Camera folder (see “In Camera Folder” on page 165), select a picture you wish to save to the Saved to Phone folder and press . (You may select multiple pictures.)
2. Press **Options** (right softkey). (The In Camera folder options will display.)
3. Select **Save to Phone** and press . (A copy of the picture will be saved to the Saved to Phone folder.)

To view pictures stored in the Saved to Phone folder:

1. Press  to access the main menu.
2. Select **Pictures** and press .

Shortcut: Instead of steps 1 and 2 above, press .

3. Select **My Pictures** and press .
4. Select **Saved to Phone** and press . (Thumbnail pictures will display, up to four pictures at a time.)
5. Use your navigation key to view and scroll through pictures.
6. To expand the selected picture, press **Expand** (left softkey).

Tip: From expanded view, press and hold the navigation key right or left to display the stored picture continuously.


7. Press **Options** (right softkey) to display a list of options for the selected picture. To select an option, highlight it and press .
 - **Set as Picture ID** to display the currently highlighted picture for incoming calls from a specific Contacts List entry.
 - **Set as Scrn Saver** to display the currently highlighted picture as a screen saver.

- **Details/Edit** to display the currently highlighted picture's details or edit the pictures. You can select from **Text Caption**, **Picture Info**, **Color Tone**, or **Rotate Picture**.
- **Delete** to delete pictures stored in the Saved to Phone folder. Select **This Picture**, **Selected Pictures**, or **All Pictures**.
- **Lock** to lock your picture to protect from unintentional deletion.
- **Unlock** to unlock your picture.
- **Sort by Date** to sort pictures by date. (Thumbnail picture only.) Select **Saved-Descending**, or **Saved-Ascending**.
- **Slideshow** to display your pictures as a slideshow. (Only appears when you have two or more pictures in the folder.)
- **Info Bar** to display information on the currently highlighted picture, such as folder name, picture number, caption, etc. (Expanded picture only.)
- **Pics in camera** to access the In Camera folder.
- **Go to Camera** to activate camera mode.

Note: Pictures may be assigned to more than one task.

Note: Assigned pictures will be identified with the .

Saved To Phone Folder



Managing Picture Mail

Using the Picture Mail Website

Once you have uploaded pictures from your phone to your online Picture Mail account (see “In Camera Folder” on page 165), you can use your personal computer to manage your pictures. From the Picture Mail Website you can send pictures, edit album titles and picture captions, organize and move images, and do much more.

You will also have access to picture management tools to improve and customize your pictures. You'll be able to lighten, darken, crop, add antique effects, add comic bubbles and cartoon effects, and use other features to transform your pictures.

To access the Picture Mail Website:

1. From your computer's Internet connection, go to www.picturemail.sprintpcs.com.
2. Enter your PCS Phone Number and Picture Mail password to sign on. (See “Creating Your Picture Mail Password” on page 154.)

Managing Online Picture Mail From Your PCS Vision Phone

You can use your phone to manage, edit, or send pictures you have uploaded to the Picture Mail Website. (See “In Camera Folder Options” on page 166 for information about uploading.)

To view your online Picture Mail from your PCS Vision Phone:

1. Press  to access the main menu.
2. Select **Pictures** and press  to access the Pictures menu.

Shortcut: Instead of steps 1 and 2 above, press .

3. Select **Online Albums** and press .
4. Select **View Albums** and press . (Depending on your settings you may be prompted to accept a PCS Vision connection.) (The Uploads folder and your albums will appear.)
5. Highlight **Uploads** or an album title and press  to display. (Thumbnail pictures, up to four per screen are displayed.)

Tip: To expand a selected picture from thumbnail to full-screen, press and hold .

6. Use your navigation key to select a picture.

Uploading Your Pictures

To upload pictures:

1. Press  to access the Pictures menu.
 2. Select **Online Albums** and press .
 3. Select **Upload Pics** and press .
 4. Use your navigation key to select a picture, and press **Upload** (left softkey).
 5. Select an option from the following and press .
- **This Picture** to upload the currently highlighted picture.
 - **Selected Pictures** to upload the selected pictures. Press  to select a picture (the check box on the lower right corner will be marked).
 - **All Pictures** to upload all the pictures in your phone.

Sending Online Picture Mail

To send pictures from the online Address Book:

1. From the online Picture Mail display, select a picture you wish to send and press **Send** (left softkey). (See “Managing Online Picture Mail From Your PCS Vision Phone” on the previous page.)
2. Select **Online Addr. Book** and press .
3. To select a recipient, highlight a recipient and press . (You may select up to 10 recipients.)
4. Press **Done** (left softkey) when you are finished selecting recipients.
5. To complete and send the Picture Mail, follow steps 8-11 in “Sending Picture Mail From the In Camera Folder” on page 163.

To send an album from online mode:

1. From the online Albums display, select an album you wish to send and press **Send** (left softkey). (See “Managing Online Picture Mail From Your PCS Vision Phone” on the previous page.)
2. Follow steps 2-5 above to complete and send your Picture Mail.

Accessing Online Picture Mail Options From Your PCS Vision Phone

1. Select a picture from your online Picture Mail (see “Managing Online Picture Mail From Your PCS Vision Phone” on page 170).
2. Press **Options** (right softkey) to display options.
3. To select an option, highlight it and press .
 - **Copy/Move** to copy or move pictures to a selected album:
 - Move This** to move the currently highlighted picture to the album.
 - Move Selection** to move the selected pictures to the album.
 - Move All** to move all pictures in the current album (or Uploads) to the target album.
 - Copy This** to copy the currently highlighted picture to the album.
 - Copy Selection** to copy the selected pictures to the album.
 - Copy All** to copy all pictures in the current album (or Uploads) to the target album.

Tip: Press **New** (right softkey) to copy/move pictures to a new folder.

- **Details/Edit** to select **Text Caption**, **Picture Info**, or **Rotate Picture**.
 - Text Caption** to edit the caption of a currently highlighted picture.
 - Picture Info** to display information on the currently highlighted picture, such as caption, time/date, size, etc.
 - Rotate Picture** to rotate the currently highlighted picture. After selecting this option, you can rotate the currently highlighted picture by pressing the navigation key right or left, or **Rotate** (right softkey).
- **Delete** to select **This Picture**, **Selected Pictures**, or **All Pictures** to erase a single picture, selected pictures, or all pictures saved in the current album (or Uploads).

- **Save to Phone** to download to the Saved to Phone folder to assign the pictures to the phone task.
 - as **Picture ID** to display the currently highlighted picture for incoming calls from a specific Contacts List entry.
 - as **Screen Saver** to display the currently highlighted picture as a screen saver.
 - Download Only** to only download the picture to the Saved to Phone folder.
- **Info Bar** to display picture's information, such as folder name, picture number, caption, etc. Select **On** to display the information; select **Off** to hide the information. (Expanded picture only.)

Tip: From expanded picture display, press the navigation key up or down to hide or display the Info Bar.

- **Thumbnail/Expand** to switch the display from thumbnail view (up to four pictures per screen) to full-screen.
- **Create Album** to create a new album (from Uploads only). Enter the album name and select **Save** (left softkey).
- **Online Albums** to switch the display to the online album list.

To access your online Albums options from your PCS Vision Phone:

1. Display the album list in the online Picture Mail menu (see "Managing Online Picture Mail From Your PCS Vision Phone" on page 170).
2. Use your navigation key to select an album (or Uploads).
3. Press **Options** (right softkey) to display options.
4. To select an option, highlight it and press .
 - **Create Album** to create a new album. Enter a new album name and press **Save** (left softkey).
 - **Delete Album** to delete the selected album.
 - **Rename Album** to rename the selected album. Enter a new name and press **Save** (left softkey).

Note: Uploads cannot be erased or renamed.

- **Album Info** to display album information: name, created time/date, and the number of stored pictures.

PCS Service Features



PCS Service Features: The Basics

In This Section

- ◆ Using Voicemail
 - ◆ Using Caller ID
 - ◆ Responding to Call Waiting
 - ◆ Making a Three-Way Call
 - ◆ Using Call Forwarding
-

Now that you've mastered your phone's fundamentals, it's time to explore the calling features that enhance your **PCS Service**. This section outlines your basic PCS Service features.

Using Voicemail

Setting Up Your Voicemail

All unanswered calls to your PCS Vision Phone are automatically transferred to your voicemail, even if your phone is in use or turned off. Therefore, you will want to set up your PCS Voicemail and personal greeting as soon as your PCS Vision Phone is activated.

To set up your voicemail:

1. Press and hold  1.
2. Follow the system prompts to:
 - Create your passcode
 - Record your greeting
 - Record your name announcement
 - Choose whether or not to activate One-Touch Message Access (a feature that lets you access messages and bypassing the need for you to enter your passcode)

Note: The voicemail setup process may vary in certain Affiliate areas.

Voicemail Notification

There are several ways your PCS Vision Phone alerts you of a new message:

- By displaying a message on the screen.
- By sounding the assigned ringer type.
- By the LED blinking red.
- By displaying  at the top of your screen.

New Voicemail Message Alerts

When you receive a new voice message, your phone alerts you and prompts you to call your voicemail.

To call your voicemail:

- ▶ Press .

To display your Missed Log:

- ▶ Press  or **OK** (left softkey).

Important: When you are roaming off the Sprint Nationwide PCS Network, you may not receive notification of new voicemail messages. It is recommended that you periodically check your voicemail by dialing 1 + area code + your PCS Phone Number. When your voicemail answers, press  and enter your passcode. You will be charged roaming rates when accessing voicemail while roaming off the Sprint Nationwide PCS Network.

Note: Your phone accepts messages even when it is turned off. However, you are only notified of new messages when your phone is turned on and you are in a PCS Service Area.

Retrieving Your Voicemail Messages

You can review your messages directly from your PCS Vision Phone or from any other touch-tone phone. To dial from your PCS Vision Phone, you can either speed dial your voicemail or use the menu keys.

Using One-Touch Message Access

- ▶ Press and hold . (Your phone will dial your voicemail box.)

Using the Menu Keys on Your Phone to Access Your Messages

1. Press  to access the main menu.
2. Select **Messaging** and press .
3. Select **Voicemail** and press .
4. Select **Call Voicemail** and press .

Note: You are charged for airtime minutes when you are accessing your voicemail from your PCS Vision Phone.

Using a Phone Other Than Your PCS Vision Phone to Access Messages

1. Dial your PCS Phone number.
2. When your voicemail answers, press **✕**.
3. Enter your passcode.

Tip: When you call into voicemail you first hear the header information (date, time, and sender information) for the message. To skip directly to the message, press **4** during the header.

Voicemail Button Guide

Here's a quick guide to your keypad functions while listening to voicemail messages. For further details and menu options, see "Voicemail Menu Key" on page 182.

1	2	3
Date/Time	Send Reply	Advance
4	5	6
Replay	Rewind	Forward
7	8	9
Erase	Call Back	Save
✕	0	#
Cancel	Help	Skip

Vicemail Options

Your PCS Vision Phone offers several options for organizing and accessing your voicemail.

Using Expert Mode

Using the Expert Mode setting for your personal voicemail box helps you navigate through the voicemail system more quickly by shortening the voice prompts you hear at each level.

To turn Expert Mode on or off:

1. Press and hold **☎1** to access your voicemail. (If your voicemail box contains any new or saved messages, press **✕** to access the main voicemail menu.)
2. Press **3** to change your Personal Options, following the system prompts.
3. Press **4** for Expert Mode.
4. Press **1** to turn Expert Mode on or off.

Setting Up Group Distribution Lists

Create up to 20 separate group lists, each with up to 20 customers.

1. Press and hold **☎1** to access your voicemail. (If your voicemail box contains any new or saved messages, press **✕** to access the main voicemail menu.)
2. Press **3** to change your Personal Options, following the system prompts.
3. Press **2** for Administrative Options.
4. Press **5** for Group Distribution Lists.
5. Follow the voice prompts to create, edit, rename, or delete group lists.

PCS Callback

Return a call after listening to a message without disconnecting from voicemail.

- ▶ Press **8** after listening to a message. (Once the call is complete, you're returned to the voicemail main menu.)

Voicemail-to-Voicemail Message

Record and send a voice message to other PCS Voicemail users.

1. From the main voicemail menu, press **2** to send a message.
2. Follow the voice prompts to enter the phone number.
3. Follow the voice prompts to record and send your voice message.

Voicemail-to-Voicemail Message Reply

Reply to a voice message received from any other PCS Voicemail user.

1. After listening to a voice message, press **2**.
2. Follow the voice prompts to record and send your reply.

Voicemail-to-Voicemail Message Forwarding

Forward a voice message, except those marked “Private,” to other PCS Voicemail users.

1. After listening to a message, press **6**.
2. Follow the voice prompts to enter the phone number.
3. Follow the voice prompts to record your introduction and forward the voice message.

Voicemail-to-Voicemail Receipt Request

Receive confirmation that your voice message has been listened to when you send, forward, or reply to other PCS users.

1. After you have recorded a message, press **1** to indicate you are satisfied with the message you recorded.
2. Press **4** to mark receipt requested.
3. Press **1** to send your voicemail message.

Continue Recording

When leaving a voice message, you can choose to continue recording even after you've stopped.

- ▶ Before pressing **1** to indicate that you are satisfied with the message you recorded, press **4** to continue recording.

Extended Absence Greeting

When your phone is turned off or you are off the Sprint Nationwide PCS Network for an extended period, this greeting can be played instead of your normal personal greeting.

1. From the main voicemail menu, press **3** for Personal Options.
2. Press **3** for Greetings.
3. Press **3** to record an Extended Absence Greeting.

Clearing the Message Icon

Your phone may temporarily continue to display the message icon after you have checked your voice and text messages.

To clear the icon from the display screen:

1. Press **MENU OK** to access the main menu.
2. Select **Messaging** and press **MENU OK**.
3. Select **Voicemail** and press **MENU OK**.
4. Select **Clear Count** and press **MENU OK**.
5. Select **Yes** and press **MENU OK**.

Vicemail Menu Key

Following the prompts on the voicemail system, you can use your keypad to navigate through the voicemail menu. The following list outlines your phone's voicemail menu structure.

- 1** Listen
 - 1** Envelope Information
 - 2** Reply
 - 3** Advance 8 Seconds
 - 4** Replay
 - 5** Rewind
 - 6** Forward Message
 - 7** Erase
 - 8** Callback
 - 9** Save
 - 0** Options
- 2** Send a Message
- 3** Personal Options
 - 1** Notification Options
 - 1** Phone Notification
 - 2** Numeric Paging to a PCS Phone
 - ✕** Return to Personal Options Menu
 - 2** Administrative Options
 - 1** Skip Pass code
 - 2** Autoplay
 - 3** Message Date & Time On/Off
 - 4** Change Pass code
 - 5** Group Distribution List
 - ✕** Return to Personal Options Menu
 - 3** Greetings
 - 1** Personal Greetings
 - 2** Name Announcement
 - 3** Extended Absence Greeting
 - ✕** Return to Personal Options Menu
 - 4** Expert Mode (On/Off)
- 8** Place a Call
- ✕** Disconnect

Using Caller ID

Caller ID allows people to identify a caller before answering the phone by displaying the number of the incoming call. If you do not want your number displayed when you place a call, just follow these easy steps.

To block your phone number from being displayed for a specific outgoing call:

1. Press **✕** **6** **7**.
2. Enter the number you want to call.
3. Press **TALK**.

To permanently block your number, call PCS Customer Solutions.

Responding to Call Waiting

When you're on a call, Call Waiting alerts you of incoming calls by sounding two beeps. Your phone's screen informs you that another call is coming in and displays the caller's phone number (if it is available and you are in digital mode).

To respond to an incoming call while you're on a call:

- ▶ Press **TALK** (or press **Options** [right softkey], highlight **Flash**, and press **MENU OK**). (This puts the first caller on hold and answers the second call.)

To switch back to the first caller:

- ▶ Press **TALK** again (or press **Options** [right softkey], highlight **Flash**, and press **MENU OK**).

Tip: For those calls where you don't want to be interrupted, you can temporarily disable Call Waiting by pressing **✕** **7** **0** before placing your call. Call Waiting is automatically reactivated once you end the call.

Making a Three-Way Call

With Three-Way Calling, you can talk to two people at the same time. When using this feature, the normal airtime rates will be charged for each of the two calls.

To make a Three-Way Call:

1. Enter a number you wish to call and press **TALK** or **SPEAKER**.
2. Once you have established the connection, press **TALK** (or press **Options** [right softkey], highlight **Three-Way Call**, and press **MENU OK**). (This puts the first caller on hold.)
3. Dial the second number you wish to call and press **TALK** (or press **Options** [right softkey], highlight **Call** or **Call:Speaker On**, and press **MENU OK**).
4. When you're connected to the second party, press **TALK** again (or press **Options** [right softkey], highlight **Flash**, and press **MENU OK**) to begin your three-way call.

If one of the people you called hangs up during your call, you and the remaining caller stay connected. If you initiated the call and are the first to hang up, all three callers are disconnected.

Tip: You can also begin a Three-Way Call by displaying a phone number stored in your Contacts, Call History, or Messaging. To call the third party, press **MENU OK** during step 3 above.

Note: Call Waiting and Three-Way Calling are not available while roaming off the Sprint Nationwide PCS Network.

Using Call Forwarding

Call Forwarding lets you forward all your incoming calls to another phone number – even when your phone is turned off. You can continue to make calls from your phone when Call Forwarding is activated.

To activate Call Forwarding:

1. Press **✖ 7 2**.
2. Enter the area code and phone number to which your future calls should be forwarded.
3. Press **TALK**. (You will hear a tone to confirm the activation of Call Forwarding.)

To deactivate Call Forwarding:

1. Press **✖ 7 2 0**.
2. Press **TALK**. (You will hear a tone to confirm the deactivation.)

Note: You are charged a higher rate for calls you have forwarded.

Note: PCS Ready Link calls cannot be forwarded. If Call Forwarding is activated, incoming PCS Ready Link calls will not be completed.

PCS VisionSM

In This Section

- ◆ Getting Started With PCS Vision
 - ◆ Understanding Messaging
 - ◆ Using Email
 - ◆ Accessing Alternate Email Providers
 - ◆ Using Instant Messaging
 - ◆ Experiencing Wireless Online Chat
 - ◆ Downloading Premium Services Content
 - ◆ Accessing Games
 - ◆ Accessing Ringers
 - ◆ Accessing Screen Savers
 - ◆ Exploring the Web
 - ◆ Using PCS Business Connection
 - ◆ PCS Vision FAQs
-

PCS VisionSM brings you clarity you can see and hear with advanced multimedia services. These features, including PCS Messaging, games, downloadable ringers and screen savers, Web access, and PCS Business ConnectionSM are easy to learn and use. The rich, colorful graphic experience is visually comparable to your home or office computer. Clearly, it's a whole new way to look at wireless.

This section introduces these advanced services and walks you through the necessary steps to start taking advantage of PCS Vision.

Getting Started With PCS Vision

With your PCS Vision Phone and PCS Service, you are ready to start enjoying the advantages of PCS Vision. This section will help you learn the basics of using your PCS Vision services, including managing your User Name, launching a Vision connection, and navigating the Web with your PCS Vision Phone.

Your User Name

When you buy a PCS Vision Phone and sign up for service, you're automatically assigned a User Name. A User Name is typically based on your name and a number, followed by "@sprintpcs.com." For example, the third John Smith to sign up for PCS Vision services might have jsmith003@sprintpcs.com as his User Name. If you want a particular User Name, you can visit www.sprintpcs.com and get the name you want – as long as nobody else has it.

When you use PCS Vision services, your User Name is submitted to identify you to the Sprint Nationwide PCS Network. The User Name is also useful as an address for Email, as a way to personalize Web services, and as an online virtual identity.

Your User Name will be automatically programmed into your PCS Vision Phone. You don't have to enter it.

Updating Your User Name

When you change the programmed User Name and select a new one, you have to update your User Name through your PCS Phone.

To update your User Name:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **PCS Vision** and press .
4. Select **Update Profile** and press .
 - If you want to cancel, press  while processing.

Finding Your User Name

If you aren't sure what your PCS Vision User Name is, you can easily find it online or on your PCS Vision Phone.

To find your User Name:

- **At www.sprintpcs.com.** Sign on to your account using your PCS Phone Number and password. To view your PCS Vision User Name, click on the **My Personal Information** menu and then click **PCS Vision User Name**.
- **On your PCS Vision Phone.** To find your User Name, access your phone's main menu, go to **Settings > Phone Info > Phone#/User ID**.

Launching a PCS Vision Connection

To launch a PCS Vision connection:

1. Press **MENU OK** to access the main menu.
2. Select **Web** and press **MENU OK**. (Your PCS Vision connection will launch and the PCS Vision Home page will display.)

The PCS Vision Home Page



Shortcut: You can also press **Web** (right softkey) in standby mode.

Note: If Net Guard is enabled and displayed (see the next page), press **OK** (left softkey) to continue and launch the Web.

Tip: When Ready Link Guard is set to On, a warning message will appear. Press **Continue** (left softkey) to continue. (See page 149 for Ready Link Guard.)

While connecting, the following will appear on the screen:

Connecting...Please wait..

If you had a previous PCS Vision connection, the last page you visited (for example, Email or ESPN Top News) will display when you launch your browser. When this occurs, you may not see the “Connecting...” message when you launch the session. Though the browser is open, you are not currently in an active data session - that is, no data is being sent or received. As soon as you navigate to another page, the active session will launch and you will see the “Connecting...” message.

Net Guard

When you first connect to the Web, the Net Guard will appear to confirm that you want to connect. This feature helps you avoid accidental connections. You can disable the Net Guard in the future by selecting **Always Auto-Connect** when the Net Guard is displayed.

To change your Net Guard settings:

1. Press  to access the main menu.
2. Select **Settings** and press .
3. Select **PCS Vision** and press .
4. Select **Net Guard** and press .
5. Select **On** or **Off** and press .
 - **On** to activate the Net Guard.
 - **Off** to deactivate the Net Guard.

Note: When enabled, the Net Guard appears only once per session. The Net Guard does not appear if the phone is merely re-connecting due to a time-out.

PCS Vision Connection Status and Indicators

Your phone's display lets you know the current status of your PCS Vision connection through indicators which appear at the top of the screen. The following symbols are used:

-  Your PCS Vision connection is active (data is being transferred); the transmit/receive symbol will blink to indicate data transmission. Incoming voice calls go directly to voicemail; outgoing voice calls can be made, but the PCS Vision connection will terminate.
-  Your PCS Vision connection is dormant (no data is being sent or received). Though not currently active, when dormant the phone can restart an active connection quickly; voice calls can be made and received.
-  Your phone is not currently able to access PCS Vision service features.

If no indicator appears, your phone does not have a current PCS Vision connection. To launch a connection, see "Launching a PCS Vision Connection" on the previous page.

Navigating the Web

Navigating through menus and Websites during a PCS Vision session is easy once you've learned a few basics. Here are some tips for getting around:

Softkeys

During a PCS Vision session, the bottom line of your phone's display contains one or more softkeys. These keys are shortcut controls for navigating around the Web, and they correspond to the softkey buttons directly below the phone's display screen.

Tip: Depending on which Websites you visit, the labels on the softkeys may change to indicate their function.

To use softkeys:

- ▶ Press the desired softkey button. (If an additional pop-up menu appears when you press the softkey button, select the menu items using your keypad [if they're numbered] or by highlighting the option and pressing .)



Scrolling

As with other parts of your phone's menu, you'll have to scroll up and down to see everything on some Websites.

To scroll line by line through Websites:

- ▶ Press the navigation key up or down.

To scroll page by page through Websites:

- ▶ Press the volume buttons on the side of the phone.

Selecting

Once you've learned how to use softkeys and scroll, you can start navigating the Web.

To select on-screen items:

- ▶ Use the navigation key to highlight the desired item, then press the desired softkey button (or press )

Tip: You'll find that the left softkey is used primarily for selecting items. This softkey is often labeled "Go."

Tip: If the items on a page are numbered, you can use your keypad (number keys) to select an item. (The tenth item in a numbered list may be selected by pressing the  key on your phone's keypad, even though the number 0 doesn't appear on the screen.)

Links allow you to jump to different Web pages, select special functions, or even place phone calls.

To select links:

- ▶ Highlight the link and select the appropriate softkey.

Going Back

To go back one page:

- ▶ Press the  key on your phone.

Note: The  key is also used for deleting text (like a BACKSPACE key) when you are entering text.

Going Home

To return to the PCS Vision Home page from any other Web page:

- ▶ Press the right softkey, then highlight **Home** and press **OK** (left softkey).

Tip: You can also return to the PCS Vision Home page by pressing and holding the  key.



PCS Messaging

Understanding Messaging

Now you can send and receive emails and text messages and participate in Web-based chatrooms right from your PCS Vision Phone. Messaging allows you to stay connected to friends, family, and co-workers 24 hours a day anywhere on the Sprint Nationwide PCS Network.

Note: In some instances, when you receive a text message, characters with accents will be displayed as question marks.

Message Types

There are many types of text messaging available on your phone. These appear on your screen as **Notifications** and include numeric messages (pages), Messages, Updates, and Mail.

(PCS Voicemail provides voicemail-to-mailbox messaging. For information on using your phone's voicemail feature, see "Using Voicemail" on page 176.)

New Messages

When you receive a new Message, your phone will alert you. Press **View** (left softkey) to display the message details.

- Press **Call** (left softkey) to dial the phone number. (Appears when a phone number is highlighted.)
- Press **Reply** (left softkey) to reply to the message. (Appears when a phone number or email address is highlighted.)
- Press **Go** (left softkey) to go to the Website. (Appears when a URL is highlighted.)
- Press **Forward** (left softkey) to forward the message. (Appears only if there are no phone numbers or URLs in the message.)
- Press **Options** (right softkey) to display options. (See page 197 for details.)

Tip: When you highlight a phone number, the left softkey may display **Call** or **Reply** depending on the circumstance.

Tip: To make a Ready Link call from the message, press and hold  (if applicable).

Message Storage

Your PCS Phone can store up to 200 received and 180 sent Messages. When the message memory is full, the oldest unlocked message will be deleted automatically. (See page 198 for locking messages.)

Displaying Messages

To display a Message from the message notification alert, see “New Messages” on the previous page.

To display a Message from the main menu:

1. Press  to access the main menu.
2. Select **Messaging** and press .
3. Select **Text Msg** and press . (The folder list appears.)
4. Select **Inbox**, **Sent**, **Outbox**, **Drafts**, or your defined folder and press . (The message list appears.)
5. Highlight the header of the message you want to see and press . (The message detail appears.)

If the sender's or addressee's information has already been stored in the Contacts list, the corresponding name or phone number appears as the header of the message.

To read other messages:

- ▶ Press the navigation key left to read the previous message.
- ▶ Press the navigation key right to read the next message.

Displaying Picture Mail

When you receive a Picture Mail, your phone will save it into the Picture Mail Inbox automatically.

To display a Picture from the main menu:

1. Press  to access the main menu.
2. Select **Messaging** and press .
3. Select **Picture Mail** and press .
4. Select **Inbox** and press .
5. Select your desired message and press .
6. Highlight the URL in the message and press **Go** (left softkey). (The browser will launch and display the picture.)

Sending a Message

With Messaging, you can use a person's wireless phone number to send and receive text messages from your PCS Vision Phone to their messaging-ready phone – and they can send messages to you. When you receive a new message, you'll automatically be notified with a two-way text message.

To send a text message:

1. Press  to access the main menu.
2. Select **Messaging** and press .
3. Select **Send Message** and press .
4. Select **Text Message** and press .
5. Select **From Phone Book**, **Mobile Phone#**, or **Email Address** and press 
 - **From Phone Book** to select a recipient from your Contacts list. Highlight an entry and press  to select. Or select **<Add Entry>** to enter a new entry. Press **Done** (left softkey) when you are finished selecting/entering recipients.
 - **Mobile Phone#** to enter a mobile phone number directly.
 - **Email Address** to enter an email address directly.
6. To add a recipient, press **Options** (right softkey), select **Add Recipients**, and press 
 - **Edit** to edit the selected entry.
 - **Erase** to erase the selected entry.
 - **Erase All** to erase all entries you have selected/entered.
 - **Add Recipient** to add recipients.
7. Press **Next** (left softkey) when you are finished selecting/entering recipients (you may include up to 10 recipients).
8. To enter a message, select the box under **Message** and press .
9. Use your keypad to enter a text message (or press **Mode** [right softkey] to select from **Preset Messages** or **Recent Messages**), and press **OK** (left softkey).
10. To set the message priority, select the box under **Priority** and press .
11. Select **Ordinary** or **Urgent** and press .

Tip: If you select **Urgent**, the message will be sent with .

12. Press **Send** (left softkey) to send the message.

To change the recipients or to save the message as a draft, press **Options** (right softkey) and select an option from the following during steps 7-11 on the previous page.

- **Chg Recipients** to change Recipients.
- **Send Callback#** to select from **None**, **My Phone#**, or **Other** to notify your recipients of your callback number. (See “Setting a Callback Number” on page 62.)
- **Save to Drafts** to save the message to a Drafts folder. (See below to edit and send the draft message.)

Note: If there is a failure when sending a message in no-service area, you are prompted to select to send the message automatically. Press **Yes** (left softkey), and the message goes to the Outbox folder with . If you press **No** (right softkey), the message goes to the folder with . (See next page to send the message.)

Sending a Message in the Drafts Folder

To edit and send a message in the drafts folder:

1. Press  to access the main menu.
2. Select **Messaging** and press .
3. Select **Text Msg** and press .
4. Select **Drafts** and press .
5. Select the message you wish to edit and press **Edit** (left softkey).
6. After editing the message, press **Send** (left softkey) to send the message.

Tip: The oldest message in the drafts folder will be erased when you save more than 10 messages.

Sending a Message in the Outbox Folder

If a failure occurs when you try to send a message, the message goes to the Outbox folder.

To send a message from the Outbox folder:

1. Press  to access the main menu.
2. Select **Messaging** and press .
3. Select **Text Msg** and press .
4. Select **Outbox** and press .
5. Select the message you wish to send and press **Send** (left softkey).

Message Options

Several options are available when you display a folder list, message list, or message details.

Folder List Options

Select **Inbox**, **Sent**, **Outbox**, **Drafts**, or your defined folder and press **Options** (right softkey). To select an option, highlight it and press .

- **Edit Folder** to edit the folder (user-defined folder only).
- **Erase Folder** to erase the folder (user-defined folder only).
- **Create Folder** to create a new user-defined folder.
- **Compose New** to compose a new message.
- **Erase Messages** to erase messages (if applicable).

Message List Options

To display a message list, select **Inbox** (or defined folder), **Sent**, **Outbox**, or **Drafts** and press . To display your Picture Mail message list, select **Picture Mail** from the Messaging menu, press , select **Inbox**, and press . Then highlight a message and press **Options** (right softkey) to display options.

- **Reply** to reply to the message. (See page 195 to send a message.) (Inbox only.)
- **Forward** to forward the message. Select from **From Phone Book**, **Mobile Phone#**, or **Email Address**. (Inbox and Sent only.)
- **Edit** to edit a message. (Outbox and Drafts only.)
- **Send** to send a message. (Outbox and Drafts only.)
- **Move** to move a message to the Inbox or to your defined folder. Select a folder and press , or press **<Add Folder>** to create a new folder. (See page 200 to create a folder.) (Inbox only.)

- **Lock** to lock a message. Locked messages will not be erased automatically. To unlock the message, select **Unlock** and press  (Picture Mail Inbox, Inbox, and Sent only.)
- **Compose New** to compose a new message. (See page 195 to compose a new message.)
- **Erase** to erase the selected message.
- **Erase Read Msgs** to erase read messages in the folder (except locked messages). (Picture Mail Inbox, Inbox only.)
- **Erase All** to erase all messages in the folder (except locked messages). A warning message appears if there are unread messages.

Tip: Locked messages will be displayed with .

Tip: To make a call from the list, highlight a message and press  or  (if applicable).

Message Details Options

After you display the Message list in the Picture Mail Inbox, Inbox, Sent, or your defined folder, press  to display the message details. Press **Options** (right softkey) to display message options. To select an option, highlight it and press .

- **Call(Go to List)** to call a number in the message. Select a number and press  or **Call** (left softkey) to place a call. Press and hold  to make a Ready Link call.
- **Call:Speaker On** to call in speaker mode. Select a number and  or **Call** (left softkey) to place a call. Press and hold  to make a Ready Link call.
- **Prepend** to add numbers to the beginning of the phone number (if applicable).
- **Go to URL List** to display URLs in the message. Press **Go** (left softkey) or select a URL and press  to go to the site.
- **Send Message** to display phone numbers and email addresses to send a message. (See page 195 for details.) (Except Picture Mail)
- **Reply** to reply to the message. (See page 195 to send a message.) (Message in Inbox and defined folder only.)
- **Forward** to forward the message. Select from **From Phone Book**, **Mobile Phone#**, or **Email Address**. (Except Picture Mail)
- **Move** to move the message to another folder. Select a folder and press  or press **<Add Folder>** to create a new folder. (See page 200 to create a folder.) (Message in Inbox and defined folder only.)

- **Lock** to lock the message. Locked messages will not be erased automatically. To unlock the message, select **Unlock** and press .
- **Font Size** to change the font size from **Small** or **Normal**.
- **Save to Ph. Book** to save the phone number, email address, and URLs. Select a data category and press  to save.
- **Go to Phone Book** to go to the Contacts list (if applicable).
- **Compose New** to compose a new message. (See page 195 to compose a message.)
- **Erase** to erase the message.

Changing the Display Font Size of a Message

After you display a Message (except in the Outbox and Drafts folder), press **Options** (right softkey) to display message options.

To adjust the display font size:

1. Select **Font Size** and press .
2. Select **Small** or **Normal** and press .

Prepending a Phone Number From a Message

After you display a Message (except in the Outbox and Drafts folder), press **Options** (right softkey) to display message options.

To add a prefix to a phone number:

1. Select **Prepend** and press .
2. Highlight your desired phone number and press  or **OK** (left softkey).
3. Enter the digits or pauses (see below) you want to add to the number.
4. Press **TALK** or **SPEAKER** to make a call.

To select another option, press **Options** (right softkey), highlight it and press .

- **Call** to dial the phone number.
- **Call:Speaker On** to dial the phone number in speakerphone mode.
- **Save Phone#** to store the phone number in your Contacts Directory.
-  **Hard Pause** to insert a hard pause. (See “Dialing and Saving Phone Numbers With Pauses” on page 28.)
-  **2-Sec. Pause** to insert a 2-second pause. (See “Dialing and Saving Phone Numbers With Pauses” on page 28.)

Message Folders

Incoming Updates and numeric pages are stored in folders in your phone's Messaging menu. You may add your own folders or use the phone's default folder.

You can create up to ten folders to store your Messages. When ten user-defined folders exist, the "Create Folder" option will not appear.

To add a new folder:

1. Press  to access the main menu.
2. Select **Messaging** and press .
3. Select **Text Msg** and press .
4. Press **Options** (right softkey).
5. Select **Create Folder** and press .
6. Enter a folder name and press  or **OK** (left softkey).
 - Pressing **Save** (left softkey) allows you to save the folder name.
7. If you want messages to be filed into the folder automatically, select the menu under **Auto Filing** and press .
8. Select **On** and press .
9. Select the box under **Keyword** by scrolling down and press .
10. Enter a keyword and press  or **OK** (left softkey).
11. Press **Save** (left softkey).

To set an optional feature for the added folder:

1. During step 9 above, scroll down to select other menu options. Highlight the menu under each item and press 
 - **Notify** to set the display notification to on or off when you have unread messages matching the defined folder.
 - **Envelope Icon** to set the envelope icon display to on or off when you have unread messages matching the defined folder.
2. After selecting each setting, press **Save** (left softkey).

To edit a folder:

1. From the folder list display, highlight a defined folder.
2. Press **Options** (right softkey).
3. Select **Edit Folder** and press .
4. Select the box you wish to edit and press .
5. Enter or select a new folder name/setting.
6. Press  or **OK** (left softkey).
7. Press **Save** (left softkey).

Erasing All Messages

To erase all messages within a folder:

1. Press  to access the main menu.
2. Select **Messaging** and press .
3. Select **Text Msg** and press .
4. Select **Inbox**, **Sent**, **Outbox**, **Drafts**, or your defined folder and press .
5. Press **Options** (right softkey).
6. Select **Erase All** and press . (A confirmation will display.)
7. Select **Yes** and press .

Moving a Message Into Another Folder

You can move messages from the Inbox folder to a user-defined folder.

To move a message into another folder:

1. After you display a message in your Inbox folder, press **Options** (right softkey) to display the message options.
2. Highlight **Move** and press .
3. Highlight your desired folder and press . (You must have at least one defined folder to move a message.)

Erasing a Folder

To erase a text message folder:

1. From the folder list display, highlight the defined folder you want to erase.
2. Press **Options** (right softkey).
3. Highlight **Erase Folder** and press .
4. Select **Yes** and press .

Note: When you erase a folder, the messages within the folder are also erased. If the folder contains a new (unread) message or locked message, you are prompted to select **Erase** or **Don't Erase**.

Erasing Selected Messages in All Folders

To erase selected messages:

1. From the folder list display, press **Options** (right softkey).
2. Select **Erase Messages** and press .
3. Select **Read**, **Unread**, and/or **Sent** and press  to check the appropriate box(es).
4. After selecting the boxes, press **Done** (left softkey).
5. Select **Erase** and press  to erase selected messages (except locked messages).

Note: To erase an individual message, see "Message List Options" on page 197.

Signing Up for Updates

With Updates, you can have news and information sent directly to your PCS Vision Phone at the times you choose.

To select the information you want to send to your PCS Vision Phone:

1. Log on to the Internet from your computer.
2. Go to the site from which you want to receive information. (A few of the sites you can visit are America Online®, Yahoo!®, MSN® and eBay®. The location where you request updates within each site will vary.)
3. Where indicated on the site, input your 10-digit PCS Phone number followed by “@messaging.sprintpcs.com.” (For example: 5551234567@messaging.sprintpcs.com.)

Upon completing the registration process, you should begin receiving updates on your PCS Vision Phone as requested.

Using Email

With Email, you can set up an account at no additional charge and perform many of the typical email functions from your PCS Vision Phone that you can from your personal computer.

You can manage your Email account from your PCS Vision Phone or from your personal computer at www.sprintpcs.com. You can also access other select email providers from the Web through your Email.

Accessing Email Messages

To access Email messages:

1. Press  to access the main menu.
2. Select **Messaging** and press .
3. Select **Go to Email** and press . (If you're a first-time user, your phone will prompt you to set up your Email account by establishing a User Name and password.)
4. To view your messages, press **Inbox** (left softkey).
5. Scroll to select the message you wish to read and press the left softkey.
6. Once you've read a message, use the quick actions at the end of each message (**Reply**, **Reply All**, **Forward**, **Erase**, **Add to Folder**, or **Main**).

Composing Email Messages

To compose an Email message:

1. From the Email menu (see steps 1-3 above), press **Compose** (left softkey).
2. Scroll to select the address box and enter the address of the person to whom you're sending a message and press the left softkey.
3. Scroll to select the message box and enter the subject and your message.
4. Select **Send** when your message is ready to be delivered.

Accessing Alternate Email Providers

With PCS Vision, you can use popular email services such as AOL® Mail, Yahoo!® Mail, MSN Hotmail, and EarthLink® to keep in touch even while you're on the go.

Using Alternate Email Providers

To access email providers from your PCS Vision Phone:

1. From the PCS Vision Home page, select **Messaging**.
2. Select **Email**.
3. Select an email provider, such as **AOL Mail**, **Yahoo! Mail**, or **EarthLink**.
4. Use your keypad to enter the required sign in information for the selected provider, such as user name, email address, and/or password, and select **Sign In**. (Your mailbox for the selected provider will display.)

Note: The information required for sign in will vary depending on the email provider you are accessing.

5. Follow the onscreen instructions to read, reply to, compose, send, and manage your email account.

Using Instant Messaging

PCS Vision also provides you with access to popular instant messaging (IM) clients, including Yahoo!® Messenger, and AOL® Instant Messenger™.

Accessing Instant Messaging

To access instant messaging clients from your PCS Vision Phone:

1. From the PCS Vision Home page, select **Messaging**.
2. Select **Instant Messaging**.
3. Select an email provider, such as **AOL Instant Messenger** or **Yahoo! Messenger**.
4. Use your keypad to enter the required sign in information for the selected provider, such as user name and/or password, and select **Sign In**. (Your IM screen for the selected provider will display.)

Note: The information required for sign in will vary depending on the instant messaging provider you are accessing.

5. Follow the onscreen instructions to read, reply to, compose, send, and manage your IM account.

Experiencing Wireless Online Chat

PCS Vision gives you the ability to join wireless chatrooms from your PCS Vision Phone, to send text messages and icons to chatroom participants, or to launch a one-on-one (private) chatroom.

To access a chatroom from the browser:

1. Press  to access the main menu.
2. Highlight **Web** and press .
3. Select **Messaging**.
4. Select **Chat**.
5. Select **Enter**. (You will see a disclaimer for Wireless Chat.)
6. Select **I Agree** to enter the Chat menu.
7. Select a chatroom from the menu (for example, “Friends” or “Singles”).
8. Use your keypad to enter a nickname and select **Enter**. (Once in the chatroom, you may scroll through the postings to read messages from other chatroom participants.)

To post a message:

1. During an active chatroom session, select **Add text**.
2. Enter your message.
3. Select **Send**.

To set up a private chatroom:

1. During an active chatroom session, select **1->1**.
2. Select a chatter with whom you’d like to launch a private chatroom.

To exit a chatroom:

- ▶ Select **Leave Room**.

Note: To avoid inadvertent data usage charges, you should sign out of chatrooms when you are ready to exit.

Downloading Premium Services Content

With PCS Vision and your new PCS Vision Phone, you have access to a dynamic variety of Premium Service content such as downloadable Games, Ringers, Screen Savers, and other applications. The basic steps required to access and download Premium Service content are outlined below.

Accessing the Download Menus

To access the PCS Vision download menus:

1. Press  to access the main menu.
2. Select **Downloads** and press .
3. Select the type of file you wish to download (**Games, Ringers, Screen Savers, or Applications**) and press .
4. Select **Get New** and press . (The browser will launch and take you to the corresponding download menu.)

To access the PCS Vision download menus from the Web browser:

- ▶ From the PCS Vision Home page, select **Games, Ringers, or Screen Savers** to go to the corresponding download menu. (For more information on navigating the Web, see “Navigating the Web” on page 191.)

Selecting an Item to Download

You can search for available items to download in a number of ways:

- **Featured** displays a rotating selection of featured items.
- **Browse Category** allows you to narrow your search to a general category, such as Movie/TV Themes for Ringers or College Logos for Screen Savers. (There may be several pages of available content in a list. Select **Next** to view additional items.)
- **Search** allows you to use your keypad to enter search criteria to locate an item. You may enter an entire word or title or perform a partial-word search (for example, entering “goo” returns “Good Ol’ Boy,” “The Good, the Bad, and the Ugly,” and “Goofy - Club”).

Downloading an Item

Once you've selected an item you wish to download, highlight it and press  or **OK** (left softkey). You will see a summary page for the item including its title, the vendor, the download detail, the file size, and the cost. Links allow you to view the **License Details** page, which outlines the price, license type, and length of license for the download, and the **Terms of Use** page, which details the Premium Services Terms of Use and your responsibility for payment.

To download a selected item:

1. From the information page, select **Buy**. (The item will download automatically. When the **New Download** screen appears, the item has been successfully downloaded to your phone.)

Note: If you have not previously purchased an item, you will be prompted to create your purchasing profile.

2. Select an option to continue:
 - Select **Use** (left softkey) to assign the downloaded item (or to launch, in the case of a game or application).
Your PCS Vision session will end and you will be redirected to the appropriate phone menu screen.
 - Select **Shop** (right softkey) to browse for other items to download.
 - Press  to quit the browser and return to standby mode.



Games

Accessing Games

You can play a variety of entertaining and graphically-rich games on your PCS Vision Phone. New games are easy to download and play.

Tip: For complete instructions on downloading, see “Downloading Premium Services Content” on page 208.

Downloading Games

To download an available game to your phone:

1. Press to access the main menu.
2. Select **Downloads** and press .
3. Highlight **Games** and press .
4. Highlight **Get New** and press . (The browser will launch and take you to the Games download menu.)
5. Use your navigation key to highlight and select a game you wish to download. (For more information on navigating the Web, see “Navigating the Web” on page 191.)
6. Select **Buy** from the item information page. (The game will download automatically. When the **New Download** screen appears, the game has been successfully downloaded to your phone.)

Note: If you have not previously purchased an item, you will be prompted to create your purchasing profile.

7. Select an option to continue:
 - Select **Use** (left softkey) to launch the downloaded game. Your PCS Vision session will end and you will be redirected to the appropriate phone menu screen.
 - Select **Shop** (right softkey) to browse for other items to download.
 - Press to quit the browser and return to standby mode.

Playing Games

To play a downloaded game on your PCS Vision Phone:

1. Press  to access the main menu.
2. Select **Downloads** and press .
3. Highlight **Games** and press .
4. Select the game you wish to play and press .
5. Highlight **Run** and press .
6. Press **OK** (left softkey) if a prompt displays the days remaining on the game license.
7. Follow the onscreen instructions to play the game.

To quit a game:

1. When you are finished playing, press . (A prompt will display: "Resume the Application?")
2. Select **Yes** to continue playing.
– or –
Select **No** to exit.



Accessing Ringers

You can personalize your PCS Vision Phone by downloading and assigning different ringers to numbers in your Contacts list.

Tip: For complete instructions on downloading, see “Downloading Premium Services Content” on page 208.

Downloading Ringers

To download an available ringer to your phone:

1. Press  to access the main menu.
2. Select **Downloads** and press .
3. Highlight **Ringers** and press .
4. Highlight **Get New** and press . (The browser will launch and take you to the Ringers download menu.)
5. Use your navigation key to highlight and select a ringer you wish to download. (For more information on navigating the Web, see “Navigating the Web” on page 191.)
6. From the item information page, select **Buy**. (The ringer will download automatically. When the **New Download** screen appears, the ringer has been successfully downloaded to your phone.)

Note: If you have not previously purchased an item, you will be prompted to create your purchasing profile.

7. Select an option to continue:
 - Select **Use** (left softkey) to assign the downloaded ringer. Your PCS Vision session will end and you will be redirected to the appropriate phone menu screen.
 - Select **Shop** (right softkey) to browse for other items to download.
 - Press  to quit the browser and return to standby mode.

Note: You may store total of 1024 KB of downloaded data on your phone.

Assigning Downloaded Ringers

You can assign downloaded ringers directly from the Downloads menu or through your phone's Settings menu.

To assign a downloaded ringer from the Downloads menu:

1. Press  to access the main menu.
2. Select **Downloads** and press .
3. Highlight **Ringers** and press .
4. Highlight a downloaded ringer and press .
5. Highlight **Assign** and press .
6. Highlight **Voice Calls**, **Voicemail**, **Messaging**, **Calendar**, **Start-up Tone**, **Power-off Tone** or **Phone Book** and press .

The following two items need an extra step:

- **Voice Calls** requires you to highlight **With Caller ID** or **No caller ID** and press .
- **Phone Book** requires you to highlight the Contacts entry you want to assign and press .

(A message appears confirming that the ringer has been assigned.)

To assign a downloaded ringer from the Settings menu:

- ▶ See “Selecting Ringer Types for Voice Calls” on page 36;
see “Selecting Ringer Types for Voicemail” on page 38;
see “Selecting Ringer Types for Messages” on page 39;
see “Selecting Ringer Types for Calendar” on page 39;
see “Setting a Start-up/Power-off Tone” on page 40;
– or –
see “Selecting a Ringer/Image Type for an Entry” on page 95.

Note: You may assign a ringer to more than one type of call.

Purchasing Ringers

You can purchase ringers directly from your phone by following the instructions on page 209 or through www.sprintpcs.com.



Screen Savers

Accessing Screen Savers

Download unique images to use as screen savers – or make it easy to tell who's calling by assigning specific images to numbers in your Contacts list.

Tip: For complete instructions on downloading, see “Downloading Premium Services Content” on page 208.

Downloading Screen Savers

To download an available Screen Saver to your phone:

1. Press  to access the main menu.
2. Select **Downloads** and press .
3. Highlight **Screen Savers** and press .
4. Highlight **Get New** and press . (The browser will launch and take you to the Screen Savers download menu.)
5. Use your navigation key to highlight and select a Screen Saver you wish to download. (For more information on navigating the Web, see “Navigating the Web” on page 191.)
6. From the item information page, select **Buy**. (The screen saver will download automatically. When the **New Download** screen appears, the screen saver has been successfully downloaded to your phone.)

Note: If you have not previously purchased an item, you will be prompted to create your purchasing profile.

7. Select an option to continue:
 - Select **Use** (left softkey) to assign the downloaded screen saver. Your PCS Vision session will end and you will be redirected to the appropriate phone menu screen.
 - Select **Shop** (right softkey) to browse for other items to download.
 - Press  to quit the browser and return to standby mode.

Note: You may store total of 1024 KB of downloaded data on your phone.

Assigning Downloaded Screen Savers

Downloaded Screen Savers may be assigned directly from the Downloads menu or through the Settings menu.

To assign a downloaded Screen Saver from the Downloads menu:

1. Press  to access the main menu.
2. Select **Downloads** and press .
3. Highlight **Screen Savers** and press .
4. Highlight a downloaded Screen Saver and press .
5. Select **Assign** and press .
6. Highlight one of **Incoming Calls**, **Screen Saver**, or **Phone Book** and press .

The following item needs an extra step:

- **Phone Book** requires you to highlight your desired Contacts entry and press .

(A message appears confirming that the image has been assigned.)

Note: Depending on the data, you can select where to assign downloaded images: Image data can be assigned to Incoming Calls, Screen Saver, or Phone Book. Animation data can be assigned to Standby, Outgoing Calls, or Service Search.

Note: You may assign a Screen Saver to more than one task.

Purchasing Screen Savers

You can purchase Screen Savers directly from your phone by following the instructions on page 209, or through www.sprintpcs.com.



Exploring the Web

With Web access on your PCS Vision Phone, you can browse full-color graphic versions of your favorite Websites, making it easier than ever to stay informed while on the go. Follow sports scores and breaking news and weather and shop on your PCS Vision Phone anywhere on the Sprint Nationwide PCS Network.

In addition to the features already covered in this section, the PCS Vision Home page offers access to these colorful, graphically rich Web categories. Many sites are available under more than one menu – choose the one that's most convenient for you.

- **News.** Get up-to-the-minute news regarding finance, business, sports, and entertainment at sites like CNNtoGo, Bloomberg, USA Today, and Forbes.
- **Weather.** Access The Weather Channel to get current weather conditions and forecasts.
- **Entertainment.** Get the latest buzz on your favorite stars as well as movie and music reviews at Websites like E! Online, Pocket BoxOffice™, and TastNtalk.
- **Sports.** Enjoy current news, statistics, and sports scores, as well as updates of events in progress at ESPN.com and other sports sites.
- **Finance.** Use Websites like Bloomberg, Fidelity, and Forbes to get stock quotes, make trades, and check your bank account online.
- **Travel.** Access flight information and make dining arrangements from travel Websites like Saber and Fodors.com.
- **Shopping.** Browse or purchase from popular shopping Websites like Amazon.com or Edmunds.
- **Tools.** Use tools like Switchboard to access yellow pages, white pages – even reverse phone number look-up or use Google to search for other Websites or images.
- **Business Links.** Access your PCS Business Connection Personal or Enterprise Edition along with links to many business-related sites.
- **My Account.** Check minutes and PCS Vision usage, view your current invoice, or make a payment.
- **Search.** Use Google to search keywords, articles, and even images.

Using the Browser Menu

Navigating the Web from your phone using the PCS Vision Home page is easy once you get the hang of it. For details on how to navigate the Web, select menu items, and more, see “Navigating the Web” on page 191.

Although the PCS Vision Home page offers a broad and convenient array of sites and services for you to browse, not all sites are represented, and certain functions, such as going directly to specific Websites, are not available. For these and other functions, you will need to use the browser menu. The browser menu offers additional functionality to expand your use of the Web on your PCS Vision Phone.

Opening the Browser Menu

The browser menu may be opened anytime you have an active PCS Vision session, from any page you are viewing.

To open the browser menu:

- ▶ Press  (right softkey) from any page during an active PCS Vision session. (The browser menu will display.)
(To launch a PCS Vision session, please see “Launching a PCS Vision Connection” on page 189.)

Options available under the browser menu include:

- **Home.** Returns the browser to the PCS Vision Home page.
- **Forward.** Allows you to go forward to the pages you have visited.
- **Mark this page.** Allows you to create new bookmarks.
- **View Bookmarks.** Allows you to view and access bookmarked sites.
- **Search.** Launches a Google search.
- **Show URL.** Displays the URL (Website address) of the site you’re currently viewing.
- **Go to URL....** Allows you to navigate directly to a Website by entering its URL (Website address).
- **History.** Displays the pages you have visited.
- **Refresh this page.** Reloads the current Web page.
- **More....** Displays the additional menu options. (Restart Browser, Send Page, and Preferences.)

Creating a Bookmark

Bookmarks allow you to store the address of your favorite Websites for easy access at a later time.

To create a bookmark:

1. Launch the Web page you want to mark.
2. Press  (right softkey) to go to the browser menu.
3. Select **Mark this page** and press  or **OK** (left softkey).

Note: Bookmarking a page does not store the page contents, just its address. Some pages cannot be bookmarked. Whether a particular Web page may be marked is controlled by its creator.

Accessing a Bookmark

To access a bookmark:

1. Access the browser menu by pressing  (right softkey).
2. Select **View Bookmarks** and press **OK** (left softkey).
3. Highlight the bookmark you'd like to access and press  or **OK** (left softkey) to go to the Website.

Editing a Bookmark

To edit a bookmark:

1. Launch the Web and press  (right softkey) to access the browser menu.
2. Select **View Bookmarks** and press **OK** (left softkey).
3. Select the bookmark you wish to edit and press  (right softkey).
4. Select **Edit Address** or **Edit Title** and press **OK** (left softkey).
5. Press **Edit** (right softkey), use your keypad to edit the address or title, and press **OK** (left softkey).
6. To save the bookmark, press **OK** (left softkey).

Deleting a Bookmark

To delete a bookmark:

1. Launch the Web and press  (right softkey) to access the browser menu.
2. Select **View Bookmarks** and press **OK** (left softkey).
3. Highlight the bookmark you wish to erase and press  (right softkey).
4. Select **Delete** and press **OK** (left softkey).
5. Press **Yes** (right softkey).

Tip: To delete all bookmarks, select **Delete All** during step 3 above.

Moving a Bookmark

To move a bookmark:

1. Access the **View Bookmarks** menu as outlined above in steps 1-2, and press  (right softkey).
2. Select **Reorder** and press **OK** (left softkey).
3. Highlight the bookmark you wish to move and press **Move** (left softkey).
4. Move the bookmark to a new location by pressing the navigation key up or down and press **Drop** (left softkey).
5. When you're finished, press **Finish** (right softkey).

Going to a Specific Website

To go to a particular Website by entering a URL (Website address):

1. Launch the Web and press  (right softkey) to display the browser menu.
2. Select **Go to URL...** and press **OK** (left softkey).
3. Select **Address** and press **OK** (left softkey).
4. Press **Edit** (right softkey), use your keypad to enter the URL of the Website you wish to go to, and press **OK** (left softkey).
5. Press **OK** (left softkey) to go to the Website.

Note: Not all Websites are viewable on your phone.

Reloading a Web Page

To reload (refresh) a Web page:

1. Launch the Web and press  (right softkey) to display the browser menu.
2. Select **Refresh this page** and press **OK** (left softkey).

Restarting the Web Browser

If the Web browser appears to be malfunctioning or stops responding, you can usually fix the problem by simply restarting the browser.

To restart the Web browser:

1. From an active PCS Vision connection, press  (right softkey) to display the browser menu.
2. Select **More...** and press **OK** (left softkey).
3. Select **Restart Browser** and press **OK** (left softkey).

Sending a Web Page

This feature allows you to send a URL (Website address) you're viewing through SMS text messaging.

To send a Web page:

1. From an active PCS Vision connection, press  (right softkey) to display the browser menu.
2. Select **More...** and press **OK** (left softkey).
3. Select **Send Page** and press **OK** (left softkey).
4. To complete and send a Web Page, follow steps 5-12 in "Sending a Message" on page 195.

Adjusting the Browser Sound Volume

To adjust the browser sound volume:

1. From an active PCS Vision connection, press  (right softkey) to display the browser menu.
2. Select **More...** and press **OK** (left softkey).
3. Select **Preferences** and press **OK** (left softkey).
4. Select **Sound Volume** and press **OK** (left softkey).
5. Select your desired volume level by pressing the navigation key up or down and press .



Using PCS Business Connection Personal Edition

PCS Business ConnectionSM Personal Edition gives you secure, real-time access to your Microsoft® Outlook® or Lotus Notes® company email, calendar, business directory, and personal contacts. You'll have the features and functions of your Microsoft Outlook and Lotus Notes so you can view, create, reply to, and delete email; schedule appointments; and look up phone numbers in real time, anywhere on the Sprint Nationwide PCS Network.

PCS Business Connection Personal Edition delivers the following features:

- **Business email access.** Read, reply to, forward, delete, and compose your company email.
- **Company directory and contacts.** Search, view, call, and email contacts from your company's directory. Do all this and add/edit your personal contacts.
- **Work calendar.** Accept and decline meetings, view daily summaries and details, and navigate to various dates.
- **Files/information on your PC.** Browse folders, download, and view documents from any device using a PC browser or Pocket Internet Explorer.

PCS Business Connection Personal Edition requires no hardware or software installation on your company's network. Just install the PCS Business Connection Personal Edition software on your work PC. This allows data to be securely retrieved in real-time by your wireless device when connected to the Sprint Nationwide PCS Network. There is a monthly charge for PCS Business Connection and usage charges will also apply.

When your work PC isn't on, you can share connections with your co-workers so that you always have access to your email, calendar, and contacts. Your data remains secure behind the corporate firewall, and any changes you make on your wireless device are instantly updated on your company server without the need to synchronize.

Additional PCS Business Connection solutions are available for your company. For more details, visit businessconnection.sprintpcs.com.

PCS Vision FAQs

How will I know when my phone is ready for PCS Vision service?

When your phone is ready, your User Address will be displayed in the Phone# UserID menu. Go to **Settings > Phone Info > Phone#/User ID**.

How do I sign-in for the first time?

You are automatically signed in to access PCS Vision services when you turn on your phone.

How do I know when my phone is connected to PCS Vision services?

Your phone automatically connects when PCS Vision service is used or an incoming message arrives. Your phone will also display the  icon. (Connecting takes about 10-12 seconds.)

Can I make calls and use PCS Vision services at the same time?

You cannot use voice and PCS Vision services simultaneously. If you receive a call while PCS Vision service is active, the call will be forwarded to voicemail. You can place an outgoing call anytime, but it will interrupt any in-progress PCS Vision session.

When is my data connection active?

Your connection is active when data is being transferred. Outgoing calls are allowed; incoming calls go directly to voicemail. When active, the  (Sending) or  (Receiving) indicator flashes on your phone's display screen.

When is my data connection dormant?

If no data is received for 10 seconds, the connection goes dormant. When the connection is dormant, voice calls are allowed. (The connection may become active again quickly.) If no data is received for an extended period of time, the connection will terminate.

Can I sign out of data services?

You can sign out without turning off your phone; however, you will not be able to browse the Web or use other PCS Vision services. While signed out, you can still place or receive phone calls, check voicemail, and use other voice services. You may sign in again at any time. To sign out, go to **Settings > PCS Vision > Disable Vision** in your phone's menu.

PCS Voice CommandSM

In This Section

- ◆ **Getting Started With PCS Voice CommandSM**
 - ◆ **Creating Your Own Address Book**
 - ◆ **Making a Call With PCS Voice Command**
 - ◆ **Accessing Information Using PCS Voice Command**
-

With Sprint, the first wireless provider to offer innovative PCS Voice Command technology, reaching your friends, family, and co-workers has never been easier – especially when you're on the go. You can even listen to Web-based information such as news, stock quotes, weather, sports, and much more. Your voice does it all with PCS Voice Command.

This section outlines the PCS Voice Command service.

Getting Started With PCS Voice CommandSM

With PCS Voice Command:

- You can store all your contacts' phone numbers, so you can simply say the name of the person you want to call.
- There's no need to punch in a lot of numbers, memorize voicemail passwords, or try to dial while you're driving.
- You can call anyone in your address book – even if you don't remember their phone number.

It's Easy to Get Started

- ▶ Just dial **✕ TALK** from your PCS Vision Phone to activate the service and listen to the brief instructions directly from your phone. There is a monthly charge for PCS Voice Command.

Note: Beginning Fall 2004, dial **✕ 2 TALK** to activate your PCS Voice Command service. PCS Voice Command calls will still be made using **✕ TALK**.

Creating Your Own Address Book

You can program up to 500 names into your personal address book, with each name having up to five phone numbers. That's 2,500 phone numbers, and with the advanced technology of PCS Voice Command, you can have instant access to all of them.

There are four ways to update your address book:

- **Use Voice Recordings.** Simply dial **✕ TALK** and say, "Add name." You will then be asked to say the name and number you want to add to your personal address book. Your address book can store up to 20 voice recorded names at once.
- **On the Web.** Go to www.talk.sprintpcs.com to receive a fully functional Web-based address book to create and update your contacts.
- **Use an Existing Address Book.** Automatically merge address books from desktop software applications with Sprint SyncSM Services for no additional charge. Simply click on the "Click to synchronize" button within your PCS Voice Command personal address book at www.talk.sprintpcs.com.
- **Call Directory Assistance.** If you don't have a computer or Internet access handy, you can have PCS Directory Assistance look up phone numbers for you and automatically add them to your address book. Just say "Call operator" and we'll add two names and numbers to your address book for our standard directory assistance charge.

Making a Call With PCS Voice Command

To place a call with PCS Voice Command:

1. Press  **TALK** and create your address book once you've signed up for PCS Voice Command. (You'll hear a tone followed by the prompt "Ready.")
2. After the "Ready" prompt, simply say, in a natural voice, "Call" and the name of the person or the number you'd like to call. (For example, you can say, "Call Jane Smith at work," "Call John Baker on the mobile phone," "Call 555-1234," or "Call Bob Miller.")
3. Your request will be repeated and you will be asked to verify. Say "Yes" to call the number or person. (The number will automatically be dialed.) Say "No" if you wish to cancel.

Tip: Keep in mind that PCS Voice Command recognizes not only your voice, but any voice, so that others can experience the same convenience if they use your phone.

For more helpful hints on PCS Voice Command, including a list of recognized commands and an interactive tutorial, visit www.talk.sprintpcs.com.

Accessing Information Using PCS Voice Command

To access information using PCS Voice Command:

1. Press  **TALK**.
2. Say "Call the Web." (To access, listen to and respond to email, once email has been set up, say "Call My Email.")
3. Choose from a listing of information categories like news, weather, sports, and more.

Note: PCS Voice Command is not available while roaming off the Sprint Nationwide PCS Network.

**Safety Guidelines
and
Warranty Information**



Safety

In This Section

- ◆ **Getting the Most Out of Your Reception**
 - ◆ **Maintaining Safe Use of and Access to Your Phone**
 - ◆ **Caring for the Battery**
 - ◆ **Acknowledging Special Precautions and the FCC Notice**
 - ◆ **Consumer Information on Wireless Phones**
 - ◆ **Owner's Record**
 - ◆ **User's Guide Proprietary Notice**
-

Part of getting the most out of your PCS Vision Phone is learning how the phone works and how to care for it. This section outlines performance and safety guidelines that help you understand the basic features of your phone's operation.

Getting the Most Out of Your Reception

Keeping Tabs on Signal Strength

The quality of each call you make or receive depends on the signal strength in your area. Your phone informs you of the current signal strength by displaying a number of bars next to the signal strength icon. The more bars displayed, the stronger the signal. If you're inside a building, being near a window may give you better reception.

Understanding the Power Save Feature

If your phone is unable to find a signal after 15 minutes of searching, a Power Save feature is automatically activated. If your phone is active, it periodically rechecks service availability; you can also check it yourself by pressing any key. Anytime the Power Save feature is activated, a message is displayed on the screen. When a signal is found, your phone returns to standby mode.

Understanding How Your Phone Operates

Your phone is basically a radio transmitter and receiver. When it's turned on, it receives and transmits radiofrequency (RF) signals. When you use your phone, the system handling your call controls the power level. This power can range from 0.01μ watts to 0.2 watts in digital mode.

Knowing Radio Frequency Safety

The design of your PCS Vision Phone complies with updated NCRP standards described below.

In 1991-92, the Institute of Electrical and Electronics Engineers (IEEE) and the American National Standards Institute (ANSI) joined in updating ANSI's 1982 standard for safety levels with respect to human exposure to RF signals. More than 120 scientists, engineers and physicians from universities, government health agencies and industries developed this updated standard after reviewing the available body of research. In 1993, the Federal Communications Commission (FCC) adopted this updated standard in a regulation. In August 1996, the FCC adopted hybrid standard consisting of the existing ANSI/IEEE standard and the guidelines published by the National Council of Radiation Protection and Measurements (NCRP).

Maintaining Your Phone's Peak Performance

There are several simple guidelines to operating your phone properly and maintaining safe, satisfactory service.

- Hold the phone with the antenna raised, fully-extended, and over your shoulder.
- Try not to hold, bend, or twist the phone's antenna.
- Don't use the phone if the antenna is damaged.
- Speak directly into the mouthpiece.
- Avoid exposing your phone and accessories to rain or liquid spills. If your phone does get wet, immediately turn the power off and remove the battery.

Note: For the best care of your phone, only Sprint authorized personnel should service your phone and accessories. Faulty service may void the warranty.

Maintaining Safe Use of and Access to Your Phone

FAILURE TO FOLLOW THE INSTRUCTIONS OUTLINED MAY LEAD TO SERIOUS PERSONAL INJURY AND POSSIBLE PROPERTY DAMAGE

Using Your Phone While Driving

Talking on your phone while driving (or operating the phone without a hands-free device) is prohibited in some jurisdictions. Laws vary as to specific restrictions. Remember that safety always comes first.

When using your phone in the car:

- Get to know your phone and its features, such as speed dial and redial.
- When available, use a hands-free device.
- Position your phone within easy reach.
- Let the person you are speaking to know you are driving; if necessary, suspend the call in heavy traffic or hazardous weather conditions.
- Do not take notes or look up phone numbers while driving.
- Dial sensibly and assess the traffic; if possible, place calls when stationary or before pulling into traffic.
- Do not engage in stressful or emotional conversations that may divert your attention from the road.
- Dial **9 1 1** to report serious emergencies. It's free from your wireless phone.
- Use your phone to help others in emergencies.
- Call roadside assistance or a special non-emergency wireless number when necessary.

Tip: Purchase an optional hands-free car kit at your local Sprint Store, or call the PCS Accessory Hotline™ at 1-800-974-2221 or by dialing **# 2 2 2 2** on your PCS Vision Phone.

Following Safety Guidelines

To operate your phone safely and efficiently, always follow any special regulations in a given area. Turn your phone off in areas where use is forbidden or when it may cause interference or danger.

Using Your Phone Near Other Electronic Devices

Most modern electronic equipment is shielded from radiofrequency (RF) signals. However, RF signals from wireless phones may affect inadequately shielded electronic equipment.

RF signals may affect improperly installed or inadequately shielded electronic operating systems and/or entertainment systems in motor vehicles. Check with the manufacturer or their representative to determine if these systems are adequately shielded from external RF signals. Also check with the manufacturer regarding any equipment that has been added to your vehicle.

Consult the manufacturer of any personal medical devices, such as pacemakers and hearing aids, to determine if they are adequately shielded from external RF signals.

Note: Always turn off the phone in health care facilities and request permission before using the phone near medical equipment.

Turning Off Your Phone Before Flying

Turn off your phone before boarding any aircraft. To prevent possible interference with aircraft systems, the U.S. Federal Aviation Administration (FAA) regulations require you to have permission from a crew member to use your phone while the plane is on the ground. To prevent any risk of interference, FCC regulations prohibit using your phone while the plane is in the air.

Turning Off Your Phone in Dangerous Areas

To avoid interfering with blasting operations, turn your phone off when in a blasting area or in other areas with signs indicating two-way radios should be turned off. Construction crews often use remote-control RF devices to set off explosives.

Turn your phone off when you're in any area that has a potentially explosive atmosphere. Although it's rare, your phone and accessories could generate sparks. Sparks can cause an explosion or fire, resulting in bodily injury or even death. These areas are often, but not always, clearly marked. They include:

- Fueling areas such as gas stations.
- Below deck on boats.
- Fuel or chemical transfer or storage facilities.
- Areas where the air contains chemicals or particles such as grain, dust, or metal powders.
- Any other area where you would normally be advised to turn off your vehicle's engine.

Note: Never transport or store flammable gas, liquid or explosives in the compartment of your vehicle that contains your phone or accessories.

Restricting Children's Access to Your Phone

Your phone is not a toy. Do not allow children to play with it as they could hurt themselves and others, damage the phone or make calls that increase your PCS Invoice.

Caring for the Battery

Protecting Your Battery

The guidelines listed below help you get the most out of your battery's performance.

- Use only Sprint-approved batteries and chargers. These chargers are designed to maximize battery life. Using other batteries or chargers voids your warranty and may cause damage.
- In order to avoid damage, charge the battery only in temperatures that range from 32° F to 113° F (0° C to 45° C).
- Don't use the battery charger in direct sunlight or in high humidity areas, such as the bathroom.
- Never dispose of the battery by incineration.
- Keep the metal contacts on top of the battery clean.
- Don't attempt to disassemble or short-circuit the battery.
- The battery may need recharging if it has not been used for a long period of time.
- It's best to replace the battery when it no longer provides acceptable performance. It can be recharged hundreds of times before it needs replacing.
- Don't store the battery in high temperature areas for long periods of time. It's best to follow these storage rules:

Less than one month:

4° F to 140° F (-20° C to 60° C)

More than one month:

4° F to 113° F (-20° C to 45° C)

Disposal of Lithium Ion (Lilon) Batteries

For safe disposal options of your Lilon batteries, contact your nearest Sprint authorized service center.

Special Note: Be sure to dispose of your battery properly. In some areas, the disposal of batteries in household or business trash may be prohibited.

Note: For safety, do not handle a damaged or leaking Lilon battery.

Acknowledging Special Precautions and the FCC Notice

FCC Notice

This phone may cause TV or radio interference if used in close proximity to receiving equipment. The FCC can require you to stop using the phone if such interference cannot be eliminated.

Vehicles using liquefied petroleum gas (propane or butane) must comply with the National Fire Protection Standard (NFPA-58). For a copy of this standard, contact the National Fire Protections Association, One Batterymarch Park, Quincy, MA 02269, Attn.: Publication Sales Division.

Cautions

Any changes or modifications to your phone not expressly approved in this document could void your warranty for this equipment and void your authority to operate this equipment. Only use approved batteries, antennas and chargers. The use of any unauthorized accessories may be dangerous and void the phone warranty if said accessories cause damage or a defect to the phone.

Although your phone is quite sturdy, it is a complex piece of equipment and can be broken. Avoid dropping, hitting, bending or sitting on it.

Body-Worn Operation

To maintain compliance with FCC RF exposure guidelines, if you wear a handset on your body, use the Sprint supplied or approved carrying case, holster or other body-worn accessory. If you do not use a body-worn accessory, ensure the antenna is at least 1.9 cm from your body when transmitting. Use of non-Sprint approved accessories may violate FCC RF exposure guidelines.

For more information about RF exposure, visit the FCC Website at www.fcc.gov.

Specific Absorption Rates (SAR) for Wireless Phones

The SAR is a value that corresponds to the relative amount of RF energy absorbed in the head of a user of a wireless handset.

The SAR value of a phone is the result of an extensive testing, measuring and calculation process. It does not represent how much RF the phone emits. All phone models are tested at their highest value in strict laboratory settings. But when in operation, the SAR of a phone can be substantially less than the level reported to the FCC. This is because of a variety of factors including its proximity to a base station antenna, phone design and other factors. What is important to remember is that each phone meets strict federal guidelines. Variations in SARs do not represent a variation in safety.

All phones must meet the federal standard, which incorporates a substantial margin of safety. As stated above, variations in SAR values between different model phones do not mean variations in safety. SAR values at or below the federal standard of 1.6 W/kg are considered safe for use by the public.

The highest reported SAR values of the PM-8200 are:

AMPS/CDMA modes (Part 22):

Head: 1.30 W/kg; Body-worn: 1.01 W/kg

PCS mode (Part 24):

Head: 1.13 W/kg; Body-worn: 1.01 W/kg

FCC Radiofrequency Emission

This phone meets the FCC Radiofrequency Emission Guidelines.

FCC ID number: AEZSCP-82H. More information on the phone's SAR can be found from the following FCC Website: <http://www.fcc.gov/oet/fccid>.

Consumer Information on Wireless Phones

(The following information comes from a consumer information Website jointly sponsored by the U.S. Food and Drug Administration (FDA) and the Federal Communications Commission (FCC), entitled “Cell Phone Facts: Consumer Information on Wireless Phones.” The information reproduced herein is dated July 29, 2003. For further updates, please visit the Website: <http://www.fda.gov/cellphones/qa.html>.)

What is radiofrequency energy (RF)?

Radiofrequency (RF) energy is another name for radio waves. It is one form of electromagnetic energy that makes up the electromagnetic spectrum. Some of the other forms of energy in the electromagnetic spectrum are gamma rays, x-rays and light. Electromagnetic energy (or electromagnetic radiation) consists of waves of electric and magnetic energy moving together (radiating) through space. The area where these waves are found is called an electromagnetic field.

Radio waves are created due to the movement of electrical charges in antennas. As they are created, these waves radiate away from the antenna. All electromagnetic waves travel at the speed of light. The major differences between the different types of waves are the distances covered by one cycle of the wave and the number of waves that pass a certain point during a set time period. The wavelength is the distance covered by one cycle of a wave. The frequency is the number of waves passing a given point in one second. For any electromagnetic wave, the wavelength multiplied by the frequency equals the speed of light. The frequency of an RF signal is usually expressed in units called hertz (Hz). One Hz equals one wave per second. One kilohertz (kHz) equals one thousand waves per second, one megahertz (MHz) equals one million waves per second, and one gigahertz (GHz) equals one billion waves per second.

RF energy includes waves with frequencies ranging from about 3000 waves per second (3 kHz) to 300 billion waves per second (300 GHz). Microwaves are a subset of radio waves that have frequencies ranging from around 300 million waves per second (300 MHz) to three billion waves per second (3 GHz).

How is radiofrequency energy used?

Probably the most important use of RF energy is for telecommunications. Radio and TV broadcasting, wireless phones, pagers, cordless phones, police and fire department radios, point-to-point links and satellite communications all rely on RF energy.

Other uses of RF energy include microwave ovens, radar, industrial heaters and sealers, and medical treatments. RF energy, especially at microwave frequencies, can heat water. Since most food has a high water content, microwaves can cook food quickly. Radar relies on RF energy to track cars and airplanes as well as for military applications. Industrial heaters and sealers use RF energy to mold plastic materials, glue wood products, seal leather items such

as shoes and pocketbooks, and process food. Medical uses of RF energy include pacemaker monitoring and programming.

How is radiofrequency radiation measured?

RF waves and RF fields have both electrical and magnetic components. It is often convenient to express the strength of the RF field in terms of each component. For example, the unit “volts per meter” (V/m) is used to measure the electric field strength, and the unit “amperes per meter” (A/m) is used to express the magnetic field strength. Another common way to characterize an RF field is by means of the power density. Power density is defined as power per unit area. For example, power density can be expressed in terms of milliwatts (one thousandth of a watt) per square centimeter (mW/cm² or microwatts (one millionth of a watt) per square centimeter (μW/cm²).

The quantity used to measure how much RF energy is actually absorbed by the body is called the Specific Absorption Rate or SAR. The SAR is a measure of the rate of absorption of RF energy. It is usually expressed in units of watts per kilogram (W/kg) or milliwatts per gram (mW/g).

What biological effects can be caused by RF energy?

The biological effects of radiofrequency energy should not be confused with the effects from other types of electromagnetic energy.

Very high levels of electromagnetic energy, such as is found in X-rays and gamma rays can ionize biological tissues. Ionization is a process where electrons are stripped away from their normal locations in atoms and molecules. It can permanently damage biological tissues including DNA, the genetic material. Ionization only occurs with very high levels of electromagnetic energy such as X-rays and gamma rays. Often the term radiation is used when discussing ionizing radiation (such as that associated with nuclear power plants).

The energy levels associated with radiofrequency energy, including both radio waves and microwaves, are not great enough to cause the ionization of atoms and molecules. Therefore, RF energy is a type of non-ionizing radiation. Other types of non-ionizing radiation include visible light, infrared radiation (heat) and other forms of electromagnetic radiation with relatively low frequencies.

Large amounts of RF energy can heat tissue. This can damage tissues and increase body temperatures. Two areas of the body, the eyes and the testes, are particularly vulnerable to RF heating because there is relatively little blood flow in them to carry away excess heat.

The amount of RF radiation routinely encountered by the general public is too low to produce significant heating or increased body temperature. Still, some people have questions about the possible health effects of low levels of RF energy. It is generally agreed that further research is needed to determine what effects actually occur and whether they are dangerous to people. In the meantime, standards-setting organizations and government agencies are continuing to monitor the latest scientific findings to determine whether changes in safety limits are needed to protect human health.

FDA, EPA and other US government agencies responsible for public health and safety have worked together and in connection with WHO to monitor developments and identify research needs related to RF biological effects.

What levels of RF energy are considered safe?

Various organizations and countries have developed standards for exposure to radiofrequency energy. These standards recommend safe levels of exposure for both the general public and for workers. In the United States, the FCC has used safety guidelines for RF environmental exposure since 1985.

The FCC guidelines for human exposure to RF electromagnetic fields are derived from the recommendations of two expert organizations, the National Council on Radiation Protection and Measurements (NCRP) and the Institute of Electrical and Electronics Engineers (IEEE). In both cases, the recommendations were developed by scientific and engineering experts drawn from industry, government, and academia after extensive reviews of the scientific literature related to the biological effects of RF energy.

Many countries in Europe and elsewhere use exposure guidelines developed by the International Commission on Non-Ionizing Radiation Protection (ICNIRP). The ICNIRP safety limits are generally similar to those of the NCRP and IEEE, with a few exceptions. For example, ICNIRP recommends different exposure levels in the lower and upper frequency ranges and for localized exposure from certain products such as hand-held wireless telephones. Currently, the World Health Organization is working to provide a framework for international harmonization of RF safety standards.

The NCRP, IEEE, and ICNIRP all have identified a whole-body Specific Absorption Rate (SAR) value of 4 watts per kilogram (4 W/kg) as a threshold level of exposure at which harmful biological effects may occur. Exposure guidelines in terms of field strength, power density and localized SAR were then derived from this threshold value. In addition, the NCRP, IEEE, and ICNIRP guidelines vary depending on the frequency of the RF exposure. This is due to the finding that whole-body human absorption of RF energy varies with the frequency of the RF signal. The most restrictive limits on whole-body exposure are in the frequency range of 30-300 MHz where the human body absorbs RF energy most efficiently. For products that only expose part of the body, such as wireless phones, exposure limits in terms of SAR only are specified.

The exposure limits used by the FCC are expressed in terms of SAR, electric and magnetic field strength, and power density for transmitters operating at frequencies from 300 kHz to 100 GHz. The specific values can be found in two FCC bulletins, OET Bulletins 56 and 65:

<http://www.fcc.gov/oet/info/documents/bulletins/#56>;

<http://www.fcc.gov/oet/info/documents/bulletins/#65>.

Why has the FCC adopted guidelines for RF exposure?

The FCC authorizes and licenses products, transmitters, and facilities that generate RF and microwave radiation. It has jurisdiction over all transmitting services in the U.S. except those specifically operated by the Federal

Government. While the FCC does not have the expertise to determine radiation exposure guidelines on its own, it does have the expertise and authority to recognize and adopt technically sound standards promulgated by other expert agencies and organizations, and has done so. (Our joint efforts with the FDA in developing this website is illustrative of the kind of inter-agency efforts and consultation we engage in regarding this health and safety issue.)

Under the National Environmental Policy Act of 1969 (NEPA), the FCC has certain responsibilities to consider whether its actions will significantly affect the quality of the human environment. Therefore, FCC approval and licensing of transmitters and facilities must be evaluated for significant impact on the environment. Human exposure to RF radiation emitted by FCC-regulated transmitters is one of several factors that must be considered in such environmental evaluations. In 1996, the FCC revised its guidelines for RF exposure as a result of a multi-year proceeding and as required by the Telecommunications Act of 1996.

Radio and television broadcast stations, satellite-earth stations, experimental radio stations and certain wireless communication facilities are required to undergo routine evaluation for RF compliance when they submit an application to the FCC for construction or modification of a transmitting facility or renewal of a license. Failure to comply with the FCC's RF exposure guidelines could lead to the preparation of a formal Environmental Assessment, possible Environmental Impact Statement and eventual rejection of an application. Technical guidelines for evaluating compliance with the FCC RF safety requirements can be found in the FCC's OET Bulletin 65.
<http://www.fcc.gov/oet/info/documents/bulletins/#65>

Low-powered, intermittent, or inaccessible RF transmitters and facilities are normally excluded from the requirement for routine evaluation for RF exposure. These exclusions are based on standard calculations and measurement data indicating that a transmitting station or equipment operating under the conditions prescribed is unlikely to cause exposures in excess of the guidelines under normal conditions of use. Such exclusions are not exclusions from compliance, but, rather, exclusions from routine evaluation. The FCC's policies on RF exposure and categorical exclusion can be found in Section 1.1307(b) of the FCC's Rules and Regulations [(47 CFR 1.1307(b))].

How can I obtain the Specific Absorption Rate (SAR) value for my wireless phone?

The FCC requires that wireless phones sold in the United States demonstrate compliance with human exposure limits adopted by the FCC in 1996. The relative amount of RF energy absorbed in the head of a wireless telephone-user is given by the Specific Absorption Rate (SAR), as explained above. The FCC requires wireless phones to comply with a safety limit of 1.6 watts per kilogram (1.6 W/kg) in terms of SAR.

Information on SAR for a specific phone model can be obtained for many recently manufactured phones using the FCC identification (ID) number for that

model. The FCC ID number is usually printed somewhere on the case of the phone. Sometimes it may be necessary to remove the battery pack to find the number. Once you have the ID number, go to the following Web address: www.fcc.gov/oet/fccid. On this page, you will see instructions for entering the FCC ID number. Type the FCC ID number exactly as requested (the Grantee Code is the first three characters, the Equipment Product Code is the rest of the FCC ID number). Then click on "Start Search." The "Grant of Equipment Authorization" for your telephone should appear. Read through the grant for the section on "SAR Compliance," "Certification of Compliance with FCC Rules for RF Exposure" or similar language. This section should contain the value(s) for typical or maximum SAR for your phone.

Phones and other products authorized since June 2, 2000, should have the maximum SAR levels noted directly on the "Grant of Equipment Authorization." For phones and products authorized between about mid-1998 and June 2000, detailed information on SAR levels is typically found in the exhibits associated with the grant. Once a grant is accessed, the exhibits can be viewed by clicking on "View Exhibit." Grants authorized prior to 1998 are not part of the electronic database but, rather, have been documented in the form of paper records.

The FCC database does not list phones by model number. However, consumers may find SAR information from other sources as well. Some wireless phone manufacturers make SAR information available on their own Web sites. In addition, some non-government Web sites provide SARs for specific models of wireless phones. However, the FCC has not reviewed these sites and makes no guarantees of their accuracy. Finally, phones certified by the Cellular Telecommunications and Internet Association (CTIA) are required to provide SAR information to consumers in the instructional materials that come with the phones.

Do hands-free kits for wireless phones reduce risks from exposure to RF emissions?

Since there are no known risks from exposure to RF emissions from wireless phones, there is no reason to believe that hands-free kits reduce risks. Hands-free kits can be used with wireless phones for convenience and comfort. These systems reduce the absorption of RF energy in the head because the phone, which is the source of the RF emissions, will not be placed against the head. On the other hand, if the phone is mounted against the waist or other part of the body during use, then that part of the body will absorb more RF energy. Wireless phones marketed in the U.S. are required to meet safety requirements regardless of whether they are used against the head or against the body. Either configuration should result in compliance with the safety limit.

Do wireless phone accessories that claim to shield the head from RF radiation work?

Since there are no known risks from exposure to RF emissions from wireless phones, there is no reason to believe that accessories that claim to shield the head from those emissions reduce risks. Some products that claim to shield the

user from RF absorption use special phone cases, while others involve nothing more than a metallic accessory attached to the phone. Studies have shown that these products generally do not work as advertised. Unlike “hand-free” kits, these so-called “shields” may interfere with proper operation of the phone. The phone may be forced to boost its power to compensate, leading to an increase in RF absorption. In February 2002, the Federal Trade Commission (FTC) charged two companies that sold devices that claimed to protect wireless phone users from radiation with making false and unsubstantiated claims. According to FTC, these defendants lacked a reasonable basis to substantiate their claim.

What are wireless telephone base stations?

Fixed antennas used for wireless telecommunications are referred to as cellular base stations, cell stations, PCS (“Personal Communications Service”) stations or telephone transmission towers. These base stations consist of antennas and electronic equipment. Because the antennas need to be high in the air, they are often located on towers, poles, water tanks, or rooftops. Typical heights for freestanding base station towers are 50-200 feet.

Some base stations use antennas that look like poles, 10 to 15 feet in length, that are referred to as “omni-directional” antennas. These types of antennas are usually found in rural areas. In urban and suburban areas, wireless providers now more commonly use panel or sector antennas for their base stations. These antennas consist of rectangular panels, about 1 by 4 feet in dimension. The antennas are usually arranged in three groups of three antennas each. One antenna in each group is used to transmit signals to wireless phones, and the other two antennas in each group are used to receive signals from wireless phones.

At any base station site, the amount of RF energy produced depends on the number of radio channels (transmitters) per antenna and the power of each transmitter. Typically, 21 channels per antenna sector are available. For a typical cell site using sector antennas, each of the three transmitting antennas could be connected to up to 21 transmitters for a total of 63 transmitters. However, it is unlikely that all of the transmitters would be transmitting at the same time.

When omni-directional antennas are used, a cellular base station could theoretically use up to 96 transmitters, but this would be very unusual, and, once again, it is unlikely that all transmitters would be in operation simultaneously. Base stations used for PCS communications generally require fewer transmitters than those used for cellular radio transmissions, since PCS carriers usually have a higher density of base station antenna sites.

Are wireless telephone base stations safe?

The electromagnetic RF signals transmitted from base station antennas stations travel toward the horizon in relatively narrow paths. For example, the radiation pattern for an antenna array mounted on a tower can be likened to a thin pancake centered around the antenna system. The individual pattern for a single array of sector antennas is wedge-shaped, like a piece of pie. As with all forms of electromagnetic energy, the power decreases rapidly as one moves away from

the antenna. Therefore, RF exposure on the ground is much less than exposure very close to the antenna and in the path of the transmitted radio signal. In fact, ground-level exposure from such antennas is typically thousands of times less than the exposure levels recommended as safe by expert organizations. So exposure to nearby residents would be well within safety margins.

Cellular and PCS base stations in the United States are required to comply with limits for exposure recommended by expert organizations and endorsed by government agencies responsible for health and safety. Measurements made near cellular and PCS base station antennas mounted on towers have confirmed that ground-level exposures are typically thousands of times less than the exposure limits adopted by the FCC. In fact, in order to be exposed to levels at or near the FCC limits for cellular or PCS frequencies an individual would essentially have to remain in the main transmitted radio signal (at the height of the antenna) and within a few feet from the antenna. This is, of course, very unlikely to occur.

When cellular and PCS antennas are mounted on rooftops, RF levels on that roof or on others near by would probably be greater than those typically encountered on the ground. However, exposure levels approaching or exceeding safety guidelines should be encountered only very close to or directly in front of the antennas. In addition, for sector-type antennas, typically used for such rooftop base stations, RF levels to the side and in back of these antennas are insignificant. General guidelines on antenna installations and circumstances that might give rise to a concern about a facility's conformance with FCC regulations can be found in *A Local Government Official's Guide to Transmitting Antenna RF Emission Safety: Rules, Procedures, and Practical Guidance*. This Guide can be accessed at: <http://www.fcc.gov/oet/rfsafety>.

Who regulates exposure to radiation from microwave ovens, television sets and computer monitors?

The Food and Drug Administration is responsible for protecting the public from harmful radiation emissions from these consumer products.

Does the FCC routinely monitor radiofrequency radiation from antennas?

The FCC does not have the resources or the personnel to routinely monitor the emissions for all the thousands of transmitters that are subject to FCC jurisdiction. However, the FCC does have measurement instrumentation for evaluating RF levels in areas that may be accessible to the public or to workers. If there is evidence for potential non-compliance with FCC exposure guidelines for a FCC-regulated facility, staff from the FCC's Office of Engineering and Technology or the FCC Enforcement Bureau can conduct an investigation, and, if appropriate, perform actual measurements. Circumstances that could give rise to a concern about a facility's conformance with FCC regulations can be found in *A Local Government Official's Guide to Transmitting Antenna RF Emission Safety: Rules, Procedures, and Practical Guidance*. This Guide can be accessed at: <http://www.fcc.gov/oet/rfsafety>. Potential exposure problems should

be brought to the FCC's attention by contacting the FCC RF Safety Program at: 202-418-2464 or by email: rf-safety@fcc.gov.

Does the FCC maintain a database that includes information on the location and technical parameters of all the transmitting towers it regulates?

Each of the FCC Bureaus maintains its own licensing database system for the service(s) it regulates (e.g., television, cellular service, satellite earth stations.) The FCC issues two types of licenses: site specific and market based. In the case of site specific licensed facilities, technical operating information is collected from the licensee as part of the licensing process. However, in the case of market based licensing (e.g., PCS, cellular), the licensee is granted the authority to operate a radio communications system in a geographic area using as many facilities as are required, and the licensee is not required to provide the FCC with specific location and operating parameters of these facilities.

Information on site specific licensed facilities can be found the "General Menu Reports" (GenMen) at <http://gulfoss2.fcc.gov/cgi-bin/ws.exe/genmen/index.htm>.

The various FCC Bureaus also publish on at least a weekly basis, bulk extracts of their licensing databases. Each licensing database has its own unique file structure. These extracts consist of multiple, very large files. The FCC's Office of Engineering and Technology (OET) maintains an index to these databases at <http://www.fcc.gov/oet/info/database/fadb.html>. Entry points into the various databases include frequency, state/county, latitude/longitude, call-sign and licensee name. For further information on the Commission's existing databases, you can contact Donald Campbell at dcampbel@fcc.gov or 202-418-2405.

Can local and state governmental bodies establish limits for RF exposure?

Although some local and state governments have enacted rules and regulations about human exposure to RF energy in the past, the Telecommunications Act of 1996 requires the Federal Government to control human exposure to RF emissions. In particular, Section 704 of the Act states that, "No State or local government or instrumentality thereof may regulate the placement, construction, and modification of personal wireless service facilities on the basis of the environmental effects of radio frequency emissions to the extent that such facilities comply with the Commission's regulations concerning such emissions." Further information on federal authority and FCC policy is available in a fact sheet from the FCC's Wireless Telecommunications Bureau at www.fcc.gov/wtb.

Do wireless phones pose a health hazard?

The available scientific evidence does not show that any health problems are associated with using wireless phones. There is no proof, however, that wireless phones are absolutely safe. Wireless phones emit low levels of radiofrequency energy (RF) in the microwave range while being used. They also emit very low levels of RF when in the stand-by mode. Whereas high levels of RF can produce health effects (by heating tissue), exposure to low level RF that does not

produce heating effects causes no known adverse health effects. Many studies of low level RF exposures have not found any biological effects. Some studies have suggested that some biological effects may occur, but such findings have not been confirmed by additional research. In some cases, other researchers have had difficulty in reproducing those studies, or in determining the reasons for inconsistent results.

What is FDA's role concerning the safety of wireless phones?

Under the law, FDA does not review the safety of radiation-emitting consumer products such as wireless phones before they can be sold, as it does with new drugs or medical devices. However, the agency has authority to take action if wireless phones are shown to emit radiofrequency energy (RF) at a level that is hazardous to the user. In such a case, FDA could require the manufacturers of wireless phones to notify users of the health hazard and to repair, replace or recall the phones so that the hazard no longer exists.

Although the existing scientific data do not justify FDA regulatory actions, FDA has urged the wireless phone industry to take a number of steps, including the following:

- Support needed research into possible biological effects of RF of the type emitted by wireless phones;
- Design wireless phones in a way that minimizes any RF exposure to the user that is not necessary for device function; and
- Cooperate in providing users of wireless phones with the best possible information on possible effects of wireless phone use on human health

FDA belongs to an interagency working group of the federal agencies that have responsibility for different aspects of RF safety to ensure coordinated efforts at the federal level. The following agencies belong to this working group:

- National Institute for Occupational Safety and Health
- Environmental Protection Agency
- Federal Communications Commission
- Occupational Safety and Health Administration
- National Telecommunications and Information Administration

The National Institutes of Health participates in some interagency working group activities, as well.

FDA shares regulatory responsibilities for wireless phones with the Federal Communications Commission (FCC). All phones that are sold in the United States must comply with FCC safety guidelines that limit RF exposure. FCC relies on FDA and other health agencies for safety questions about wireless phones.

FCC also regulates the base stations that the wireless phone networks rely upon. While these base stations operate at higher power than do the wireless phones themselves, the RF exposures that people get from these base stations are typically thousands of times lower than those they can get from wireless

phones. Base stations are thus not the primary subject of the safety questions discussed in this document.

What kinds of phones are the subject of this update?

The term “wireless phone” refers here to hand-held wireless phones with built-in antennas, often called “cell,” “mobile,” or “PCS” phones. These types of wireless phones can expose the user to measurable radiofrequency energy (RF) because of the short distance between the phone and the user’s head. These RF exposures are limited by Federal Communications Commission safety guidelines that were developed with the advice of FDA and other federal health and safety agencies. When the phone is located at greater distances from the user, the exposure to RF is drastically lower because a person’s RF exposure decreases rapidly with increasing distance from the source. The so-called “cordless phones,” which have a base unit connected to the telephone wiring in a house, typically operate at far lower power levels, and thus produce RF exposures well within the FCC’s compliance limits.

What are the results of the research done already?

The research done thus far has produced conflicting results, and many studies have suffered from flaws in their research methods. Animal experiments investigating the effects of radiofrequency energy (RF) exposures characteristic of wireless phones have yielded conflicting results that often cannot be repeated in other laboratories. A few animal studies, however, have suggested that low levels of RF could accelerate the development of cancer in laboratory animals. However, many of the studies that showed increased tumor development used animals that had been genetically engineered or treated with cancer-causing chemicals so as to be pre-disposed to develop cancer in the absence of RF exposure. Other studies exposed the animals to RF for up to 22 hours per day. These conditions are not similar to the conditions under which people use wireless phones, so we don’t know with certainty what the results of such studies mean for human health.

Three large epidemiology studies have been published since December 2000. Between them, the studies investigated any possible association between the use of wireless phones and primary brain cancer, glioma, meningioma, or acoustic neuroma, tumors of the brain or salivary gland, leukemia, or other cancers. None of the studies demonstrated the existence of any harmful health effects from wireless phone RF exposures. However, none of the studies can answer questions about long-term exposures, since the average period of phone use in these studies was around three years.

What research is needed to decide whether RF exposure from wireless phones poses a health risk?

A combination of laboratory studies and epidemiological studies of people actually using wireless phones would provide some of the data that are needed. Lifetime animal exposure studies could be completed in a few years. However, very large numbers of animals would be needed to provide reliable proof of a cancer promoting effect if one exists. Epidemiological studies can provide data

that is directly applicable to human populations, but 10 or more years' follow-up may be needed to provide answers about some health effects, such as cancer. This is because the interval between the time of exposure to a cancer-causing agent and the time tumors develop - if they do - may be many, many years. The interpretation of epidemiological studies is hampered by difficulties in measuring actual RF exposure during day-to-day use of wireless phones. Many factors affect this measurement, such as the angle at which the phone is held, or which model of phone is used.

What is FDA doing to find out more about the possible health effects of wireless phone RF?

FDA is working with the U.S. National Toxicology Program and with groups of investigators around the world to ensure that high priority animal studies are conducted to address important questions about the effects of exposure to radiofrequency energy (RF).

FDA has been a leading participant in the World Health Organization International Electromagnetic Fields (EMF) Project since its inception in 1996. An influential result of this work has been the development of a detailed agenda of research needs that has driven the establishment of new research programs around the world. The Project has also helped develop a series of public information documents on EMF issues.

FDA and the Cellular Telecommunications & Internet Association (CTIA) have a formal Cooperative Research and Development Agreement (CRADA) to do research on wireless phone safety. FDA provides the scientific oversight, obtaining input from experts in government, industry, and academic organizations. CTIA-funded research is conducted through contracts to independent investigators. The initial research will include both laboratory studies and studies of wireless phone users. The CRADA will also include a broad assessment of additional research needs in the context of the latest research developments around the world.

What steps can I take to reduce my exposure to radiofrequency energy from my wireless phone?

If there is a risk from these products—and at this point we do not know that there is—it is probably very small. But if you are concerned about avoiding even potential risks, you can take a few simple steps to minimize your exposure to radiofrequency energy (RF). Since time is a key factor in how much exposure a person receives, reducing the amount of time spent using a wireless phone will reduce RF exposure.

- If you must conduct extended conversations by wireless phone every day, you could place more distance between your body and the source of the RF, since the exposure level drops off dramatically with distance. For example, you could use a headset and carry the wireless phone away from your body or use a wireless phone connected to a remote antenna.

Again, the scientific data do not demonstrate that wireless phones are harmful. But if you are concerned about the RF exposure from these products, you can use measures like those described above to reduce your RF exposure from wireless phone use.

What about children using wireless phones?

The scientific evidence does not show a danger to users of wireless phones, including children and teenagers. If you want to take steps to lower exposure to radiofrequency energy (RF), the measures described above would apply to children and teenagers using wireless phones. Reducing the time of wireless phone use and increasing the distance between the user and the RF source will reduce RF exposure.

Some groups sponsored by other national governments have advised that children be discouraged from using wireless phones at all. For example, the government in the United Kingdom distributed leaflets containing such a recommendation in December 2000. They noted that no evidence exists that using a wireless phone causes brain tumors or other ill effects. Their recommendation to limit wireless phone use by children was strictly precautionary; it was not based on scientific evidence that any health hazard exists.

What about wireless phone interference with medical equipment?

Radiofrequency energy (RF) from wireless phones can interact with some electronic devices. For this reason, FDA helped develop a detailed test method to measure electromagnetic interference (EMI) of implanted cardiac pacemakers and defibrillators from wireless telephones. This test method is now part of a standard sponsored by the Association for the Advancement of Medical Instrumentation (AAMI). The final draft, a joint effort by FDA, medical device manufacturers, and many other groups, was completed in late 2000. This standard will allow manufacturers to ensure that cardiac pacemakers and defibrillators are safe from wireless phone EMI.

FDA has tested hearing aids for interference from handheld wireless phones and helped develop a voluntary standard sponsored by the Institute of Electrical and Electronic Engineers (IEEE). This standard specifies test methods and performance requirements for hearing aids and wireless phones so that no interference occurs when a person uses a “compatible” phone and a “compatible” hearing aid at the same time. This standard was approved by the IEEE in 2000.

FDA continues to monitor the use of wireless phones for possible interactions with other medical devices. Should harmful interference be found to occur, FDA will conduct testing to assess the interference and work to resolve the problem.

Which other federal agencies have responsibilities related to potential RF health effects?

Certain agencies in the Federal Government have been involved in monitoring, researching or regulating issues related to human exposure to RF radiation.

These agencies include the Food and Drug Administration (FDA), the Environmental Protection Agency (EPA), the Occupational Safety and Health Administration (OSHA), the National Institute for Occupational Safety and Health (NIOSH), the National Telecommunications and Information Administration (NTIA) and the Department of Defense (DOD).

By authority of the Radiation Control for Health and Safety Act of 1968, the Center for Devices and Radiological Health (CDRH) of the FDA develops performance standards for the emission of radiation from electronic products including X-ray equipment, other medical devices, television sets, microwave ovens, laser products and sunlamps. The CDRH established a product performance standard for microwave ovens in 1971 limiting the amount of RF leakage from ovens. However, the CDRH has not adopted performance standards for other RF-emitting products. The FDA is, however, the lead federal health agency in monitoring the latest research developments and advising other agencies with respect to the safety of RF-emitting products used by the public, such as cellular and PCS phones.

The FDA's microwave oven standard is an emission standard (as opposed to an exposure standard) that allows specific levels of microwave leakage (measured at five centimeters from the oven surface). The standard also requires ovens to have two independent interlock systems that prevent the oven from generating microwaves the moment that the latch is released or the door of the oven is opened. The FDA has stated that ovens that meet its standards and are used according to the manufacturer's recommendations are safe for consumer and industrial use. More information is available from: www.fda.gov/cdrh.

The EPA has, in the past, considered developing federal guidelines for public exposure to RF radiation. However, EPA activities related to RF safety and health are presently limited to advisory functions. For example, the EPA now chairs an Inter-agency Radiofrequency Working Group, which coordinates RF health-related activities among the various federal agencies with health or regulatory responsibilities in this area.

OSHA is responsible for protecting workers from exposure to hazardous chemical and physical agents. In 1971, OSHA issued a protection guide for exposure of workers to RF radiation [29 CFR 1910.97]. However, this guide was later ruled to be only advisory and not mandatory. Moreover, it was based on an earlier RF exposure standard that has now been revised. At the present time, OSHA uses the IEEE and/or FCC exposure guidelines for enforcement purposes under OSHA's "general duty clause" (for more information see: <http://www.osha-slc.gov/SLTC/radiofrequencyradiation/index.html>).

NIOSH is part of the U.S. Department of Health and Human Services. It conducts research and investigations into issues related to occupational exposure to chemical and physical agents. NIOSH has, in the past, undertaken to develop RF exposure guidelines for workers, but final guidelines were never adopted by the agency. NIOSH conducts safety-related RF studies through its Physical Agents Effects Branch in Cincinnati, Ohio.

The NTIA is an agency of the U.S. Department of Commerce and is responsible for authorizing Federal Government use of the RF electromagnetic spectrum. Like the FCC, the NTIA also has NEPA responsibilities and has considered adopting guidelines for evaluating RF exposure from U.S. Government transmitters such as radar and military facilities.

The Department of Defense (DOD) has conducted research on the biological effects of RF energy for a number of years. This research is now conducted primarily at the U.S. Air Force Research Laboratory located at Brooks Air Force Base, Texas. The DOD Web site for RF biological effects information is listed with other sites in conjunction with a question on other sources of information, below.

Who funds and carries out research on the biological effects of RF energy?

Research into possible biological effects of RF energy is carried out in laboratories in the United States and around the world. In the U.S., most research has been funded by the Department of Defense, due to the extensive military use of RF equipment such as radar and high-powered radio transmitters. In addition, some federal agencies responsible for health and safety, such as the Environmental Protection Agency (EPA) and the U.S. Food and Drug Administration (FDA), have sponsored and conducted research in this area. At the present time, most of the non-military research on biological effects of RF energy in the U.S. is being funded by industry organizations. More research is being carried out overseas, particularly in Europe.

In 1996, the World Health Organization (WHO) established the International EMF Project to review the scientific literature and work towards resolution of health concerns over the use of RF technology. WHO maintains a Web site that provides extensive information on this project and about RF biological effects and research (www.who.ch/peh-emf).

FDA, EPA and other US government agencies responsible for public health and safety have worked together and in connection with WHO to monitor developments and identify research needs related to RF biological effects.

How does FCC Audit Cell Phone RF?

After FCC grants permission for a particular cellular telephone to be marketed, FCC will occasionally conduct “post-grant” testing to determine whether production versions of the phone are being produced to conform with FCC regulatory requirements. The manufacturer of a cell phone that does not meet FCC’s regulatory requirements may be required to remove the cell phone from use and to refund the purchase price or provide a replacement phone, and may be subject to civil or criminal penalties. In addition, if the cell phone presents a risk of injury to the user, FDA may also take regulatory action. The most important post-grant test, from a consumer’s perspective, is testing of the RF emissions of the phone. FCC measures the Specific Absorption Rate (SAR) of the phone, following a very rigorous testing protocol. As is true for nearly any scientific measurement, there is a possibility that the test measurement may be

less than or greater than the actual RF emitted by the phone. This difference between the RF test measurement and actual RF emission is because test measurements are limited by instrument accuracy, because test measurement and actual use environments are different, and other variable factors. This inherent variability is known as “measurement uncertainty.” When FCC conducts post-grant testing of a cell phone, FCC takes into account any measurement uncertainty to when determining whether regulatory action is appropriate. This approach ensures that when FCC takes regulatory action, it will have a sound, defensible scientific basis.

FDA scientific staff reviewed the methodology used by FCC to measure cell phone RF and agreed it is an acceptable approach, given our current understanding of the risks presented by cellular phone RF emissions. RF emissions from cellular phones have not been shown to present a risk of injury to the user when the measured SAR is less than the safety limits set by FCC (an SAR of 1.6 W/kg). Even in a case where the maximum measurement uncertainty permitted by current measurement standards was added to the maximum permissible SAR, the resulting SAR value would be well below any level known to produce an acute effect. Consequently, FCC’s approach with measurement uncertainty will not result in consumers being exposed to any known risk from the RF emitted by cellular telephones.

FDA will continue to monitor studies and literature reports concerning acute effects of cell phone RF, and concerning chronic effects of long-term exposure to cellular telephone RF (that is, the risks from using a cell phone for many years). If new information leads FDA to believe that a change to FCC’s measurement policy may be appropriate, FDA will contact FCC and both agencies will work together to develop a mutually-acceptable approach.

Owner's Record

The model number, regulatory number and serial number are located on a nameplate inside the battery compartment. Record the serial number in the space provided below. This will be helpful if you need to contact us about your phone in the future.

Model: PCS Vision™ Picture Phone PM-8200 by Sanyo

Serial No.:

User's Guide Proprietary Notice

CDMA Technology is licensed by QUALCOMM Incorporated under one or more of the following patents:

4,901,307 5,109,390 5,267,262 5,416,797

5,506,865 5,544,196 5,657,420 5,101,501

5,267,261 5,414,796 5,504,773 5,535,239

5,600,754 5,778,338 5,228,054 5,337,338

5,710,784 5,056,109 5,568,483 5,659,569

5,490,165 5,511,073

T9 Text Input is licensed by Tegic Communications and is covered by U.S. Pat. 5,818,437, U.S. Pat. 5,953,541, U.S. Pat. 6,011,554 and other patents pending.

User's Guide template version 3D (09-01-03)

Terms & Conditions and Manufacturer's Warranty

In This Section

◆ **Terms and Conditions**

◆ **Manufacturer's Warranty**

Your PCS Vision Phone has been designed to provide you with reliable, worry-free service. If for any reason you have a problem with your equipment, please refer to the manufacturer's warranty.

This section contains the Terms and Conditions of Service for your PCS Phone and Service and the manufacturer's warranty for your PCS Phone.

Terms and Conditions

Terms and Conditions of Services

(Effective as of November 24, 2003 until replaced)

Thanks for choosing Sprint. These terms and conditions are part of your agreement with Sprint for PCS Services.

The terms and conditions included with your PCS Phone may not be the most current version. For the most current version of the terms and conditions, please visit our website at www.sprintpcs.com or call PCS Customer Service Solutions at 1-888-211-4PCS. If you activated PCS Services before the effective date of these terms and conditions, these terms and conditions replace and supersede any previous terms and conditions.

If you have questions about your PCS Services, please visit our website at www.sprintpcs.com or call PCS Customer Service Solutions at 1-888-211-4PCS (4727).

Para solicitar esta literatura en español, por favor contactar a 1-888-211-4PCS(4727).

Agreement. Your agreement (“Agreement”) with Sprint Spectrum L.P. and any of its affiliates doing business as Sprint providing PCS Services (“Services”) to you is made up of these Terms and Conditions of Service (“Terms”) and the Service Plan that we agree to provide you. Your “Service Plan” is described in our marketing materials, and includes the terms, rates and features we set for that Service Plan. In the agreement, we use the words “we,” “us,” “our” or “Sprint” to refer to Sprint Spectrum L.P. and its affiliates doing business as Sprint. You accept the agreement when you activate PCS Services or make any attempt to use our PCS Services (for example, attempting to place any call while on or roaming off the Sprint Nationwide PCS Network, using data services, etc.). We may change the Agreement at any time by giving you prior notice. Any changes to the Agreement are effective when we publish them. If you use our Services or make any payment to us on or after the effective date of the changes, you accept the changes. If we change a material term of the Agreement and that change has a material adverse effect on you, you may terminate the Agreement without an early termination fee by calling 1-888-211-4727 within 30 days after the invoice date of the first invoice you receive after the changes go into effect. You understand and agree that taxes, Universal Service fees and other charges imposed by the government or based on government calculations may increase or decrease on a monthly basis, and that this paragraph does not apply to any increases in such taxes, Universal Service fees and other charges.

Provision of Service. Your purchase of a PCS Phone or other equipment does not mean that we must provide Services to you. We may decide not to provide Services to you for any lawful reason. We may request that you provide us with any information we reasonably require to determine whether you qualify for Services. Services in some areas are managed and provided under contract with Sprint by independent affiliates with access to the Sprint Nationwide PCS Network. Some Services may not be available or may operate differently in certain affiliate markets or other areas.

Credit Verification. You must have and maintain satisfactory credit to receive and continue to receive Services. We will verify your credit before agreeing to provide Services to you and we may verify your credit at any time while we provide Services to you. Credit verification may include a review of credit reports that we receive from credit bureaus. If at any time we determine, in our sole discretion, that payment for Services may not be made when due, we may suspend Services and require that you provide payment on account or a guarantee of payment before we resume Services.

Service Plan. You may be eligible for a fixed length PCS Service Plan (“Term Service Plan”) or for a month-to-month Service Plan (“Non-Term Service Plan”). We determine the Service Plan for which you qualify. Except as permitted by the Agreement, you must maintain service with us on your Term Service Plan for the minimum term associated with that Term Service Plan. We may offer non-identical Service Plans to different individuals or entities. Services and coverage under some Service Plans may be more limited than available under other Service Plans. Your Service Plan sets out the charges for Services and is your Service Plan until that Service Plan is changed, you switch to a different Service Plan, or your Services terminate. Based on your credit rating or other factors, we may require that you make a deposit, prepayment, or a series of deposits or prepayments, or be subject to an account spending limit, before Services are activated or maintained.

Changing Service Plans. If you are on a Non-Term Service Plan, you may change to a different Service Plan for which you qualify. Any change is effective at the start of your next full invoicing cycle unless otherwise specified by us at the time that you place your change order. If you change or add a different Service Plan or service feature and the change is effective prior to the start of your next full invoicing cycle, you will be invoiced a prorated amount. We may require a service charge for implementing any change directed by you in addition to the charges associated with the Service Plan or optional service features you select. If you are on a Term Service Plan and you want to change your service plan, you may be required to accept a new Term Service Plan and we may require you to pay the early termination fee set out in your Service Plan or other fee.

Termination. Non-Term Service Plan. If you are on a Non-Term Service Plan, you may terminate Services at any time by giving us notice. Subject to the terms of this Agreement, we may terminate Services at any time, with or without notice. If your Service has been suspended due to non-payment, you may be charged a reactivation fee. We may deactivate any Number before you receive notice of termination without liability to you. Termination by either of us may be with or without cause.

Termination. Term Service Plan. EXCEPT AS PERMITTED BY THE AGREEMENT, IF YOU TERMINATE YOUR TERM SERVICE PLAN BEFORE THE END OF THE TERM, OR IF WE TERMINATE SERVICES FOR CAUSE BEFORE THE END OF THE TERM, YOU WILL BE REQUIRED TO PAY THE EARLY TERMINATION FEE ASSOCIATED WITH YOUR TERM SERVICE PLAN. No early termination fee is charged if you terminate a Term Service Plan in accordance with the return policy associated with your Term Service Plan. After the expiration of the term, the Terms relating to Non-Term Service Plans apply.

Termination. General. Regardless of whether you have a Non-Term or a Term Service Plan, we may terminate or suspend Services to you without liability if: (1) you breach any provision of this Agreement (including if you fail to pay any charges for Services); or (2) you fail to pay any charges due us for equipment or otherwise. If Services are terminated before the end of your current invoicing cycle, we will not prorate the monthly recurring charge to the date of termination, and you will not receive a credit or refund for any unused minutes in your Service Plan.

Use of Services and Equipment; Availability. You must be at least 18 years old to subscribe to our Services. We may require you to provide proof of your age and identity. If you are under 18 years old you may be eligible for certain Services that have Account Spending Limits if a person 18 years or older is also named as a subscriber on the Account. Your PCS Phone will not accept the services of any wireless provider other than Sprint (but see Roaming). Services and equipment may not be used for any unlawful, fraudulent or abusive purpose. By requesting Services, you agree that you will not use Services and equipment in any unlawful, fraudulent or abusive manner. You may not resell or lease Services or equipment to anyone.

Coverage. Most services are only available within the operating range of the Sprint Nationwide PCS Network (also see Roaming). Coverage is not available everywhere. Coverage and quality of Services may be affected by conditions within or beyond our control, including network problems, signal strength, your equipment, and atmospheric, geographic, or topographic conditions. We do not guarantee service availability or that there will be no interruptions or delays in Services (e.g., dropped calls, blocked calls, etc.).

Number. We may change the phone number ("Number") assigned to your PCS device without compensation by giving you prior notice. You do not own the Number. You may not modify the Number we program into any phone or other equipment, duplicate the Number to any device other than that authorized by us or, except as allowed for by law, transfer (port) the Number to any other individual or entity. If you transfer the Number to another carrier, the terms of the Agreement (including the rights and obligations set forth in the Termination paragraphs) still apply. In certain instances, you may transfer a Number from another carrier to Sprint. Sprint does not in any way guarantee that such transfers to (or from) Sprint will be successful. If a transfer to Sprint is not successful, you will be responsible any discounts provided to you with the purchase of your PCS device. See our printed in-store materials or visit www.sprintpcs.com for additional important information on Number transfers.

Phone Activation Fee. You may be required to pay a non-refundable phone activation fee when you activate a new Number, have us switch a Number to a different phone, have your current Number changed, we activate a different phone on your existing account or your Service Plan says so.

Charges. For most forms of wireless Service, your usage will be charged from the time you first initiate contact between your phone or other wireless device and the network until the network connection is broken, whether or not you are successful in connecting with the service with which you seek to connect, even if the connection is later broken or dropped. An exception is that you are not charged for

voice calls that are not completed. You are charged for completed calls to your Number from the time shortly before the phone starts ringing until the call is terminated. You will be charged peak rates for the entire duration of calls initiated during the peak time periods applicable to your Service. You will be charged off-peak rates for the entire duration of calls initiated during the off-peak time periods applicable to your Service. In addition to these usage charges, you may be charged for recurring monthly service charges, applicable local and long-distance toll charges, other usage charges, (including voicemail access, call waiting, call forwarding, etc.), connection fees, roaming charges, directory assistance, call completion charges, account review and management charges, optional features you select at an extra cost, surcharges related to government programs, and taxes. Charges for most Services are incurred in one-minute increments, with partial minutes of use rounded up to the next highest minute. You must pay, by each invoice due date, all charges for Services provided to the Number for each phone or other equipment that our records show you activated, no matter who actually uses or has possession of the phone or other equipment at the time Services are provided.

PCS Vision (Third Generation) Charges. For PCS Vision wireless services, you will be charged on a per kilobyte basis for data used, rather than for airtime used. As long as your PCS Vision device is connected to the Sprint Nationwide PCS Network ("PCS Vision network"), you will be incurring data usage charges. You are responsible for all data activity from and directed to your PCS Phone, regardless of who initiates the activity. We will invoice you for all data directed to the internet address (or "IP address") assigned to your device in a given PCS Vision session, regardless of whether your device actually receives the data. You will be charged for data usage initiated by others as well as those you initiate. You will be charged for additional data used in transporting and routing on the network. You will be charged for partial and interrupted data downloads or other use, including re-sent data, and for unsuccessful attempts to reach websites and use other applications and services, including those resulting from dropped network connections. If you use a Premium Service (including services provided by third parties but for which you are billed on your PCS Invoice), you will be charged for data used in transport and routing in addition to the charge for the Premium Service. The amount of data used and charged to you will vary widely, depending upon the specific PCS Vision wireless application or other service you use, the amount of data used in the specific application or service, and network congestion and other matters. For this and other reasons, estimates of data usage - for example, the size of downloadable files - will vary from what you actually use. You cannot receive incoming calls while using third generation services. Data usage will be rounded up to the next whole kilobyte. Kilobyte usage will be rounded up to the next full cent. Rounding up will occur at the end of each separate session or each clock hour (at the top of each hour), if the session spans more than 1 clock hour. When traveling on our PCS Vision network, a session may be ended and new session initiated, although no interruption to the actual data session will occur. Your invoice will not separately identify the number of kilobytes attributable to your use of specific sites, sessions or services used.

PCS Vision Premium Services. Your PCS Vision wireless services may allow you to access or download premium content for an additional charge. Certain PCS Vision services (e.g., games, ringtones and screen savers) primarily contain premium services content. Access to and downloading of premium content is not included with PCS Vision services. The additional charges for this premium content will be billed to you on your PCS Invoice. You will be charged for this content (at rates and charges specified at the time of access or download) that will be in addition to data usage charges you will incur while connected to the enhanced PCS Vision network. We provide no warranties and make no representations or claims with regard to third-party Premium Services. In certain instances, subject to the terms of the content purchased, we may delete premium and non-premium items downloaded to available storage areas (e.g., your vault), including any pictures, games and other content. We may limit the amount of Premium Services you may purchase in a specific timeframe (month, week, day, or other time period). We may suspend your use of Premium Services without prior consent or notice if we have reason to suspect fraudulent or unauthorized use of your Premium Services account, but we make no assurances that we will suspend your account.

Other Terms Applicable to PCS Vision Wireless Usage. Use of PCS Vision wireless services requires the purchase of a separate third generation wireless compatible phone or other device and is subject to any software, memory, storage or other limitation in the phone or other equipment. Not all applications and services work, or work the same, on all third generation wireless phones and devices. Check the materials accompanying your phone or device to determine which applications and services it will support. PCS Vision wireless services are not available while off the PCS Vision network. PCS Vision services are not available for server devices or host computer applications, other systems that drive continuous heavy traffic or data sessions, or as substitutes for private lines or frame relay connections. Unlimited PCS Vision plans/options are only available with phones or PCS smart phones where the device is not being used as a modem in connection with other equipment (e.g., computers, PDAs, etc.) through use of connection kits or other phone-to-computer/PDA accessories, or Bluetooth or other wireless technology. Sprint reserves the right to deny or to terminate service without notice for any misuse. Sprint is not responsible for any opinions, advice, statements, services applications or other information provided by third parties and accessible through PCS Vision wireless services. Neither Sprint nor its vendors or licensors guarantees the accuracy, completeness or usefulness of information that is obtained through the PCS Vision wireless services. You are responsible for evaluating such content. Use of certain PCS Vision wireless services, including some messaging services, may result in the disclosure to others of your email address and other information about you in connection with your internet usage. Your accessing of, or use of, third party sites or services accessible PCS Vision wireless services may require the disclosure of information about you, subject to the policies of those sites and services. You consent to receiving advertising, warnings, alerts and other messages, including broadcast messages. Your access to PCS Vision wireless services is controlled by a password.

Voice Command. PCS Voice Command is an optional service that allows you to place calls by using speech recognition technology. Calls to 911 or similar emergency numbers cannot be placed through the Voice Command feature. Airtime and applicable long distance charges for a call completed from your Number using the Voice Command feature begin when you press or activate the TALK or similar key(s) and end when your call is terminated by hitting the END key or by returning to the Voice Command platform. If you initiate and complete another call without leaving the Voice Command platform, a separate charge for that call will begin from the time the previous call was terminated. Airtime and applicable long distance charges will be applied to the entire length of a completed call initiated from Voice Command. Using Directory Assistance to input names into your Voice Command address book will incur additional charges.

Invoicing. Invoicing cycles are approximately 30 days in length. Invoicing cycles and dates may change from time to time. Except as otherwise provided in your Service Plan, monthly recurring charges (MRCs) are invoiced one invoicing cycle in advance. Charges for Services are usually invoiced as soon as possible after the charges accrue. We may, however, invoice you for usage and charges occurring before the invoicing cycle being invoiced, if they were not previously invoiced. If you are invoiced for usage incurred during a prior invoicing cycle, those minutes will be applied to your Service Plan minutes for the current invoicing cycle. However, if you change your PCS Service Plan between the time the usage was incurred and the beginning of the current invoicing cycle, those minutes from the prior invoicing cycle will be charged at the rate per minute for usage over included minutes provided in the Service Plan in effect at the time the usage was incurred.

Payment. If you have authorized payment for Services or equipment by credit card or by debiting a bank account, no additional notice or consent is required before we invoice the credit card or debit the bank account for all amounts due to us or billed by us on behalf of a third party. You must promptly notify us of any change in your invoicing address or of the credit card or bank account used for payment. We reserve the right to require payment by money order, cashier's check or other secured form of payment. If we take action to receive payment beyond invoicing you for charges for Services or equipment, you must pay our costs and expenses of collection, including attorneys' fees and expenses, the fees of any collection agency and court costs. If we act as an invoicing agent for a third-party service provider, payments received are first applied to amounts due and owing to us and any remaining amounts are applied to sums due and owing to the third-party service provider. We may immediately charge an additional fee for any check or other negotiable instrument endorsed by you and returned unpaid by a financial institution for any reason. You may be charged fees for certain methods of payment.

Late Payment Charges. Payment is past due if we do not receive it by the due date shown on your invoice. Any payment for Services and equipment not made when due accrues late charges until paid at the rate of 5% per month or at the highest rate allowed by law. Acceptance of late or partial payments (even if marked "paid in full") does not waive our right to collect all amounts that you owe us. If your Service has been suspended due to non-payment, you may be charged a reactivation fee.

Disputed Charges. You must raise any dispute that you have about any charges invoiced to you within 15 days of the date of the invoice or you have accepted the invoice. You may notify us of any dispute by notifying PCS Customer Service Solutions. Calls to our sales or general business offices are not notice of a dispute. If disputed invoice procedures are described on the invoice, you must follow them.

Account Spending Limit. If we agree to provide Services to you on an Account Spending Limit basis, we will tell you your Account Spending Limit before we start Services to your Number, or as reasonably practicable after the limit is imposed. If we require a deposit for you to establish or keep Services on an Account Spending Limit basis, we will hold the deposit as partial guarantee of payment for Services (see Deposits). Charges for Services accrue against your Account Spending Limit as they are incurred. We may charge an initial ASL start up fee. We may charge a monthly ASL service fee, in addition to your recurring monthly service charge. We may suspend Services to your Number without prior notice to you when your account balance reaches your Account Spending Limit. Services are restored when you have paid any past due balance and pay a specified minimum amount to reduce your account balance below your Account Spending Limit. We may change this minimum amount at any time upon notice to you. You may pay any past due balance and the minimum amount by any method authorized by Sprint. Contact PCS Customer Service Solutions for information about authorized methods of making these payments. We may charge you a fee for calls that involve our live customer care services. If we provide Services to you on an Account Spending Limit basis, Services and coverage may be limited in certain ways. You must pay all charges for Services even if they exceed the amount of your Account Spending Limit.

Clear Pay. If we agree to provide Services to you as a Clear Pay customer, we may suspend Services to your Number without prior notice to you immediately when your bill becomes past due. Even if your bill is not past due, we may suspend services if your unpaid usage exceeds \$125 or another amount to be determined by your past credit or usage history. If we require a deposit for you to establish or keep Services as a Clear Pay customer, we will hold the deposit as partial guarantee of payment for Services (see Deposits, below). Contact PCS Customer Service Solutions for information about authorized methods of making these payments. We may charge you a fee for calls that involve our live customer care services. If we provide Services to you on as a Clear Pay basis, Services and coverage may be limited in certain ways. You must pay all charges for Services whether or not your Services are suspended or terminated.

Deposits. If we require a deposit for you to establish or keep Services, we will hold the deposit as partial guarantee of payment for Services. We may change the deposit amount at any time to reflect revised estimated monthly charges based upon your usage. A deposit may not be used to pay any invoice (unless it is used to pay a final invoice) or delay payment. The deposit amount, the length of time we hold the deposit and changes to the deposit amount are determined based on your credit and payment history. The rate of interest, if any, on the deposit is subject to change. We may mix deposits with our other funds. If Services are terminated for any reason, we may, without notice to you, apply your deposit toward payment of

outstanding charges and return any excess to you at your last known address within 75 days after termination of Services. If the U.S. Postal Service cannot deliver the money to you and returns it to us, we will hold it for you for one year from the date of return and, during that period, we may charge a servicing fee against the deposit balance. Any money held during this one-year period will not accrue interest for your benefit. You forfeit any portion of the money left after the one-year period.

Wireless Web and Voice Portal Services. Wireless Web Services are part of the Services that can be obtained through Sprint. Wireless Web Services are not available in all markets or while roaming off the Sprint Nationwide PCS Network. Use of Wireless Web Services requires an Internet-ready PCS Phone or certain other equipment (or both) and is subject to any memory, storage or other limitation in the phone or other equipment. Wireless Web Services are not available on PCS Vision phones or devices. The Caller ID blocking feature is not available when using Wireless Web Services. Any use of Wireless Web Services deducts from your Service Plan minutes. For data calls (including Wireless Web and Voice Portal calls) that are attempted, but not completed, you are charged for the time during which the network attempts to connect the call. You are charged for time spent connected to the Wireless Web or Voice Portal, including time spent browsing on the Internet or Voice Portal and reviewing or scrolling through Internet information on-line while still connected to the Sprint Nationwide PCS Network. Not all Internet sites can be accessed and you may receive an error message if you attempt to access a site that cannot be accessed through Wireless Web Services. You are also charged for Wireless Web connections to review your PCS account information. Wireless Web Services are not available with all Service Plans. Sprint is not responsible for any opinions, advice, statements, services or other information provided by third-parties and accessible through Wireless Web Services or Voice Portal Services. Neither Sprint nor its vendors or licensors guarantees the accuracy, completeness or usefulness of information that is obtained through the Wireless Web Services or Voice Portal Services. You are responsible for evaluating such content.

Taxes and Surcharges. We invoice you for taxes, fees and other charges levied by or remitted directly to federal, state or local authorities, or foreign government on Services including, without limitation, sales, gross receipts, use, and excise taxes. If you claim any tax exemption, you must provide us with a valid tax-exempt document. Any tax exemption applies only from the date we receive a valid tax-exempt document. We also invoice you for fees that we collect and remit to the government such as Universal Service, and for surcharges that we collect and keep to pay for the costs of complying with government mandates such as number pooling and portability, and Enhanced 911 service. These charges are neither taxes nor government imposed assessments.

Roaming. Calls made while off the Sprint Nationwide PCS Network are “roaming” calls. Your PCS Phone is specifically designed and engineered to work only on the Sprint Nationwide PCS Network. It works on another CDMA PCS provider’s system only when a roaming agreement is in place between Sprint and the other providers. If your PCS Phone is a dual-mode phone, it works on both a CDMA PCS provider’s system (in addition to the Sprint Nationwide PCS Network) and a wireless analog telecommunications provider’s system only when roaming agreements are in place

between Sprint and the other providers. If we do not have a roaming agreement in place, you may be able to place roaming calls “manually” by using a valid credit card. If there is a gap or other interruption of coverage within a PCS coverage area that prevents connection with the Sprint Nationwide PCS Network and your dual-band phone is set to roam automatically when outside PCS coverage, you may incur roaming fees within a PCS coverage area. Certain features and services may not be available when roaming (including PCS Vision, voicemail, call waiting, call forwarding, etc.).

Phones and Other Equipment. Phones and other equipment may be purchased and returned as provided in the purchase documents. We are not the manufacturer of the phones or other equipment. The only warranties on the phones or other equipment are any limited warranties extended by the manufacturers. We have no liability in connection with the phones and other equipment or for the manufacturers’ acts or omissions.

Lost or Stolen Equipment. If your phone or other equipment is lost or stolen, you must notify us by calling PCS Customer Service Solutions. You are responsible for all charges for Services provided to the Number for the lost or stolen equipment before you notify us of the loss or theft. We will deactivate Services to the Number upon notification to us of any loss or theft. You may be required to provide evidence of the loss or theft (for example, a police report or sworn statement). If the equipment is later found, we may require that you exchange it for another phone or other equipment before we reactivate Services (if we do reactivate Services), as well as require you to pay a reactivation fee. We will deactivate Services to any Number without prior notice to you if we suspect any unlawful or fraudulent use of the Number. You agree to cooperate reasonably with us in investigating suspected unlawful or fraudulent use.

Messages. You will incur airtime usage charges when accessing your voicemail from your PCS Phone. You may also incur charges in accessing text messages from your PCS Phone. You may access your voicemail without incurring airtime usage charges by checking your voicemail from a wireline phone. We may impose limits on the number of voicemail or text message that can be retained through your PCS account. Audible or visual indicators of text or voicemail messages, including mailbox icons on your PCS Phone, may not always provide an up to date indication of new messages. In certain instances, you may be required to manually reset or clear your mailbox indicator.

Caller ID. If you do not want people you call to receive the Number assigned to your phone, you must call PCS Customer Service Solutions for information about automatic Caller ID blocking. The Number assigned to your phone can be blocked on a per-call basis by dialing *67 + Destination Number + TALK (or similar key), but Caller ID delivery resumes on the next call you make. Caller ID display on incoming calls to your Number depends on receiving the information from the calling party.

TTY Access. A TTY (also known as TDD or Text Telephone) is a telecommunications device that allows people who are deaf or hard of hearing, or who have speech or language disabilities, to communicate by telephone. TTY doesn't work with all PCS Phones. If you have a PCS TTY-capable phone, it may not function effectively, or at all, when attempting 911 calls due to the equipment or software of the answering agency. Therefore, a TTY device should not be relied on for 911 calls.

Pay-Per-Call Service. We will not complete calls from your Number to 900, 976 and similar numbers for pay-per-call services.

International Calling. You may be limited in the international destinations that you can call with Services. You should contact PCS Customer Service Solutions for information about international destinations that you cannot call.

Limitation of Liability. Except as otherwise provided in this section, our sole liability to you for any loss or damage arising out of providing or failing to provide Services (including mistakes, omissions, interruptions, delays, errors, or defects) does not exceed (1) in cases related to a specific piece of equipment, the prorated MRC for Services to the piece of equipment during the affected period, or (2) in cases not related to a specific piece of equipment, the prorated MRCs for Services to you during the affected period. Neither we nor our vendors, suppliers or licensors are liable for any damage arising out of or in connection with:

- a) any act or omission of any telecommunications service or other service provider other than us;
- b) any directory listing;
- c) any dropped calls or inability to place or receive calls;
- d) any interruption of Services, including interruptions caused by equipment or facilities failure or shortages, transmission limitations or system capacity limitations;
- e) traffic or other accidents, or any health-related claims allegedly arising from the use of Services, phones, equipment or accessories used in connection with the Services;
- f) the use of Wireless Web Services and PCS Vision applications and services, including the accuracy or reliability of any information obtained from the Internet using Wireless Web Services or from Voice Portal Services, PCS Vision wireless services or Internet services, content or applications not supported by Sprint PCS;
- g) any late or failed message delivery;
- h) any interruption or failure of 911 or E911 emergency services or identification of the Number, address or name associated with any person accessing or attempting to access emergency services from your phone;
- i) the installation or repair of any products or equipment by parties who are not our authorized employees or agents;
- j) events due to factors beyond our control, including acts of God (including, without limitation, weather-related phenomena, fire or earthquake), war, riot, strike, or orders of governmental authority;

k) any act or omission of any third party or independent contractor that offers products or services in conjunction with or through the Services; or

l) your negligent or intentional act or omission.

NO CONSEQUENTIAL OR OTHER DAMAGES. UNDER NO CIRCUMSTANCES ARE WE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR SPECIAL DAMAGES OF ANY NATURE WHATSOEVER ARISING OUT OF OR IN CONNECTION WITH PROVIDING OR FAILING TO PROVIDE SERVICES, PHONES OR OTHER EQUIPMENT USED IN CONNECTION WITH THE SERVICES, INCLUDING, WITHOUT LIMITATION, LOST PROFITS, LOSS OF BUSINESS, OR COST OF REPLACEMENT PRODUCTS AND SERVICES. THIS SECTION SURVIVES TERMINATION OF THIS AGREEMENT.

Indemnification. You indemnify and defend us, our partners, directors, officers, employees and agents from and against any claim, action, damage, liability and expense arising out of or in connection with: (1) your acts or omissions that occur in connection with your use of the Services or equipment used in connection with the Services, and (2) any communications you make or receive using the Services. This indemnification extends to and includes any attorney's fees and costs incurred by us arising from any actions or claims to which this indemnification applies, or from the contesting of the applicability of this provision. This section survives termination of this Agreement.

MANDATORY ARBITRATION OF DISPUTES. ANY CLAIM, CONTROVERSY OR DISPUTE OF ANY KIND BETWEEN THE CUSTOMER AND THE COMPANY AND/OR ANY OF ITS EMPLOYEES, AGENTS, AFFILIATES OR OTHER REPRESENTATIVES, WHETHER SOUNDING IN CONTRACT, STATUTE, OR TORT, INCLUDING FRAUD, MISREPRESENTATION, FRAUDULENT INDUCEMENT, OR ANY OTHER LEGAL OR EQUITABLE THEORY AND REGARDLESS OF THE DATE OF ACCRUAL OF SUCH CLAIM, CONTROVERSY OR DISPUTE SHALL BE RESOLVED BY FINAL AND BINDING ARBITRATION AS PRESCRIBED IN THIS SECTION. THE FEDERAL ARBITRATION ACT, NOT STATE LAW, GOVERNS THE QUESTION OF WHETHER A CLAIM IS SUBJECT TO ARBITRATION. HOWEVER, NOTHING CONTAINED IN THIS ARBITRATION PROVISION SHALL PRECLUDE THE CUSTOMER FROM RESOLVING ANY CLAIM, CONTROVERSY OR DISPUTE IN SMALL CLAIMS COURT HE OR SHE OTHERWISE WOULD HAVE THE RIGHT TO PURSUE.

A single arbitrator engaged in the practice of law will conduct the arbitration. The arbitrator will be selected according to the rules of CPR or, alternatively, may be selected by agreement of the parties, who shall cooperate in good faith to select the arbitrator. The arbitration will be conducted by, and under the then-applicable rules of the CPR Institute for Dispute Resolution. All expedited procedures prescribed by the applicable rules will apply. Any required hearing fees and costs shall be paid by the parties as required by the applicable rules or as required by applicable law, but the arbitrator shall have the power to apportion such costs as the arbitrator deems appropriate. The arbitrator's decision and award will be final and binding (subject to the appeal clause below), and judgment on the award rendered by the arbitrator may be entered in any court with jurisdiction.

An appeal may be taken under the CPR Arbitration Appeal Procedure from any final award of any arbitral panel in any arbitration arising out of or related to this agreement that is conducted in accordance with the requirements of such Appeal Procedure. Unless otherwise agreed by the parties and the appeal tribunal, the appeal shall be conducted at the place of the original arbitration.

If any party files a judicial or administrative action asserting a claim that is subject to arbitration and another party successfully stays such action or compels arbitration, the party filing that action must pay the other party's costs and expenses incurred in seeking such stay or compelling arbitration, including attorney's fees.

Notices. You may get our current address for written notice by calling PCS Customer Service Solutions. Written notice to you is sent to your last known address in our invoicing records. Written notice is effective three days after deposit in the U.S. mail, postage prepaid, and properly addressed. Unless required by this Agreement or Applicable Laws, (1) you may notify us by calling PCS Customer Service Solutions, and (2) we may notify you by leaving a message for you on your PCS Phone, answering machine or with your answering service. Notice addresses may be changed by giving notice as provided in this section.

Choice of Law; Jurisdiction. This Agreement is governed by and must be construed under federal law and the laws of the State of Kansas, without regard to choice of law principles.

General. If either of us does not enforce any right or remedy available under this Agreement, that failure is not a waiver of the right or remedy for any other breach or failure by the other party. Our waiver of any requirement in any one instance is not a general waiver of that requirement and does not amend this Agreement. This Agreement is subject to any applicable federal and state law (collectively, "Applicable Laws"). If any part of this Agreement is held invalid or unenforceable, that part is interpreted consistent with Applicable Laws as nearly as possible to reflect the original intentions of the parties and the rest of this Agreement remains in full force and effect. Section headings are for descriptive purposes only and are not used to interpret this Agreement. You may not assign this Agreement to any other person or entity without our prior written approval. This Agreement (including any referenced documents and attachments) makes up the entire agreement between you and us and replaces all prior written or spoken agreements, representations, promises or understandings between you and us. The provisions of this Agreement that are contemplated to be enforceable after the termination of this Agreement survive termination of this Agreement. If there is a conflict, the Service Plan (including any Term Service Plan) controls over the Terms.

Terms of Picture Mail Service

The Picture Mail service (“Service”) – including access to and use of the services at www.pictureemail.sprintpcs.com – is provided to you by Sprint under the following terms and conditions and incorporate the Terms and Conditions set forth at www.sprintpcs.com which include the Terms and Conditions of Service provided with your PCS Phone User’s Guide, terms regarding copyright and trademark matters, and other terms relating to the use of our services. Your use of the Service indicates your acceptance of all of these terms (collectively “Terms”). Sprint may change these Terms from time to time at our discretion with or without notice to you. Any changes will be posted on the Service.

1. Eligibility

The Service is provided to individuals who are at least 18 years old and to minors who have parental permission. We encourage parents and guardians to take an active role in protecting the privacy and security of their children. If you as a parent have any concerns regarding this issue, please feel free to contact us at pictureemail@sprintpcs.com.

2. Membership Fees

Picture Mail is available at an additional monthly charge (in addition to any charges you may pay for PCS Vision services) through Sprint and provides you basic services, such as the ability to store and share pictures taken on select PCS Vision Picture Phones or devices. Additional features or services (beyond basic services) may also be available from time to time for an additional charge. If you have previously not signed up for the Service with activation of your PCS Service Plan, you may add this Service to your account for an additional monthly charge through a PCS Vision Picture Phone.

3. Picture Mail Password

We will have access to your Picture Mail Password and User Name. We may remind you of your password, at your request, by sending an email to the address you used when creating your account. We will not disclose your Picture Mail Password to third parties, but we may access your account if necessary to maintain the Service, to comply with lawful requests from governmental authorities, or in response to court orders, subpoenas, complaints.

4. Photo Loss

Sprint does not warrant that pictures or albums stored will not be deleted, modified or damaged. If pictures or images are particularly valuable, have sentimental or other intangible value or are otherwise unique or irreplaceable, reliable storage alternatives should be used, including hard copy duplication and electronic back up and storage.

5. Use of Related Software

Any software that is provided for download and installation on your personal computer or electronic device in connection with the Service is licensed under the terms and conditions of a separate software license agreement. These license agreements are available for your review upon download, installation and/or use of that software.

6. Use of Picture Mail

Solely for the purposes of displaying your pictures to selected persons and fulfilling your print orders, you grant us permission to use, download, upload, copy, print, display, reproduce, modify, publish, post, transmit and distribute any material included in your albums.

7. Member Conduct

(a) In consideration for use of the Service, you agree to provide true, accurate, current and complete information about you as prompted during the registration process, and to maintain and update this information to keep it true, accurate, current and complete.

(b) You are responsible for maintaining the confidentiality of your Picture Mail Password and Account, and you agree to be fully responsible for all activities which occur through anyone's use of your Picture Mail Password or account, whether or not authorized by you. You agree to notify Sprint immediately of any unauthorized use of your password or account or any other breach of security.

(c) You must provide at your own expense all equipment and software required to use the Service, including computer and photography equipment, application software, modems, and access to the Internet. We are not responsible for delays resulting from incompatibility of such equipment and software, or from improper configuration or maintenance of such equipment and software.

(d) While we do not control the content of any member submissions to the Service and do not have any obligation to monitor such content, if we have any reason to believe that any language, content, graphics or other materials contained within your content is inappropriate, we may, in our sole discretion, refuse to process any print orders, remove your pictures from our servers, suspend your account, restrict access to it, remove content from it, or terminate it.

(e) You agree (1) not to use the Service for illegal purposes; (2) not to interfere with or disrupt the Service or servers or networks or software or data connected to the Service; (3) to comply with all requirements, procedures, policies and regulations of networks connected to the Service; and (4) to comply with all applicable laws regarding the transmission of technical data exported from the United States. You agree to abide by all applicable local, state, national, and international laws and regulations in your use of the Service and in your use of any software downloaded from the Service, including, without limitation, copyright, trademark, obscenity and defamation laws.

(f) You agree not to interfere with the use and enjoyment of the Service by other users of the Service. You agree not to attempt to gain unauthorized access to other computer systems or networks connected to the Service.

(g) You agree not to transmit through the Service, or upload to it (1) any pictures or other content in violation of the copyrights, privacy rights or other rights of any other person; (2) any unlawful, harassing, libelous, privacy invading, abusive, hateful, threatening, harmful, vulgar, defamatory, obscene or otherwise objectionable material of any kind; (3) any material that violates the rights of another, including, but not limited to, the intellectual property rights of another; (4) any material that harms minors; (5) any material that violates any applicable local, state, national, or international law or regulation; or (6) "junk mail," "spam," "chain letters," or unsolicited mass distribution of email.

8. Privacy Statement

In order to register you as a member of the Service, we ask you to supply us with some basic information (email address, user selected Picture Mail Password, name) during the registration process and, occasionally, at other times while using the Service. All uses of your information will be in accordance with our privacy policy, as set forth in the following Privacy Policy. As this policy may be updated from time to time, a current version can be found at www.sprintpcs.com.

PRIVACY POLICY

(a) Sprint respects the privacy of its customers, and other individuals and businesses using the Websites owned and operated by Sprint and its Affiliates ("Sprint Websites"). This updated Privacy Policy effective October 22, 2001, is to keep you informed about the types of information collected on Sprint Websites and how the information is used and protected. The revised Privacy Policy includes information about advertisements on Sprint Websites and access to your account information.

Sprint protects the privacy of its local, long distance and wireless customers consistent with the Federal Telecommunications Act and rules and regulations issued by the Federal Communications Commission.

Sprint's Privacy Policy for its high speed Internet services can be accessed at: www.sprint.com/privacypolicy/broadbandservices.

There are two types of information that may be exchanged between the Sprint site and the user during each visit to a Sprint site. They are:

1. General technical data transmitted between your computer and the Sprint site that does not identify you personally.
2. Personally identifiable information that you voluntarily share. The types of personally identifiable information that you might share include your name, address, phone number, email address and credit card number.

(b) Anonymous Information

In order to provide you with the information and services that you look for from the Sprint Websites, Sprint gathers certain types of information from you that are not personally identifiable. This is called anonymous information and includes:

1. The type of Internet browser you use when you visit
2. The types of computer operating system you use
3. The search engine you use to access the Sprint Websites (such as “AOL.com,” “Yahoo.com” or “Go.com”)
4. The specific Sprint Website that you visit (sprint.com, sprintpcs.com, etc.).

The anonymous information collected is not associated with you personally or your business. Sprint uses this anonymous information in the aggregate to improve Sprint Websites and the services we provide through those sites.

(c) Use Of Cookies

Sprint Websites may use “cookies” to collect the anonymous information described in this Privacy Policy. Cookies are bits of encrypted data that are loaded by a Sprint server onto your computer or other device when you visit a Sprint Website. The server can retrieve the cookies the next time you visit a site and use them to identify the computer as a return visitor. Sprint uses cookies to collect non-personally identifiable information and generically track usage patterns on the Sprint Websites in order to monitor activity and administer the sites. Sprint also uses information obtained from cookies to improve Sprint Websites, and make decisions concerning advertising, product offerings and services. Most users can disable cookies from their Internet browsers, receive a warning before a cookie is placed on their computer, and erase all cookies from their computer hard drives by following the instructions provided by the browser.

(d) Advertisements On Sprint Websites

Advertising companies deliver ads on some Sprint Websites. You should be aware that when you click on these ads, the advertising companies may also deploy cookies to receive anonymous information about ad viewing by Internet users on Sprint Websites and other Websites. This information is associated with your Web browser, but cannot be associated with your name or email address without your permission. Therefore, advertising companies may know where your computer goes on the Web, but they do not know who you are unless you tell them. Sprint does not provide personally identifiable information about its customers or Sprint Website visitors to these advertising companies.

(e) Personally Identifiable Information

Sprint may ask you to provide what is often referred to as “personally identifiable information” such as your name, address, telephone number and email address when you use Sprint Websites to: purchase a service or product online, enter a contest or sweepstakes, ask to receive information, respond to a survey, register with a Sprint Website, access your account, ask for a personalized service, request customer service online, or apply for a job. You always have the alternative of mailing or calling Sprint with the information requested if you do not wish to provide it online. Personally identifiable information provided at a Sprint Website

to order Sprint services other than Internet services will be protected in the same manner as when the information is provided by other means such as over the telephone or by mail. We protect customer information obtained from the local, long distance and wireless service customers of Sprint consistent with federal laws governing telecommunications services and with regulations issued by the Federal Communications Commission. Sprint's Privacy Policy for its Internet services can be accessed at: www.sprint.com/privacypolicy/broadbandservices.

We use personally identifiable information provided at a Sprint Website in the following ways unless otherwise specified:

1. For its intended purpose (such as to complete an online order for service).
2. To provide you with information about new PCS Products and Services or products and services offered in conjunction with Sprint business partners.

(f) Disclosure To Third Parties

Sprint will not sell or disclose to outside parties any personally identifiable information obtained from a Sprint online service or the registration at a Sprint Website without your consent except under the following circumstances:

1. When required by law,
2. When disclosure is necessary to protect the safety of a customer, third party or Sprint's property,
3. If it is required in connection with any sale or transfer of all or a portion of Sprint's assets.

When Sprint uses agents, contractors or other companies to perform services on its behalf, Sprint will require that they protect your personally identifiable information consistent with this Privacy Policy. Sprint may share the anonymous information described in this Privacy Policy with third parties from time-to-time.

(g) Email Communications

Email is an increasingly popular communication tool through which you and your business may communicate with Sprint. Likewise, Sprint may use email to communicate with you, respond to your email, and to tell you about new products and services. If you do not wish to receive email promotions and new products and service announcements from Sprint, please follow the instructions that appear at the end of the email communication that you receive from Sprint to have your name removed from the list.

(h) Security

Sprint utilizes several encryption methods to ensure that the data you submit on any of the Sprint Websites is secure. Through this "secure session," information that you input into a Sprint online order form will be sent and will arrive privately and unaltered at a Sprint server. This security prohibits access to your information by other companies and Web users.

(i) Children

Sprint does not intend to collect personally identifiable information from individuals under 18 years of age. If Sprint becomes aware that a user who is under 18 is using a Sprint Website, Sprint will specifically instruct that individual that they are not to submit information on Sprint Websites without a parent or guardian's consent. If a child has provided Sprint with personally identifiable information without the knowledge of Sprint, a parent or guardian of the child may contact Sprint at privacy@mail.sprint.com and Sprint will delete the child's information from our existing files.

(j) Links

Some Sprint Websites contain links to other Websites that are owned and operated by parties other than Sprint. Please be aware that this Privacy Policy does not extend to any Websites other than those owned and controlled by Sprint.

(k) Account Information

You may always contact us at privacy@mail.sprint.com or by telephone or mail to verify your name, address, email address, telephone number and/or billing information. Sprint will correct any information that is inaccurate.

(l) Questions

If you have questions or comments regarding this Privacy Policy, you may contact us at privacy@mail.sprint.com. If you have submitted personally identifiable information, and would like that information deleted from our records, please contact us at our email address, privacy@mail.sprint.com. We will use reasonable efforts to delete that information from our files.

(m) Updates

Sprint may amend this Privacy Policy from time-to-time. These changes will be posted online.

9. Usage and Storage

We and our suppliers assume no responsibility for: (1) any full or partial loss, deletion or failure to store your pictures or any other data; (2) any notice or lack of notice of such loss, deletion or failure to store your data; or (3) any correct or erroneous informing of or failure to inform user of such loss, deletion or failure to store your data. From time to time we may establish an upper limit on the size of data storage that you are permitted to use on the Service and/or an upper limit on the frequency or amount of usage that you are permitted on the Service or related software. We may establish a reasonable period of time (for example, three months) such that if you do not use the Service at least once during such period, we may terminate the Service to you for non-use, and delete pictures and other data that you may have stored through the Service.

10. No Resale of Service or Software

Your membership account is intended only for personal, noncommercial use. You agree not to reproduce, duplicate, copy, sell, resell or exploit for any commercial purposes, any portion of the Service, use of the Service, access to the Service, or related software.

11. Proprietary Rights

You agree that content, including but not limited to software, text, pictures, graphics, video, music, sound, or other materials or information, contained in the Service or contained in sponsor advertisements or presented to you through the Service or advertisers is protected by copyrights, trademarks, service marks, patents, or other proprietary rights, laws, and/or treaties. You agree that you are permitted to use such materials and information only as expressly authorized by us or the true owner of the right in question and you may not copy, reproduce, transmit, distribute, or create derivative works of such materials or information without proper express, written authorization from us or the true owner of the right in question.

12. Changes to the Service and Termination of the Service

(a) We may change these Terms from time to time without notice to you. Should you object to any of these Terms or any changes to them, or should you become dissatisfied with the Service in any way, your only recourse is to immediately: (1) discontinue use of the Service; and (2) terminate the Service and notify us of the termination. Termination of the Service may, in some instances, require you to change your PCS Service Plan.

(b) We may discontinue the Service or any feature or portion of the Service at any time, with or without notice. You agree that upon modification or discontinuance of the Service, we may delete the data you have stored on the Service.

(c) You agree that we may terminate your membership in the Service and delete any and all information, posting, communications, albums and pictures at any time, without notice, if we believe: (1) that you have failed to use the Service at least once during a reasonable span of time as determined by us; (2) that you have violated or acted inconsistently with the letter or spirit of these Terms; (3) that you have violated our rights or the rights of other users or parties; or (4) that you have abused or misused the Service in any way, including but not limited to exceeding any limits that we may place on the amount of data that any individual may store on the Service.

(d) We reserve the right at all times to disclose any information posted by you or any other user as necessary to satisfy any law, regulation or governmental request, or to edit, remove, or refuse to post any information or materials, in whole or in part, that in our sole discretion are objectionable or in violation of these terms and conditions.

(e) Except as otherwise set forth in this provision, in the event your Service is terminated we will make reasonable efforts to provide 30 days prior notice before may delete any data from the Service.

13. Disclaimers

(a) We hereby disclaim any and all responsibility or liability for the accuracy, content, completeness, legality, reliability, operability or availability of information or material in this Service. We further disclaim any responsibility for the deletion, misdelivery, failure to store or untimely delivery of any information or material. We disclaim any responsibility for any harm resulting from downloading or accessing any information or material through the Service. You agree that you, the member, will bear all risk associated with any content that you access.

(b) All processing of film, prints, slides, negatives or digital images is subject to our Terms. You agree that your sole remedy for any damage or loss of any materials that you submit to us for processing, printing, storage, transmission or other handling, even if caused by negligence or other fault, will only entitle you to replacement with a like amount of unexposed film and processing. EXCEPT FOR THE EXCLUSIVE REMEDY OF REPLACEMENT, THE HANDLING OF ANY FILM, PRINT, SLIDE, NEGATIVE OR DIGITAL IMAGE IS WITHOUT WARRANTY OR LIABILITY AND RECOVERY FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES IS EXCLUDED.

(c) THIS SITE AND ALL PRODUCTS, SERVICES AND CONTENT PROVIDED THROUGH IT ARE PROVIDED "AS IS" AND "AS AVAILABLE" AND WITH NO WARRANTIES WHATSOEVER. TO THE FULLEST EXTENT PERMITTED BY APPLICABLE LAW, WE EXPRESSLY DISCLAIM ALL WARRANTIES OF ANY KIND, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE AND NON-INFRINGEMENT. WE DISCLAIM ANY WARRANTIES FOR THE SECURITY, RELIABILITY, TIMELINESS, AND PERFORMANCE OF THIS SERVICE, OR THAT THIS SITE OR OUR SERVER IS FREE OF VIRUSES OR OTHER HARMFUL COMPONENTS. WE DISCLAIM, TO THE FULLEST EXTENT PERMITTED BY LAW, ANY WARRANTIES FOR OTHER SERVICES OR GOODS RECEIVED THROUGH OR ADVERTISED ON THIS SERVICE OR RECEIVED THROUGH ANY LINKS PROVIDED IN THE SERVICE, AS WELL AS FOR ANY INFORMATION OR ADVICE RECEIVED THROUGH THE SERVICE OR THROUGH ANY LINKS PROVIDED IN THE SERVICE.

(d) YOU EXPRESSLY AGREE THAT, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, UNDER NO CIRCUMSTANCES SHALL SPRINT BE LIABLE TO ANY USER ON ACCOUNT OF THAT USER'S USE OR MISUSE OF AND RELIANCE ON THE SITE OR ITS ASSOCIATED PRODUCTS AND SERVICES. SUCH LIMITATION OF LIABILITY SHALL APPLY TO PREVENT RECOVERY OF DIRECT, INDIRECT, INCIDENTAL, CONSEQUENTIAL, SPECIAL, EXEMPLARY, AND PUNITIVE DAMAGES (EVEN IF WE HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES). SUCH LIMITATION OF LIABILITY SHALL APPLY WHETHER THE DAMAGES ARISE FROM USE OR MISUSE OF AND RELIANCE ON THE SITE, PRODUCTS OR SERVICES, FROM INABILITY TO USE THE SITE OR FROM THE INTERRUPTION, SUSPENSION, OR TERMINATION OF THE SITE OR DAMAGES INCURRED BY REASON OF OTHER SERVICES OR GOODS RECEIVED THROUGH OR ADVERTISED ON THIS SERVICE OR RECEIVED THROUGH ANY LINKS PROVIDED ON THIS SITE, AS WELL AS BY REASON OF ANY INFORMATION OR

ADVICE RECEIVED THROUGH OR ADVERTISED ON THE SERVICES OR RECEIVED THROUGH ANY LINKS PROVIDED IN THE PRODUCTS AND SERVICES.

(e) BECAUSE SOME JURISDICTIONS PROHIBIT THE EXCLUSION OF CERTAIN WARRANTIES OR THE EXCLUSION OR LIMITATION OF LIABILITY FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES, THE ABOVE LIMITATION MAY NOT APPLY TO YOU. OUR OWN AND OUR SUPPLIERS' TOTAL LIABILITY FOR DAMAGES, LOSSES, AND CAUSES OF ACTION, REGARDLESS OF LEGAL THEORY, WILL IN NO EVENT EXCEED THE AGGREGATE DOLLAR AMOUNT YOU HAVE PAID TO US UNDER THESE TERMS, OR US \$25.00, WHICHEVER IS GREATER.

14. Indemnity

You agree to indemnify and hold Sprint and its parents, suppliers, licensors, subsidiaries, affiliates, officers, and employees harmless from any claim or demand, including reasonable attorneys' fees, made by any third party due to or arising out of: (1) use of the Service by you or by anyone using your account; (2) violation of these Terms by you or by anyone using your account; or (3) violation or infringement by you, or by anyone using your account, of intellectual property rights or any other rights of any other person.

15. General Provisions

We may assign our rights and duties under these Terms to any third party at any time without notice to you. These Terms and the relationship between you and Sprint shall be governed by the laws of the State of California without regard to its conflict of law provisions. You and Sprint agree to submit to the personal and exclusive jurisdiction of the courts located within the State of California. You agree that regardless of any statute or law to the contrary, any claim or cause of action arising out of or related to use of the Service must be filed within one (1) year after such claim or cause of action arose or be forever barred. The failure of Sprint to exercise or enforce any right or provision of these Terms shall not constitute a waiver of such right or provision.

If any provision of these Terms is found by a court of competent jurisdiction to be invalid, the parties nevertheless agree that the court should endeavor to give effect to the parties' intentions as reflected in the provision, and that the other provisions of the Terms shall be valid and remain in full force and effect.

Manufacturer's Warranty

Customer Limited Warranty

SPRINT SPECTRUM, L.P., (Sprint) offers you a limited warranty that the enclosed subscriber unit (Product), including accessories in the product package, will be free from defects in material or workmanship as follows:

SUBSCRIBER UNIT:

A. SPRINT ONE (1) YEAR LIMITED WARRANTY: For a period of one (1) year from the date of purchase, Sprint will, at its option, either pay the parts and labor charges to any authorized PCS Phone service facility to repair or replace a defective product (with new or rebuilt parts/replacements). After this one (1) year period, you must pay all parts, shipping and labor charges.

B. REPAIRS: For a period equal to the remainder of the original limited warranty period on an original Product or for the 180 days after the date of repair/replacement, whichever is longer, Sprint will repair or replace (with new or rebuilt replacement) defective parts or Product used in the repair or replacement of the original Product under this Limited Warranty.

Proof of purchase in the form of a bill of sale or receipted invoice warranty repair document which is evidence that the Product is within the warranty period must be presented to obtain warranty service. This limited warranty is not transferable to any third party, including but not limited to any subsequent purchaser or owner of the Products.

Transfer or resale of a Product will automatically terminate warranty coverage with respect to the Products.

This limited warranty does not cover and is void with respect to the following: (i) Products which have been improperly installed, repaired, maintained or modified (including the antenna); (ii) Products which have been subjected to misuse (including Products used in conjunction with hardware electrically or mechanically incompatible or used with accessories not supplied by Sprint), abuse, accident, physical damage, abnormal operation, improper handling and storage, neglect, exposure to fire, water or excessive moisture or dampness or extreme changes in climate or temperature, (iii) Products operated outside published maximum ratings; (iv) cosmetic damage; (v) Products on which warranty stickers or Product serial numbers have been removed, altered, or rendered illegible; (vi) customer instruction; (vii) cost of installation, removal or reinstallation; (viii) signal reception problems (unless caused by defect in material and workmanship); (ix) damage the result of fire, flood, acts of God or other acts which are not the fault of Sprint and which the Product is not specified to tolerate, including damage caused by mishandling and blown fuses; (x) consumables (such as fuses); or (xi) any Products which have been opened, repaired, modified or altered by anyone other than Sprint or a Sprint authorized service center.

This warranty does not cover customer education, instruction, installation, set up adjustments, or signal reception problems.

This warranty is valid only in the United States.

USE WITH ACCESSORIES NOT SUPPLIED BY SPRINT OR OTHERWISE NOT EXPRESSLY AUTHORIZED BY SPRINT MAY BE DANGEROUS.

SPRINT SPECIFICALLY DISCLAIMS LIABILITY, AND SHALL HAVE NO OBLIGATION TO PROVIDE TO BUYER ANY OTHER REMEDY, FOR ANY AND ALL DIRECT, INDIRECT, SPECIAL, GENERAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING, BUT NOT LIMITED TO LOSS OF PROFITS, LOST SALES, LOSS OF USE OF THE PRODUCT, OR ANTICIPATED PROFITS ARISING OUT OF USE OF OR INABILITY TO USE ANY PRODUCT (FOR EXAMPLE, WASTED AIRTIME CHARGES DUE TO THE MALFUNCTION OF A PRODUCT), DAMAGE DUE TO IMPROPER OPERATION OR MAINTENANCE, INSTALLATION, CONNECTION TO IMPROPER VOLTAGE SUPPLY. OR ATTEMPTED REPAIR OF THE PRODUCT BY ANYONE OTHER THAN A FACILITY AUTHORIZED BY SPRINT. THIS WARRANTY DOES NOT COVER PRODUCTS SOLD AS IS OR WITH ALL FAULTS, OR CONSUMABLES, (SUCH AS FUSES). THIS WARRANTY DOES NOT APPLY WHEN THE MALFUNCTION RESULTS FROM USE OF THE PRODUCT IN CONJUNCTION WITH ACCESSORIES, PRODUCTS OR ANCILLARY OR PERIPHERAL EQUIPMENT NOT SUPPLIED BY OR EXPRESSLY AUTHORIZED FOR USE BY SPRINT, AND WHERE IT IS DETERMINED BY SPRINT THAT THERE IS NO FAULT WITH THE PRODUCT ITSELF.

REPAIR OR REPLACEMENT, AS PROVIDED UNDER THE WARRANTY, IS YOUR SOLE AND EXCLUSIVE REMEDY FOR BREACH OF THE LIMITED WARRANTY. TO THE EXTENT PERMITTED BY APPLICABLE LAW,

SPRINT MAKES NO OTHER WARRANTIES OF ANY KIND, EXPRESS OR IMPLIED, WITH RESPECT TO THE PRODUCTS FOR A PARTICULAR PURPOSE OR AGAINST INFRINGEMENT WITHIN THE TIME PERIOD SPECIFIED IN THE LIMITED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ON THIS PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THIS WARRANTY.

Some States do not allow the exclusion or limitation of incidental or consequential damages, or allow limitations on how long an implied warranty last, so the above limitations or exclusions may not apply to you.

This limited warranty gives you specific legal rights, and you may have other rights which vary from State to State.

For other Warranty Service Information, please call PCS CUSTOMER SOLUTIONS at 1-888-211-4727.

Copyright(c) 2004 ACCESS Systems America Inc. ACCESS, NetFront are registered trademarks or trademarks owned by ACCESS Co., Ltd. in Japan and selected countries worldwide. NetFront is a registered trademark of NetFront Communications, Inc. in the United States and is used under a license. Portions of this software are based in part on the work of the Independent JPEG Group.

Powered by JBlend™ Copyright 1997-2004 Aplix Corporation. All right reserved. JBlend and all JBlend-based trademarks and logos are trademarks or registered trademarks of Aplix Corporation in Japan and other countries.

Copyright © 2004 Sprint Spectrum L.P. All rights reserved. No reproduction in whole or in part without prior written approval. Sprint, the diamond logo design, and all other Sprint marks referenced herein are trademarks of Sprint Communications Company L.P. All other trademarks are property of their respective owners.

Index

A

- Abbreviated Dialing 30, 59
- Advanced Information 111
- Airplane Mode 54
- Alarm Clock 111
- Alert Notification 42
- Answering Calls 21
- Any Key Answer 58
- Area Name 48
- Auto Answer 56

B

- Background 51
- Backlight Time Length 45
- Battery
 - Capacity 16
 - Charging 17
 - Disposal 231
 - Installing 16
 - Removing 16
 - Standby Time 16
 - Talk Time 16

C

- Calculator 112
- Call Alarm
 - Adding 104
 - Alerts 105
 - Editing 106
 - Erasing 103, 109
 - Menu 105
 - Viewing 106
- Call Forwarding 185
- Call Guard 77
- Call History
 - Erasing 87
 - Making a Call 85
 - Options 85
 - Prepending 87
 - Saving 86
 - Viewing 84

- Call Waiting 183
- Callback Number 62
- Caller ID 183
- Calling in Lock Mode 67
- Chat 207

Contacts

- Adding 89, 93
- Dialing 29
- Editing 93, 95
- Erasing 92
- Finding 28, 90
- Options 92
- Saving 27
- Secret 97
- Current Time Setting 62

D

Dialing

- Abbreviated 30, 59
- Contacts 29
- Numbers With Pauses 28
- Options 20
- PCS Services 98
- Speed Dialing 30, 94, 148
- Voice-Activated Dialing 124

Display Settings

- Area Name 48
- Background 51
- Backlight Time Length 45
- Display Screen 46
- Font Size 52
- Greeting 44
- Incoming Calls 47
- My Buddy 51
- Screen Saver 50
- Standby Mode 49

Downloading

- Accessing Menus 208
- Data Size 122
- Erasing 70, 122
- Icon Indication 121
- Sorting 121
- Viewing Memory 122

E

- Email 204
- Emergency Calling 25
- End-of-Call Options 27
- Event
 - Adding 101
 - Alerts 102
 - Erasing 103, 109
 - Menu 103
 - Viewing 103, 106

F

- FCC Notice 232
- Features 14
- Font Size 52, 199

G

- Games
 - Downloading 210
 - Playing 211
- Greeting 44

H

- Hard Pause 28
- Headset Mode 60
- Help 6

I

- Icon Indication 121, 161
- In-Call Options 26
- Input Mode
 - Alphabet Mode 33
 - Numbers 34
 - Preset Suffixes 34
 - Smileys 34
 - Symbols 34
 - T9 Text Mode 32
- Instant Messaging 206

L

- Language 63
- Limit Use 68
- Location Settings 53
- Lock Code 67
- Locking Phone 66
- Locking Picture 67
- Locking through SMS 71

M

- Making Calls 18
 - Making Ready Link Call 136, 137, 138
 - Menu Diagram 80
 - Message Notification 61
 - Messaging
 - Displaying 194
 - Folder
 - Creating 200
 - Drafts 196
 - Editing 201
 - Erasing 201, 202
 - Outbox 197
 - Font Size 199
 - Moving a Message 201
 - Options 197
 - Picture Mail 194
 - Prepending 199
 - Sending 195, 196, 197
 - Storage 194
 - Mini Flashlight 63
 - Missed Call Notification 25, 138
 - Muting 24
 - My Buddy 51
 - My Shortcut 56
- ## **N**
- Net Guard 190

O

Online Picture Mail

Auto Delete 160

Managing 170

Options 172

Sending 171

Uploading 171

Open/Close Flip Option 57

P

Passcode 71

PCS Business Connection 221

PCS Ready Link

Adding 143, 144

Alert 134, 150

Contacts List 135

Copying 141

Default View 151

Editing 145

Erasing 147

Finding 142

Making Calls

by Entering Number 138

Contact 136

Group 137

Options 140

Preparing 134

ReadyLink Guard 149

Receiving 139

Redialing 140

Restarting 149

Ringer Types 150

Saving 142

Setting 133

Speakerphone 151

Speed Dialing 148

Updating 148

PCS Services

Call Forwarding 185

Call Waiting 183

Caller ID 183

Customer Solutions 3, 5, 6, 65,
71, 97, 273

Directory Assistance 7

Operator Services 7

PCS Vision

Chat 207

Downloading 208

Email 204

Enabling and Disabling 72

FAQs 222

Games 210

Launching 189

Ringers 212

Screen Savers 214

Web 216

PCS Voice Command 223

Phone Number

Dialing with Pauses 28

Displaying 18

Finding 28

Saving 27

PictureMail Password 154

Pictures

Auto Delete 160

Flash 156

Multiple Shots 157

Options 155

Self-timer 156

Sending 162, 164

Settings 159

Shutter Sound 159

Status Area 160

Storing 165

Taking 153

Zoom 158

Power-off Tone 40

Premium Services Content 208

Prepend Dialing 87, 199

Preset Messages 61

Preset Suffixes 34

Q

Quiet Ringer 22

R

Resetting

Phone 70

Picture Account 70

Through SMS 71

Ringer

Assigning 213

Downloading 212

Purchasing 213

Tone Length 40

Types 36

Volume 24, 41

Roaming

Analog Networks 75

Digital Networks 74

Setting 76

S

Safety Guideline 226

Scheduler

Calendar 100

Call Alarm 104

Erasing 108, 109

Event 101

Memory 109

Setting Holidays 100

Setting the Time/Date 100

To Do 107

Screen Call

Activating 129

Erasing 131

Recording 130, 131

Reviewing 131

Selecting Announcement 130

Screen Savers

Assigning 215

Downloading 214

Purchasing 215

Secret Mode 97

Security Menu

Accessing 65

Changing the Lock Code 67

Locking Phone 66

Unlocking Phone 66

Shortcut 56

Side Key Guard 58

Silence All 43

Sleep Mode 60

Sound Settings

Silence All 43

Start-up/Power-off Tone 40

Volume Settings 24, 41

Speakerphone 23

Special Number 69

Speed Dialing 30, 94, 148

Standby Time 16

Start-up Tone 40

Symbols 34

T

T9 Text Input 32

Talk Time 16

Three-Way Call 184

To Do Items

Adding 107, 108

Deleting 108, 109

Editing 107

Viewing 107

Tone Length 40

TTY 55

Turning On and Off 15

2-Second Pause 28

U

Unlocking Phone 66

Unmute 24

Updates 203

User Address 110

User Name 187

V

Version 110

Voice Command

Creating Address Book 224

Getting Started 224

Making a Call 225

Voice Dial

Erasing 125

Programming 124

Reviewing 125

Using 124

Voice Memo

Erasing 128

Options 127

Recording 126

Voice Prompt 40

Voicemail

Button Guide 178

Clearing Message Icon 181

Menu Key 182

Message Alerts 177

Notification 176

Options 179

Retrieving 177

Setting Up 176

Volume Settings

During a Conversation 24

Muting 24

Ringer 24, 41

W

Warranty 272

Web

Launching 189

Navigating 191

Net Guard 190

User Name 187

World Clock 49, 112